'68'

MICRO JOURNAL

VOLUME VI ISSUE VIII • Devoted to the 68XX User • Aug./Sept. 1984
"Small Computers Doing Big Things"

SERVING THE 68XX USER WORLDWIDE

PHOTO CREDIT: NASA

0 74470 12810

08

'68'

MICRO JOURNAL

Portions of the text for **68 MICRO JOURNAL** was prepared
using the following furnished hard/software.

COMPUTERS-HARDWARE
Southwest Technical Products
219 W. Rhapsody
San Antonio, Texas 78216
SO9-5/8 DMF disk-CDS1-8212W-Sprint 3 Printer
-
GIMIX Inc.
1337 West 37th Place
Chicago, IL 60609
Super Mainframe-OS9-FLEX-Assorted Hardware

EDITORS-WORD PROCESSORS
Technical Systems Consultants, Inc.
111 Providence Road
Chapel Hill, NC 27514
FLEX-Editor-Processor
-
Great Plains Computer Company, Inc.
PO Box 916
Idaho Falls, ID 83401
STYLO-Mail Merge

Editorial Staff

Don Williams Sr. — Publisher
Larry E. Williams — Executive Editor
Tom E. Williams — Production Editor
Robert (Bob) Nay — Color Editor

Administrative Staff

Mary Robertson — Office Manager
Penny Williams — Subscriptions
Michael Westfall — Shipping/Rec.
Christine Kocher — Accounting

Contributing Editors

Ron Anderson
Norm Cammo
Peter Dibble
Dr. Theo Elbert
William E. Fisher
Dr. E.M. Pass

Special Technical Projects

Clay Abrams K6AEP
Tom Hunt

CONTENTS

Items Submitted for Publication

Articles submitted for publication should be
accompanied by the authors full name, address, date and
telephone number. It is preferred that articles be
submitted on either 5 or 8 inch diskette in TSC Editor
format or STYLO format. All diskettes will be returned.

The following TSC Text Processor commands ONLY should
be used (due to our proportional processor): .sp space,
.pp paragraph, .fl fill and .nf no fill. Also please do
not format within the text with multiple spaces. The
rest we will enter at time of editing.

STYLO commands are all acceptable except the .pg page
command, we print edited text files in continous text.

All articles submitted on diskettes should be in TSC
FLEX™ format, either FLEX2 6800, or FLEX9 6809 any ver-
sion.

If articles are submitted on paper they should be on
white 8X11 bond or better grade paper. No hand written
articles (hand written or drawn art accepted). All
paper submitted articles will be photo reproduced.
This requires that they be typed or produced with a
dark ribbon (no blue), single spaced and type font no
smaller than 'elite' or 12 pitch. Typed text should be
approximately 7 inches wide (will be reduced to column
width of 3 1/2 inches). **Please use a dark ribbon!**

All letters to the editor should also comply with the
above and bear a signature. Letters of 'gripes' as well
as 'praise' are solicited. We attempt to publish all
letters to the editor verbatim, however, we reserve the
right to reject any submission for lack of 'good taste'.
We reserve the right to define what constitutes 'good
taste'.

Advertising: Commercial advertisers please contact the
68 Micro Journal advertising department for current
rate sheet and requirements.

Classified: All classified must be non-commercial.
Maximum 20 words per classified ad. Those consisting of
more than 20 words should be figured at .35 cents per
word. 20 words or less $7.50 minimum, one time, paid in
advance. No classified ads accepted by telephone.

Microware presents 4 new OS-9 software packages.

1 LEVEL II PRINT SPOOLING SYSTEM

This versatile package gives your OS-9 Level Two System a complete print spooling management capability for time-sharing applications. Features of the spooling system are:

- Handles up to seven independent spooling devices and queues with "print on first available device" feature.
- Prints large block header pages between listings with date, time, user name and job name.
- Multiple listing copy option.
- Complete forms change capability for each job and device.
- Prints formatted or unformatted listings.
- Status command displays print queues and status.
- User can kill or change priority of queued jobs.

Available only for OS-9 Level Two Systems.

Suggested List Price: $150.00   Manual Only: $15.00

2 RMA RELOCATABLE MACRO ASSEMBLER

At last — a full feature relocatable macro assembler and linkage editor for OS-9. RMA permits sections of assembly language programs to be independently assembled to "relocatable object files". The linkage editor takes any number of program sections and/or library sections and combines them into a single executable OS-9 memory module. Global data (including indexed and direct addressing modes) and program references are automatically resolved in the process. The macro facility permits commonly used statement sequences to be defined, then used within the program with appropriate parameter substitution. RMA also supports conditional assembly and library source files.

Suggested List Price: $200.00   Manual Only: $20.00

3 OS-9 FILE HANDLER TOOLBOX

Introducing a special toolbox for OS-9 users who do a lot of file manipulation! A collection of 12 useful OS-9 command programs; Most can be used as "filters" using OS-9 pipeline facilities. Included are:

D — unformatted directory listing with "wild card" matching
Compress — does character compression on text files.
Expand — restores a "compressed" file to the original state.
Split — breaks a file into smaller files.
Space — indents lines with optional spacing between lines.
Code — decodes any key on a keyboard to hex.
Qsort — quick sort for small files, directories, etc.
Pr — versatile formatted file printing utility.
Tr — transliterates text pattern to substitution pattern.
Grep — searches file for a pattern and prints matching lines.
Xmode — same "tmode" except changes are made to the device descriptor.
Count — counts words, lines, or characters within a text file.

Suggested List Price $85.00

4 ENTERTAINMENT PACK I

A collection of games and other interesting programs that are not only entertaining but serve as good instructional examples of Basic09 programming techniques. All programs include complete Basic09 source files and can be easily edited to run on standard alphanumeric or graphics terminals.

Blkjak — A Vegas-rules blackjack game.
Clk — graphical display of a wall clock on your terminal.
Dogs — Greyhound racing with simulated graphics.
Eliza — Basic09 version of the famous artificial intelligence simulation of natural language dialogue with a psychiatrist.
Haiku — Program that creates original "haiku" prose.
Quest — a mini-"Adventure" game.
Rats — find your way out of a computer-generated maze — from a rat's point of view.
Towers — a graphical display of the solution to the "Tower of Hanoi" puzzle.

Suggested List Price: $85.00

MICROWARE®

Microware Systems Corporation
P.O. Box 4865 • Des Moines, IA 50304
515-279-8844 • Telex 910-520-2535

OS-9 and Basic09 are trademarks of Microware and Motorola. Unix is a trademark of Bell Labs.

Flex User Notes

Ronald W. Anderson
3540 Sturbridge Court
Ann Arbor, MI 48105

Bells and Whistles or Bricks and Mortar?

I recently have been doing some thinking about software again. This topic is the result of my having looked at a couple of products over the past several months. As usual, let me say first that I am not out to pick on anyone in particular, so I will use no names. What I am saying is that the author of software normally becomes so involved in the detail that he can't see the overall picture very clearly. (I include myself in these remarks). Because of this tendency, sometimes, the software writer will include a "cute" feature of marginal use to the user, while completely overlooking some very frequently used feature, either omitting it, or making it very awkward to use.

The first example might be a screen editor that I received some time ago. I found that it would actually total values in a table so that totals could be run for rows or columns or both. That is a nice "whistle" by my definition. I've never needed such a function in an editor, and if I did, it would be so easy to use a calculator alongside to do the totals, and then type them in.... Now, I was going into this editor's features and I discovered that in order to indent a paragraph, I had to put the cursor at the first line of the paragraph and type a sequence of instructions. At that point, the paragraph would reformat. Now to indent the next paragraph, it was again necessary to bump the cursor down to that paragraph and type the sequence of instructions in again. Worse, any editing of the first line of any paragraph, would cause the indent to be lost, and the pr ess for that paragraph had to be repeated.

I imagine that most of you have used screen editors by now, and you know that most have some provision for indenting. The problem with the above mentioned editor could be fixed simply by modifying the paragraph formatter routine so it would ignore (and leave in place) any leading spaces at the start of a new paragraph. The spaces could be inserted by spacing or tabbing over a few spaces at the start of each paragraph, and would remain there permanently. When I wrote the supplier of the editor with the suggestion, he apparently didn't take kindly to my criticism, and he has not answered my letter. I don't know about everyone's applications for editors, but I would imagine that a paragraph indent would be performed vastly more times than totalizing the columns or rows in a table of numbers. I can only say that this editor was skimpy on the basic building blocks but contained unnecessary frills.

Example 2 is a compiler that I looked at recently. I found that it had a nice feature that would convert integer numbers to the equivalent Roman Numerals (in a choice of upper or lower case yet!). That is a nice feature that many users of the compiler would never use, and some would use infrequently. I found later that a couple of very standard features of the compiler had not been implemented. (In this case, the version I received was a "very preliminary" one, and the missing features are being implemented, but it struck me strange that the frills were done before the standard features).

When I wrote some software some time ago, I was guilty of doing some things "cleverly" that could have been done in a way much more standard to FLEX users. When this was pointed out to me by someone that received a copy for comments, I was defensive on first reading of the letter, but decided that the comments were quite valid, and I changed the software to make it operate in a manner much more as expected and in keeping with FLEX. I think the result was a greatly improved package.

Perhaps this indicates that not only is a software author too close to the project to be able to write the instruction manual, but that he may also be too close to the project to be objective about the features that are included. We all have software that is "almost". A second opinion would have made most of that software at least "great" if not perfect.

While I am throwing bricks, let me also pitch a couple of bouquets. Though there is reason to leave the bricks aimed at folks who will remain anonymous, there is no reason not to mention names for some positive feedback.

Dan Farnsworth of Palm Beach Software (and of recent "great debate" fame) sent me preliminary versions of his SPELLB. I gave it a workout and responded with several suggestions, all of which were taken seriously. Both Dan and I feel that the final result was better for having had two people look at it.

When I first received PL/9 I made a number of suggestions for improvements in features, and I found Graham Trott, its author, most willing to listen. Many of the suggested improvements were implemented, and the rest at least brought forth an explanation of why they couldn't be added.

More Compiler Debate Evidence

I know, I said last time that the topic had been exhausted, but something has happened since then. Let me give you a case history of a project in which I have been involved. I've mentioned this previously, but it has come to a conclusion so I can report final results.

Several months ago, I received a call from a company that needed some help with software. They had a fairly complex calculation program that they had written for a 6800, in assembler. The execution time for the calculation was 160 seconds. "Send me the listing and a non-disclosure agreement, and I'll see what can be done", I said. The listing arrived, and I found that the math package was a BCD version. The scientific functions EXP, LOG, and XTOY (in BASIC XTY) were required. The functions were accurate enough, but with the slow BCD arithmetic and overly complex functions, XTOY took 5 seconds all by itself.

A look at the code for the calculations showed that the author had used B↑5 and X↑2 liberally rather than the much faster B*B*B and X*X. I changed those and then as a first step wrote a new SQRT function since the package used X↑0.5 for the square root, and I knew that to be a slow calculation. The result was an execution time of 16 seconds. Next step was to write more efficient scientific functions. That done, the time was down to 8 seconds.

I had mentioned switching to a binary math package, and we decided to go in that direction for further improvement. I had a math package that I had done previously, and I made some improvements to it, adding the necessary scientific functions. Now, of course the calculations had to be recoded to match the new math package. It was about a 12 hour chore to recode the 8 or ten pages of calculations and get them debugged. Resulting execution time was not quite what I had hoped, but it was approximately 2.75 seconds. I could probably, with some hours of looking and hair pulling manage to get that down to 2.5 seconds or a little less.

I wrote the customer that I felt this was about as well as we could do with a 6800. Because the 6809 has the MUL instruction that does an 8 bit by 8 bit multiply in 12 microseconds (six on a 2 MHz system) it should run considerably faster, particularly in light of the fact that the scientific functions use many multiplies and few divides, so as to take advantage of the '09's capabilities.

I have a 6809 version of the binary math package, but I would have to code the improvements to make it compatible. I decided to test my theory about the '09 advantage by coding the calculation in PL/9 and seeing how fast it would run. Would you believe that it ran in 0.280 seconds? The MUL instruction brought about a speed advantage of nearly ten times, in going to a 6809. I've still not coded the 6809 binary math package for compatibility so I can't yet test it, but I'm betting it won't be much better (if any) than the PL/9 results.

I draw several conclusions from all this. First, Assembler code is not inherently fast. It has to be efficiently coded to have the speed advantage so glibly claimed by its proponents. Second, the pr essor DOES make a difference, though the advantage of one processor over another will depend greatly on the application. In a simple control application consisting mostly of AND and OR logic and shifts and rotates, the 6809 would have no speed advantage over the 6800, for example. Third, compiled code is not necessarily slow or inefficient. The PL/9 output was about 20% larger than the best assembler code version, and about the same size as the original assembler code version.

As I stated above, the recoding of the calculations and the debug of the assembler version took about 12 hours. It took no more than half an hour to write the PL/9 code, and it was debugged in five minutes on the

second try. Now someone convince me that assembler was a better choice for this application!! I think this was a fair test. The job to be done was clearly defined at the start. The chore was simply one of coding the calculations, and there was no advantage gained by having done one version ahead of the other. I am about as familiar with and experienced in assembler coding as in PL/9 so there was no advantage one way or the other due to familiarity. I wrote the scientific functions package for the assembler version, and was responsible at least in part for the package in PL/9, so that there was no familiarity bias in that area either. The fact is that it is much easier to code:

Z=(1-SQR(B*B+A*A*A)/3)↑(1/3)

Than it is to code:

```
JSR MATH
FCB PSH
FDB ONE
FCB PSH
FDB A
FCB CPY
FCB CPY
FCB FML
FCB FML
FCB PSH
FDB B
FCB CPY
FCB FML
FCB FAD
FCB PSH
FDB TIREE
FCB FDV
FCB FSB
FCB PSH
FDB ONE
FCB PSH
FDB THREE
FCB FDV
FCB SWP
FCB EXT
JSR XTOY
JSR MATH
FCB STR
FDB Z
```

I made a couple of mistakes in coding the above example and had to correct them just now. Multiply this little example by 20 or so, and you get an idea of the order of magnitude of the project.

Maintenance Policy

I've recently been disturbed by what seemed to be restrictive policies on the part of Windrush Microsystems, and I wrote and told them so. Their reply to my criticism is well thought out and it explains their policies quite well, so, with their permission, I am going to explain here.

My irritation was over the fact that Windrush won't provide an update of a customer's compiler unless that customer returns the original disk on which the software was supplied, to England, fully insured. Windrush then will supply the update on the original disk, to the customer. My irritation was twofold. First, it takes a long time for a disk to make a round trip to England. Second, insurance and postage are not cheap. "Why can't you have U. S. distributors provide updates?" I asked. Well, I found out. Let me quote from Bill Dickinson's letter.

"The fact that we upgrade customers who report bugs free of charge has got to be worth the delay and cost of postage back to the U.K. If we wanted to get clever we would start charging maintenance like everybody else. I'll let you decide which of the(se) two policies is the better one:

1. You buy my product. You've got 90 days to report any problems with it. If you find a bug on the 91st day you have got to buy my maintenance contract to get the bug fixed. My maintenance contract costs $75.00 per year. You will have to send me the original disks to get bugs fixed on your maintenance contract. You've had my product for over a year. I just released a new version with all sorts of improvements. You have not been paying for maintenance so you will have to pay for the upgrade which is 50% of the purchase price of a new one. If you have paid me $75 a year for the past two years you will get the upgrade free.

2. You buy my product. If you find a bug I don't care if you bought it last week or two years ago, I will try to

resolve the problem. If solving the problem means giving you the latest version of the product then you will get the latest version of the product free of charge. All you have to do is send me the original disk. You've had my product for over a year. I just released a new version with all sorts of improvements. All you have to do is send me $25.00 and the original disk. I will send you the latest version and a new manual (if applicable)."

Of course Windrush's guarantee is the latter. Bill's letter continues:

"Asking for the original disk back may seem to be a waste of everyone's time until you consider the following points:

"We do not keep any sales records from one year to the next. Therefore we have no way of verifying whether someone is a 'paid up' customer or a rip-off artist. If the customer can produce our original disk then he is considered to be legitimate. If he can't he isn't.

"It prevents the customer from selling his old copy to someone else, who then expects to get an upgrade for $25.00!

"We have a great desire to keep our administrative costs to a very low level. If our administrative costs start to rise then we will have to adopt policy #1 as it will be the only way we could recover the losses.

"We lose money on $25.00 upgrades and positively lose money when we give someone a copy of the latest version to fix a bug he has discovered in a product that is two years old. The least the customer should be willing to do is to send us his disk back at a cost of about $15.00 and wait bit for the replacement.

"It is not really practical to send 'upgrade' packs to the distributors to stock as there is always the danger that they will be sold and neither we nor the author see any money from the sale.

"The bottom line is that for us to be able to support policy #2 the customer has got to be willing to put up with a little delay. If you had the choice of paying us an additional $75.00 within 90 days of purchasing the product and $75 for every year of maintenance you wanted in return for the ability to phone us for a free copy of the latest version (without having to return the disk first) would you pay it? I rest my case."

Bill, thanks for the clarification and defense of your policies. Now they make rather good sense to me. I've always found Windrush responsive to reports of bugs. One thing else to remember is that it takes about ten days for a letter from the U.S. to make it to England and about the same the other way. Of course I am talking about air mail letters. In addition to the mail delay, software authors sometimes get busy or have other commitment so that they can't drop everything and search for a bug immediately.

Well, Don Williams tells me that I have been getting a little too long winded lately, so I am going to give him some space for some other stuff this time.

SUPPORT YOUR ADVERTISERS

OS9 USER NOTES

by Peter Dibble
("OS-9 Users Notes" Columnist;
'68' Micro Journal)

The First Step Into OS-9

There has been some call recently for information for the beginning user of OS-9. Color Computer users new to OS-9 feel swamped by the number of details involved in the operating system. This column is an attempt to make OS-9 seem simpler to new users.

The OS-9 operating system has started to develope a reputation for complexity and obscurity -- in other words, user hostility. It is an unjust accusation. The thing that makes OS-9 appear confusing is the way it is presented. There are many subtle features in the operating system, and a large array of utilities. The manuals that come with it could help but don't. The OS-9 manuals were written as reference manuals, not tutorials. They drop everything on you at once. A new OS-9 user who is experienced with computers or very brave should read the manuals, wrap his mind around the whole thing, and sit down at the computer to enjoy OS-9. That is the quick, brute force, way to learn OS-9, but if it doesn't work for you, I recommend a gentler approach.

My copy of CoCo OS-9 includes about fifty commands. All these commands are important to at least some people, but most of them are only confusing to to new OS-9 users. The entire English language includes more than a hundred thousand words, but most people only use fewer than twenty thousand of them, and it is possible to communicate with a vocabulary of a thousand words or less. Operating systems like Unix and OS-9 are very much like English in that respect. Of all the commands available under OS-9 about a dozen are really necessary.

The bare minimum set of OS-9 commands are:
backup
copy
del
dir
edit
format
free
list
rename
shell The shell is the program which processes the commands you type into OS-9 and runs the other commands. Several commands are built into the shell. They are:
chd
chx
ex
w
kill
setpr The only shell commands that you really need to know are chd and chx, if you mean to do assembly language programming you will also need:
asm
debug If you will be using Basic09 you will need:
Basic09
RunB
GFX

Of all these commands there are four that need explanation especially badly. Format needs to be discussed because it is dangerous; if it is used carelessly it can destroy important information. BACKUP is a relatively fast way to copy an entire disk (it is a very good thing to get into the habit of doing this); perhaps a careful discussion of BACKUP will encourage people to use it more. Explaining DIR is a good excuse to say a few things about directories: one of the more important features of OS-9. CHX and CHD also relate to directories, and seem straightforward. What they are supposed to do is less important to a person with a OS-9 on a small computer than their unofficial side effects.

Format

The format command is the first one to use. Until a disk has been formatted it is unuseable to OS-9. The format command writes a pattern on the disk which marks the disk off into sectors (which amount to pigeon-holes for OS-9 to store data in). After writing the pattern format checks the disk to make certain the pattern is recorded correctly on the disk. If it isn't, format will note that the sectors where the errors occurred are faulty, and those sectors won't be used to store data. Format also writes some information which will be used to manage files on that disk. In the process of doing all this the format program completely erases the disk. If the disk is fresh out of a box of new disks you can feel certain that there is nothing on the disk that you care about, but, if it is one you are recycling, be very careful. After format is started any data that was on that disk is gone forever.

Put the disk you want to format in the drive you aren't using for the system disk (I'm going to assume you have your system disk in the drive OS-9 calls /D0, and the disk you want to format in drive /D1). Invoke the format command by typing FORMAT /D1 at the OS-9 prompt. The command line should look like:
OS9:FORMAT /D1 to which you should get the response:
COLOR COMPUTER FORMATTER
FORMATTING DRIVE /D1
Y (YES) OR N (NO)
READY? This is format giving you a chance to change your mind. It is also a way for you to format disks if you only have one drive, by asking format to format the disk in drive /D0 and replacing the system disk with the disk you want to format in at this point. In either case double check that you are about to format the correct disk. If you want to be especially safe take your system disk out of drive /D0 at this point even if you are formatting the disk in drive one. There is no danger at all of format writing on the wrong disk, but you can't be too careful. If you reply N to the READY? prompt format will quit immediately leaving the disk intact. If you reply Y, there will be a pause (23 seconds on my CoCo), then format will prompt you for a name for the disk. The prompt will look like:
DISK NAME: At this point enter the name you have assigned to the disk. The name can be up to 32 characters long and may include blanks. Follow the disk name with an ENTER. Format will now check the disk. As it checks each track on the disk it will write the track number to the screen in hexadecimal (base 16). If you have a thirty five track drive, the numbers will be from 000 to 022. Then format will print the message:
NUMBER OF GOOD SECTORS: $000276 If the number is smaller than 276 (a base 16 number which is 630 in decimal) some sectors were faulty.

If you want to demonstrate to yourself that format did something to the disk try the FREE command on the new disk. Enter the command FREE /D1. The command line should look like:

OS9:FREE /D1 The response should be something
like:
    disk name CREATED ON 84/01/24
    CAPACITY: 630 SECTORS (1-SECTOR
    CLUSTERS)
    620 FREE SECTORS, LARGEST BLOCK
    620 SECTORS Where "disk name" in the first line
of the response will be the name you gave the disk
when you formatted it.

Backup

The next command to use after the format command is
BACKUP. It is crucial to have a backup copy of each
software distribution disk you have. If you make an
error that damages the only disk with an important
piece of software on it you will have to wait until
you can get a replacement for the disk before you
can use your computer again. Even if the time
wasted waiting for the replacement disk isn't
important to you, consider that replacement disks
cost money.

    Backup is a relatively fast way to create an
exact copy of a disk. It has lots of options, but
the simplest way to use the command is to just give
the command BACKUP. The command line should look
like:
    OS9:BACKUP The response will be:
    READY TO BACKUP FROM /D0 TO /D1
    ?: At this point put the disk you want to copy
in /D0 and a formatted disk which has nothing you
want to keep on it in drive /D1. Then check the
disk in /D1 ... BACKUP will erase anything that's
on that disk. When you are certain everything is OK
type Y. Now BACKUP will double check with you by
telling you the name of the disk in drive /D1. The
message will look like:
    THE DISK
    IS BEING SCRATCHED
    OK ?: if you reply Y to this, the backup from
the disk in /D0 to the disk in /D1 will take place.
The disk in /D1 will become an exact copy of the
disk in /D0 right down to the disk's name.

    The BACKUP command takes what seems like a long
time to run. There are two things that can speed it
up. One is to use the -V option which prevents the
copy from being verified. I don't suggest that
anyone use this option. The other way to speed
BACKUP up is to instruct OS-9 to give it extra
memory to run in. BACKUP can use extra memory to
run more quickly. BACKUP ran for one minute 58
seconds when I started it with the command line:
    OS9:BACKUP Normally BACKUP uses 19 pages of
memory. If you give it more -- say 100 pages --
with the command line:
    OS9:BACKUP 100 it runs in one minute 48
seconds. It is also quieter because the heads on
the disks don't load and unload as often.

Dir

The command which tells you what files are one your
disks is the the Dir (short for directory) command.
If you just type DIR after booting OS-9 you will
get a response like
    DIRECTORY OF . 23:55:08
    OS9BOOT CMDS SYS
    DEFS STARTUP This means that you are
listing the current directory which is known by the
pseudonym "." at 11:55:08 in the evening. The files
in that directory are OS9BOOT, CMDS, SYS, DEFS, and
STARTUP. Now, in fact only OS9BOOT and STARTUP are
normal files, the other three files are
subdirectories. Subdirectories are such an
interesting topic that they were the subject of
their own column some months ago, and won't be
covered any more than absolutely necessary here. To
find out more about the files than their names use

the command DIR E.
    OS9:DIR E which will respond:
     DIRECTORY OF . 23:59:57

CREATED ON	OWNER	NAME		
ATTR	START	SIZE		
==========================				
83/06/02 1921	0	OS9BOOT		
-----WR	A		3032	
83/06/02 1956	0	CMDS		
D-EWREWR	3C		6A0	
83/06/02 2002	0	SYS		
D-EWREWR	164		A0	
83/06/02 2002	0	DEFS		
D-EWREWR	17F		C0	
83/06/02 2003	0	STARTUP		
----R-WR	1F5			E then it will stop

because the screen is full. When you are ready to
continue hit any key ... I usually press the space
bar.   That was the end of the directory, so all you
get after you let the output continue is a few blank
lines and a new OS9 prompt.

Two of the fields in the DIR E output are of no
special interest until you become an advanced OS-9
user: OWNER, and START. The first two fields for
each file are the date and time the file was
created. The date is in the usual YY/MM/DD format
and the time is in HHMM format with hours ranging
from 00 to 23. The attributes field contains
information about what the file can be used for.
The important thing right now is that files with a D
as the first character in the attribute field are
directories. Files with a dash as the first
character in their attribute field are normal files.

The other option which can be used with the DIR
command is X. The X option is a short hand way to
get the directory of the execution directory; that
is, the directory OS-9 searches for programs, like
the commands, you ask it to run. The command line:
    DIR X will give you a rather long list of all
the files in your execution directory. If you
haven't written any of your own programs, this will
be a list of all the commands and utility programs
which came with OS-9. You will probably have to
press the space bar in the middle of the output of
this command. It is more than one page long.

Chx and Chd

Chx stands for Change Execution Directory, Chd for
Change Data Directory. OS-9 expects to find all
commands, whether they are part of the operating
system or something you wrote, in the execution
directory. All files that you don't mean to execute
are looked for in the data directory. (There are
ways around both of these restrictions, but let's
skip that for now.) After you boot OS-9 you will
find that the execution directory is /D0/CMDS and
the data directory is /D0. If you have a second
drive (I have been assuming that you do) you will
probably want to use that for data. The command:
    CHD /D1 will cause all future references to
data files to look for them on /D1.

To speed OS-9 up, the location of the directory
file on the disk is kept in memory. This leads to
the important side effect of the Chd and Chx
commands. When you read the directory OS-9 goes
directly to the directory's location on disk and
starts reading ... imagine what would happen if you
fooled OS-9 by changing disks. You change disks and
type a command like
    LIST FOO or even just DIR. Your operating
system will start reading where the directory is
supposed to be. Since the disk with a directory at
the selected spot is sitting in its envelope and
some other disk is in the drive, OS-9 will find

something unexpected where the directory was. The
result could be any of a number of error messages.
The solution to this problem is to always give OS-9
a chance to locate the directories on a new disk by
giving it Chd and Chx commands as necessary when you
change disks.

There is one last tricky thing about the
Chx/Chd commands' special use. If you keep things
very simple it will seem that you only need to use
the Chx command, but this is just a special case. I
suggest that you learn how to make directories and
use them as soon as you can, but, until you start
using them, the new disks you use to store data will
only have the directory FORMAT automatically creates
(called the "root directory"). The root directory
is always at the same location on a disk. Because
of this special fact about the root directory OS-9
is always able to find it, and changing disks that
only have the root directory on them won't cause any
trouble. The execution directory is usually not the
root directory, so this special case doesn't
generally apply to it.

The set of commands I have mentioned in this
column might be considered a "starter set" for OS-9.
The dozens of commands I left out are certainly
worth learning, but you can get OS-9 working with
these few.

Oops

I neglected to mention a few months ago that OFlex
as reviewed in this column is available only from
Gimix. Richard Don, the salesman for Gimix,
explained the geneology of OFlex to me. It is Flex
by TSC adapted by Richard Hogg to run under OS-9.
Gimix provides enhanced disk Device Drivers to
support Flex's requirements, and made some
enhancements to Richard Hogg's design. Anyone who
takes out licenses from TSC and Richard Hogg can
sell OFlex, but the version I reviewed has features
added by Gimix.

"C" User Notes

Edgar M. (Bud) Pass, Ph.D.
1454 Latta Lane
Conyers, GA 30207

INTRODUCTION

This month's column discusses the new Tandy C
compiler for COCO OS/9 and provides an example of
the use of the C language in interfacing with
interrupt-driven devices: in particular, the COCO
printer port.

TANDY C COMPILER

Tandy has recently begun marketing the Microware
(McCosh) C compiler for the COCO for $99.00. This
is in sharp contrast to the Microware cost of
$250.00 for essentially the same product. It
includes its own relocating macro assembler, for
which Microware asks $125.00, if purchased
separately from the C compiler.

For a COCO OS/9 user, the situation is excellent, in
that Tandy has made a full C compiler available for
$99.00, along with reasonably good documentation,
which is a typeset version of the Microware C
manual. Even the relocating macro assembler itself
may be worth the $99.00.

For non-COCO OS/9 users, the situation is not quite so clear. Although the price is very good, there are several non-monetary disincentives to the use of the Tandy C.

One obstacle which must be cleared is the COCO OS/9 format of the Tandy C diskette. There are several means of solving this problem. If a COCO is available, the D. P. Johnson SDISK software may be used to copy it to a standard OS/9 mini-floppy format. If no COCO is available, but a GIMIX system with mini-floppies is available, the GIMIX COCO driver may be used to read the diskettes. If mini-floppy diskettes are not acceptable, the files may be transmitted with one of the available modem programs from one system to another.

A small problem with the Tandy C package concerns the fact that it does not include the K & R C book, while the Microware C package contains it. The highest price noted for this book is $19.95, from Microware.

Another disadvantage with the Tandy C for OS/9 Level 2 users is that only the version of C for OS/9 Level 1 is included, whereas the Microware C provides versions of C for both OS/9 Level 1 and OS/9 Level 2. There may be subtle differences in the versions of the compilers for the two levels of OS/9, but I am aware of no differences aside from the obvious one of two passes for the OS/9 Level 1 version.

For new users, the Tandy C compiler is supported by Tandy service and the Microware C compiler is supported by the Microware hot-line. Both services are free for the first ninety days, and available for a fee subsequently. The Microware support costs $150.00 per year for all products.

Following is a table representing the combined alphabetized directories of each of the C compiler release diskettes.

Microware/McCosh	Tandy
cmds.common/c.asm	cmds/c.asm
cmds.common/c.link	cmds/c.link
cmds.common/c.opt	cmds/c.opt
cmds.common/c.prep	cmds/c.prep
cmds.II/c.com	
cmds.II/c.pass1	cmds/c.pass1
cmds.II/c.pass2	cmds/c.pass2
cmds.II/ccl	cmds/ccl
cmds.III/c.comp	
cmds.III/cc2	
defs/ctype.h	defs/ctype.h
defs/direct.h	defs/direct.h
defs/errno.h	defs/errno.h
defs/modes.h	defs/modes.h
defs/module.h	defs/module.h
defs/os9.h	defs/os9.h
defs/os9defs.a	defs/os9defs.a
defs/setjmp.h	defs/setjmp.h
defs/sgstat.h	defs/sgstat.h
defs/signal.h	defs/signal.h
defs/stdio.h	defs/stdio.h
defs/time.h	defs/time.h
lib/clib.l	lib/clib.l
lib/cstart.r	lib/cstart.r
sources/line.c	sources/line.c
sources/prof.c	sources/prof.c
sources/rdump.c	sources/rdump.c
sources/sys/abort.a	sources/sys/abort.a
sources/sys/access.a	sources/sys/access.a
sources/sys/ccdevice.a	
sources/sys/cfinish.a	sources/sys/cfinish.a
sources/sys/change.a	sources/sys/change.a
sources/sys/comp.sys	sources/sys/comp.sys
sources/sys/cstart.a	sources/sys/cstart.a
sources/sys/dir.a	sources/sys/dir.a
sources/sys/id.a	sources/sys/id.a
sources/sys/intercept.a	sources/sys/intercept.a
sources/sys/io.a	sources/sys/io.a
sources/sys/make.sys	sources/sys/make.sys
sources/sys/mem.a	sources/sys/mem.a
sources/sys/misc.a	sources/sys/misc.a
sources/sys/mod.a	sources/sys/mod.a
sources/sys/process.a	sources/sys/process.a
sources/sys/profdummy.a	sources/sys/profdummy.a
sources/sys/signal.a	sources/sys/signal.a
sources/sys/stat.a	sources/sys/stat.a
sources/sys/syscall.a	sources/sys/syscall.a
sources/sys/syscommon.a	sources/sys/syscommon.a
sources/sys/tidyup.a	sources/sys/tidyup.a
sources/sys/time.a	sources/sys/time.a

The only differences between the versions, in terms of the file structures of the release diskettes, involve the organization of the compilers and the file "sources/sys/ccdevice.a". As far as could be determined, the contents of the corresponding non-executable files on the release diskettes are identical. The "ccdevice.a" file provides a simple means of changing the assumed device containing the DEFS and LIB files. Since this is assumed not to be a problem with COCO OS/9, it is not provided on the diskette. However, the device strings in the compiler and preprocessor could be found and patched if this were a problem in a particular environment.

The objection to the use of the Tandy version of C on non-Tandy systems may present a problem to copyright purists. Copyright lawyers disagree on such usage, but most do not envision a conflict with the existing copyright laws, assuming the product is not used for resale. The standard Tandy copyright notice in the manual does not prohibit the use of the software on a non-Tandy system, and allows the making of backup copies for the customer's use.

Hopefully, this discussion has clarified, not obscured, the issue of the use of Tandy C on non-COCO systems.

INTERFACING C PROGRAMS WITH INTERRUPT-DRIVEN DEVICES

Recently, I had been attempting to get a modem program working properly under COCO OS/9, using the internal printer port. The program is written in C and was already working on several non-COCO 6809-based computers.

The primary problems involved the original RS232 driver module, which had several serious errors, including the lack of a status function and its inability to process characters properly at any rate over 300 Baud. After procuring a replacement module from Dale Puckett and rewriting it to correct the status function and other problems, its performance continued to be unacceptable.

The primary problem with the original and revised RS232 modules concerns the bit-banging nature of the printer port when used for input. The original module polls for characters on each interrupt and has no input or output character queues. The revised module uses the FIRQ interrupt to signal the beginning of an input character, and places the characters into an input queue, but normally receives characters properly only until its queue is full.

With either module, to ensure proper timing, interrupts must be masked during the reception or transmission of characters from or to the printer port. The input routine waits until half of the first bit time has elapsed, then checks the status of the line for each bit time to determine which bit pattern is on the input line. The output routine

places the appropriate signal on the output line for the time corresponding to each bit time. In order to construct the ASCII character code, with transmission envelope of one start bit and one stop bit.

All other processing on the COCO is restricted to the time between character reception or transmission. If characters are being received or transmitted continuously, the time between characters is only about ten percent of the available time for processing. The overhead involved with OS/9 uses up most of this small amount, leaving the program an insufficient amount of time to process input data, even if only stuffing the characters into memory, and the queue overflows if enough characters are received to fill it.

I decided to change the concept of the character collection process to that of an interrupt-driven handler depositing the incoming characters into a large (possibly circular) buffer, from which the C program could draw the characters. This helps reduce the OS/9 overhead and postpones the queue-full situation until the circular buffer overflows, which may not occur if the user is careful in what the COCO is requested to receive.

The real point of the inclusion of the C functions described below is not to demonstrate how to use the printer port on the COCO, but to provide a concrete example of the use of C programs with interrupt drivers. Many other situations will be similar to this one, and will often be more complex, especially in the area of output.

The COCO printer connector must be wired as follows:
  pins 1 and 2   received data
  pin 3   ground
  pin 4   transmitted data
In order to allow a FIRQ interrupt to be generated at the beginning of each character.

The output characters are written directly to the port, since there is no interrupt to indicate that the port is ready for output, as in the ACIA and other chips more suited for serial output. Characters are transmitted and received as eight-bit bytes with no parity.

The C program controls the processing of the input and output characters thru a group of functions, the logic of which is implemented thru assembler-language text. They are as follows:

    xinitpia   sets up pia and firq
    xtermpia   resets pia and firq
    xresbuf   resets buffer pointers
    xmaskpia   disables firq
    xunmkpia   enables firq
    xoutpia   transmits one character

Xinitpia establishes the boundaries of the large buffer, the addresses of the head and tail queue pointers, the address of the overflow flag, the circularity state of the buffer, and the baud rate delay factor. It establishes the firq vector, but disables the firq interrupt itself. It calls xresbuf to reset the queue pointers and overflow flag.

Xtermpia restores the original firq vector and disables the firq interrupt.

Xresbuf resets the head and tail queue pointers to the beginning of the buffer, sets the circularity state of the buffer, and resets the overflow flag.

Xmaskpia disables the firq interrupt.

Xunmkpia enables the firq interrupt.

Xoutpia transmits a character at the specified baud rate.

Although it may bother OS/9 purists, the functions share a work area into which they store data on a pc-relative basis. This could have not easily been avoided, because of the interrupt-driven nature of the code. However, the COCO has only one printer port, and thus it can logically have only one owner active at any point in time, so sharable code is not a problem.

There are a few rules the C driver program must obey. The primary one is that it may not arbitrarily manipulate the queue head and tail pointers. In particular, it should not directly modify the head pointer and should advance the tail pointer by one and only after removing each character from the buffer. If the buffer is circular, the tail pointer must be reset to the beginning of the buffer when it overflows the end of the buffer. The overflow flag is actually a counter of the number of characters which could not be placed into the buffer; it may be zeroed after interrogation.

The COCO must not be requested by any user, not only the printer port user, to perform operations (such as disk I/O) which would cause interrupts to be masked during periods of character reception, or input characters may be lost. Since OS/9 itself periodically masks interrupts to perform such operations such as timer service routines, the exact time delay between the start of the character and the start of the firq handling routine will vary slightly. This may cause an occasional garbled input character at higher baud rates.

The program must call xinitpia to establish the routine's necessary pointers, vectors, and flags. During periods when no characters are to be placed into the buffer, the xmaskpia function should be used. Conversely, when characters are to be allowed into the buffer, the xunmkpia function should be used. The xtermpia function must be used before the program terminates; it disables the firq interrupt and restores the firq vector.

The baud rate delay factor specifies the number of delay loops required to correctly receive or transmit characters on the printer port. The following table provides the suggested delay factors for certain standard baud rates:

    baud rate   delay factor
       110        $04cc
       300        $01bf
       600        $00de
      1200 $006d
      2400 $0036
      4800 $001b
      9600 $000e
     19200 $0007

Because baud rates may vary by as much as ten percent from device to device, some modification in the suggested values may be required in specific cases to reduce the error rate.

The functions just described are presented below, along with a simple main function which displays the characters input into the buffer from the printer port. In order to provide a termination point, the buffer is made non-circular and the program terminates when the buffer is full.

```c
main()
{
    char buff[1000];
    char *head,*tail;
    int over;
    xinitpia(&buff[0],&buff[999],&head,&tail,&over,0,0x6el);
    xunmkpia();
    while (tail<=&buff[999])
    {
        while (head==tail);
        putchar (*tail++);
    }
    xtermpia();
}


xinitpia (buff,bufe,head,tail,over,circ,baud)
char *buff,*bufe,*head,*tail,*over;
int circ,baud;
{
#asm
*****************
* initpia (&buff,&bufe,&head,&tail,&over,circ,baud)
*    initialize pia and start processing
*
initpia pshs cc,dp,x
 orcc #$50 mask interrupts
 ldx #$ff20 point to pia
 clr $01,x data direction
 lda #$fe set rs-232 lines
 sta ,x mostly output
 lda #$36 set data register
 sta $01,x
 lda #(parlas-parfir) initialize internal storage
 leax $0a,s point to first parameter in stack
 leay parfir,pcr point to storage
initlp ldb ,x+ copy parameter list
 stb ,y+
 deca
 bne initlp
 ldd circ,pcr reset buffer pointers and flags
 pshs d,x,y,u
 lbsr resbuf
 puls d,x,y,u
 leax basicp,pcr set new firq vector
 ldy #frqos9 os/9 firq vector address
 ldd #$7ecd check for flex
 cmpd $cd00
 bne initos
 cmpd $cd03
 bne initos
 ldy #frqflx flex firq vector address
 ldb ,y flex firq jump
 stb oldjmp,pcr
 sta ,y+ jump
initos sty oldadr,pcr
 ldy ,y remember firq vector
 sty oldfrq,pcr
 stx [oldadr,pcr] replace firq vector
 puls cc,dp,x
 lbra overfirq
***************
```

```
* basicp
*    basic pia input driver
*
basicp pshs d,dp,x,y,u stack other registers
 leax worka,pcr build dp-register
 tfr x,d
 tfr a,dp
 ldd baud,pcr baud delay factor
 cmpd #$000b >9600 baud
 bhi basic1 wait for rest of start bit
 ldb #$08 get bit count
 pshs b hold it
 bra basic5 get the character
basic1 lsra divide delay factor in half
 rorb for start bit
 subd #$0005 overhead
basic2 subd #$0001
 bne basic2 time half bit
 ldb #$08 get bit count
 pshs b hold it
basic3 ldd baud,pcr baud delay factor
 subd #$0005 overhead
basic4 subd #$0001
 bne basic4 time full bit
basic5 ldb $ff22 get incoming bit
 lsrb hold bit in cc
 ror <worka build the character
 dec ,s decrease bit count
 bne basic3 done with character?
 puls b
 lda $ff20 clear pending interrupt
 lda <worka get character
 ldx [head,pcr] get head pointer
 sta ,x+ put character into buffer
 cmpx [tail,pcr] check tail pointer
 beq basic7
 cmpx bufe,pcr check for end of buffer
 bls basic6
 ldd [circ,pcr] check circular flag
 beq basic7
 ldx buff,pcr reset to start of buffer
basic6 stx [head,pcr] set new head pointer
 bra basic9
basic7 ldd [over,pcr] incr overflow flag
 addd #$0001
 beq basic9 ensure no rollover
 std [over,pcr]
basic9 puls d,dp,x,y,u restore other registers
 rti return to the original task
****************
* interrupt handler storage areas
*
parfir equ * first parameter
buff fdb $0000 address of start of buffer
bufe fdb $0000 address of end of buffer
head fdb $0000 address of head pointer
tail fdb $0000 address of tail pointer
over fdb $0000 address of overflow flag
circ fdb $0000 circular buffer flag
baud fdb $0000 baud rate delay factor
```

```
parlas equ * last parameter
oldadr fdb $0000 old firq address
oldjmp fcb $00 old firq jump
oldfrq fdb $0000 old firq vector
worka fcb $00 work area
frqos9 equ $0030 os/9 firq vector
frqflx equ $010f flex firq vector
overfirq equ *
@endasm
;
}


xtermpia ()
{
@asm
****************
* termpia ()
*    terminate pia processing
*
termpia pshs cc,x
 orcc #$50 mask interrupts
 bsr maskpia mask firq from pia
 ldd oldfrq,pcr restore firq vector
 ldx oldadr,pcr
 std ,x
 cmpx #(frqflx+1) check for flex
 bne termpix
 lda oldjmp,pcr restore jump
 sta -$01,x
termpix clra return zero
 clrb
 puls cc,x
@endasm
;
}


xresbuf (circ)
int circ;
{
@asm
****************
* resbuf (circ)
*    reset buffer pointers and flags
*
resbuf pshs cc
 orcc #$50 mask interrupts
 bsr maskpia mask firq from pia
 ldd buff,pcr
 std [head,pcr]
 std [tail,pcr]
 ldd $07,s
 std circ,pcr
 clra
 clrb
 std [over,pcr]
 puls cc
@endasm
;
}
```

```
xmaskpia ()
{
@asm
****************
* maskpia ()
*    disable firq from pia
*
maskpia pshs cc
 orcc #$50 mask interrupts
 lda #$34 disable firq from pia
 sta $ff21
 lda $ff20 clear pending interrupts
 clra return zero
 clrb
 puls cc
@endasm
;
}


xunmkpia ()
{
@asm
****************
* unmkpia ()
*    enable firq from pia
*
unmkpia pshs cc
 orcc #$50 mask interrupts
 lda #$35 enable firq from pia
 sta $ff21
 lda $ff20 clear pending interrupts
 clra return zero
 clrb
 puls cc
@endasm
;
}


xoutpia (chr)
char chr;
{
@asm
****************
* outpia (chr)
*    send one character to pia
*
outpia ldb #$09 number of bits to output
 pshs b,cc store bit count and interrupt flags
 clrb clear carry for start bit
 orcc #$50 mask interrupts
outpi1 ldb #$02 pia mask for 1 bit
 bcs outpi2 if carry set, write a 1 else write 0
 clrb pia mask for 0 bit
outpi2 stb $ff20 put the bit on the line
 ldd baud,pcr baud delay factor
 subd #$0006 overhead
outpi3 subd #$0001
 bne outpi3 time full bit
 lsr $09,s shift character for next bit
 dec $01,s count bits
```

```
bne outpil continue if more bits
ldb #$02 pia mask for 1 bit
stb $ff20 put stop bit on line
ldb $ff20 clear interrupts
puls cc,b
clra return zero
clrb
#endasm
;
}
```

SUMMARY

This month's column discussed the Tandy C compiler for COCO OS/9
and the use of a C program in driving the COCO printer port using
interrupts to indicate input operations in order to attempt to
receive the characters more accurately.

68000 USER NOTES

Philip Lucido
2320 Saratoga Drive
Sharpville, PA 16150

For this month's column, I have the results of the
prime number benchmark on my 68008. There are also
listings of the C and assembler programs used in the
test. I also will cover the various programs included in
the OS-9/68K package a little more deeply.

A Speed Test

What would a new computer be without someone
immediately testing its speed? To perform the test, I
used the prime number Sieve of Eratosthenes program,
which has appeared in Ron Anderson's column, as well as
in Byte magazine articles on benchmarking. The test
consisted of various versions of some C programs, as well
as two 68000 assembler programs. All were run on a
10 MHz 68008, and the C programs were also run on a
2 MHz 6809 for comparison. Microware's C compiler was
used with both the 6809 and the 68008. The programs
were run for 100 iterations, with the times in the table
adjusted for 10 iterations for comparison with the
previously published benchmarks.

The first C program is a direct copy of the program
found in the January 1983 Byte, page 284. I first ran
the program as written, with the scalar variables all
auto variables, that is, variables located on the local
stack. I then changed the variable declaration from
'int' to 'register int'. For the 6809, this caused the
variable 'i' to be kept in the U register. For the 68000,
though, this register declaration caused all of the
variables except 'iter' to be kept in registers D4 to D7.
I then wrote an assembler program which closely mimicked
the algorithm of the C program.

The first C and assembler programs refer to the
'flags' array using indexing. That is, references in C
are of the form 'flags[i]', and references in assembler
are of the form '0(a0,d0)' where A0 holds the address of
'flags[0]', and D0 holds the value of the variable 'i'.
While keeping with the same general algorithm, I wrote
improved versions of both programs, in which the array
is referenced using pointer variables, which hold the
address of the current entry. The C program was then
run with auto variables and register variables. For the
68000, all seven of the variables in this version were
kept in registers, using D4 to D7 and A2 to A4.

Note that, for the C versions using auto variables,
the 6809 was about as fast as the 68008. When register
variables were used, though, the 68008 really flew. In
fact, the C times, then, were not all that different from
the times for the assembler code. The speed of utilities
and the like written in C should prove to be quite good,
as long as the large register set in the 68000 is
properly utilized. I'm not sure what the times would be
for a true 16 bit 68000, but my guess would be about 60%
to 75% of the times for the 68008.

So what does the test show? In various tests of
6809 compilers, high level language versions generally
take about 10 seconds at 2 MHz, and my times are no

exception. When register variables are used on the
68008, though, the times are reduced to less than half
what they were. As far as assembler goes, the second,
pointer version of the program is a better comparison
for the 6809 assembler test in the August 1984 68MJ.
The 2 MHz time there was 3.3 seconds, while here it is
2.2 seconds.

There is another point that can be made here. To
get really good times for the 68008 using a high level
language, I needed to be able to keep variables in the
registers at all times. As far as I know, C is the only
commonly available language with this ability. Without it,
a 68008 would offer little significant improvement in
speed over a 6809. It seems, then, that as our
microprocessors evolve, the languages must do likewise.
I'm not suggesting that Pascal or the like should
allow register declarations. We do need to have
languages that do a much better job of optimizing the
object code that they produce, to take advantage of the
power inherent in the new crop of chips, though.

More on OS-9/68K

I'm getting this column out a little earlier than I
had planned, so I haven't recieved version 0.6 of OS-
9/68K yet. The remarks I have to make apply to version
0.5. I'll have more to say as the new versions come in.
In any case, these are all still preliminary releases.

First of all, most of the utilities that I recieved
with Level 2 OS-9/6809 are present with the 68000
version. Missing are display, echo, ident, verify, binex,
and exbin. I don't particularly need binex and exbin,
but the others come in handy. In fact, I wrote my own
display utility since I need it to configure my terminal in
the startup file. Hopefully, these should all be present
in later versions.

Most of the utilities run a little differently here.
The biggest difference has to do with the handling of
options in the command line. Now, all options must be
preceded with a minus sign. This may be the hardest
adjustment to make when moving from OS-9/6809. I keep
typing 'dir e' when I should type 'dir -e'. Most utilities
now allow an option of '-?', which causes a summary of the
command to be printed on the standard error output.

As I mentioned last month, the dir command has been
made more powerful, with the addition of wildcard
searching, as well as an option to output the files found
one per line, without any header information. Most
utilities which accept a number of filenames in the
command line also accept the option '-z', which allows the
list of files to come from a text file or the standard
input. Piping the results of a wildcard dir command into
one of these utilities gives the equivalent of the
powerful wildcard file specification found in Unix, which
comes in very handy when performing such jobs as
deleting all of a group of related files.

There are several new utilities included with the
package. The 'inlz' utility performs an I$Attach command
on memory modules. This command can be used to perform
the initialization of a device driver. I have used it to
start up a RAM disk drive which is part of OS-9/68K. By
running 'inlz r0', 32K of memory is set aside as a fast
disk drive, referred to as /r0.

A utility by the name of 'cfp', for Command File
Processor, provides a method for submitting procedure
files with limited parameter substitution. A text file is
created on disk, with an '*' in place of a filename. Cfp
will read this file, and substitute the filename supplied
on the command line for each occurence of the '*'. The
resulting commands are stored in a procedure file and
executed.

There is a 'debug' program, which is quite a bit more
powerful than the 6809 version. The main reason for
this is the ability of the 68000 to automatically trace a
program, one instruction at a time, as it is run. OS-
9/68K provides all the links required to use this, and
debug does a good job of it. Debug can disassemble a
portion of a program, and can also step through a
program, disassembling as it runs. This was available in
the 6809 with the Flex Debug, and was missed (by me at
least) under OS-9/6809.

There are two editors included with OS-9/68K. The
first is a line editor named 'edt'. Edt is useful with
small text files. It functions in much the same way as
the editor found in Basic09 (without the Basic language
syntax checking, of course). The other editor is a
screen editor, 'scred'. Scred combines a command mode,
for doing such jobs as global searches and changes, with
edit and insert modes, which operate with automatic
screen updating. In my release, scred required some
customizing before it could be run. The main part of
the program was in a relocatable file 'scred.r'. A C
source code file, 'sconfig.c', contained all of the
terminal-specific routines, and I had to modify it to
work with my equipment, and then compile and link the
result to get a working program. Unfortunately, this

requires the C compiler to work. Future versions may come with a number of pre-configured 'sconfig.r' files, requiring you to link in the one which applies to your own terminal. This would eliminate the need for the C compiler, which does not come as part of the OS-9/68K package.

The standard assembler which comes with OS-9/68K is a relocatable assembler, 'r68', which performs much like the 6809 assembler 'rma'. There is no absolute assembler like the 6809 'asm'. There is also a linker, 'l68', for converting relocatable code into executable modules. Read through the two assembler listings that were used in the primes benchmark to see an example of the source code accepted by r68. Notice that the second program is meant to be used in conjunction with the C library. The program calls the 'printf' routine to display some results at the completion of the run.

I did not recieve any manuals for r68 or l68. This was not much problem, but I did discover something having to do with the data area which is not immediately apparent. Look at the first assembly language program, which does not use the C library. The program starts by adding $8000 (32K) to register A6. In the 68000, indexing is within a 64K range, using a signed 16 bit value. That means that locations up to 32K forward or backwards of an address register's contents can be referenced. To address a full 64K in the data area, the address register must point 32K past the start of the data area. You might think that this is not required with my particular program, since the data area is well under 32K long. It turns out, though, that the linker assumes that a reference to a data area label is made with an address register that has been offset. The label 'flags -', for instance, is assigned a value of -32768 (-$8000) by the linker, instead of the expected value of 0. Since a module running under OS-9/68K starts up with A6 pointing to the start of the data area, I had to add 32K to A6 to address the correct location using data area labels. I did not need to perform the offsetting in the second program, since this is done within the 'cstart' routine which actually begins all programs produced with the C compiler.

I'm Out of Room!

There are some long listings with this column, so I better cut it short here. Look here next month for some thoughts on operating systems, and what I might like to see. I just bought a book, 'The Unix Programming Environment', which was written in part by Brian Kernighan, who co-wrote the standard book for the C language (he's the K of K&R). The book describes how to use the Unix system, and spends a lot of time on using the shell. Just a quick glance makes me wish that some of the shell capabilities were included in OS-9/68K, and since memory usage is of less concern with the 68000, I see no reason that they could not be implemented. Anyway, more on this next month.

Sieve benchmark timings - 10 iterations - in seconds

	C - auto	C - register	Assembler

Version 1 - flags[] referenced with indexing

6809	11.0	9.7	---
68008	9.7	4.8	3.5

Version 2 - flags[] referenced with pointers

6809	8.9	8.2	---
68008	9.4	3.0	2.2

```c
/* Eratosthenes Sieve Prime Number Program in C */

#define TRUE   1
#define FALSE  0
#define SIZE   8190
#define MAXLOOP 100

char flags[SIZE+1];

main()
{
    int i,prime,k,count,iter;

    printf("%d iterations.\n",MAXLOOP);
    for (iter = 1; iter <= MAXLOOP; iter++) {
```

```c
        count = 0;
        for (i = 0; i <= SIZE; i++)
            flags[i] = TRUE;
        for (i = 0; i <= SIZE; i++) {
            if (flags[i]) {
                prime = i + i + 3;
                for (k = i + prime; k <= SIZE; k += prime)
                    flags[k] = FALSE;
                count++;
            }
        }
    }
    printf("%d %d\n",prime,count);
}
```

```c
/* Eratosthenes Sieve Prime Number Program in C */
/* Version 2 - use pointers for flags array reference */

#define TRUE   1
#define FALSE  0
#define SIZE   8190
#define MAXLOOP 100

char flags[SIZE+1];

main()
{
    register int i,prime,count,iter;
    register char *flagsi, *flagsk, *flagsend;

    printf("%d iterations.\n",MAXLOOP);
    flagsend = flags + SIZE;
    for (iter = 1; iter <= MAXLOOP; iter++) {
        count = 0;
        for (flagsi = flags; flagsi <= flagsend; )
            *flagsi++ = TRUE;
        flagsi = flags;
        for (i = 0; i <= SIZE; i++) {
            if (*flagsi++) {
                prime = i + i + 3;
                for (flagsk = flagsi + prime - 1; flagsk <= flagsend;
                        flagsk += prime)
                    *flagsk = FALSE;
                count++;
            }
        }
    }
    printf("%d %d\n",prime,count);
}
```

```
                nam     sieve1
                ttl     primes          by sieve benchmark

* sieve
*
* benchmark, in 68000 assembler
* finds primes using sieve of Eratosthenes

                opt     m
                opt     f

                use     ../defs/osdefs

00000101 Type   set     (Prgrm<<8)+Objct
00000001 Revs   set     (ReEnt<<8)+1
00000001 Ed     set     1               edition
00000200 Stk    set     512             stack allocation

                psect   Sieve,Type,Revs,Ed,Stk,Entry

00001ffe size   equ     8190            flags array size - 1
00000064 maxiter equ    100             number of iterations

                vsect
00000000 flags  ds.b    size+1
00000000        ends

* Register usage - Variable names are from 'C' program
*   D0.w = i      - main index in flags array
*   D1.w = prime  - current prime number
*   D2.w = k      - cross-out index in flags array
*   D3.w = count  - count of primes found
```

```
*  D4.w = iter  - main iteration loop counter
*  A0.l = pointer to start of flags array

0000 ddfc Entry     adda.l   #$8000,a6   offset data space pointer
0006 41ee           lea      flags(a6),a0   point to flags array
000a 7863           moveq    #maxiter-1,d4
* count = 0
000c 4243 iterloop  clr      d3
* for (i = size; i >= 0; i--)
*    flags[i] = 1;
000e 303c           move     #size,d0
0012 11bc fillloop  move.b   #1,0(a0,d0.w)
0018 51c8           dbra     d0,fillloop
* for (i = 0; i <= size; i++)
001c 4240           clr      d0
001e 0c40 mainloop  cmpi     #size,d0
0022 6224           bhi.s    done
*    if (flags[i]) {
0024 4a30           tst.b    0(a0,d0.w)
0028 671a           beq.s    loopend
*       prime = i + i + 3;
002a 3200           move     d0,d1
002c d241           add      d1,d1
002e 5641           addq     #3,d1
*       for (k = i + prime; k <= size; k += prime)
*          flags[k] = 0;
0030 3400           move     d0,d2
0032 d441           add      d1,d2
0034 0c42 crossout  cmpi     #size,d2
0038 6208           bhi.s    cdone
003a 4230           clr.b    0(a0,d2.w)
003e d441           add      d1,d2
0040 60f2           bra.s    crossout
*    count++;
0042 5243 cdone     addq     #1,d3
0044 5240 loopend   addq     #1,d0   i++ in for loop
0046 60d6           bra.s    mainloop
*    }
0048 51cc done      dbra     d4,iterloop
004c 4281           clr.l    d1      no error
004e=4e40           os9      F$Exit  all finished!

00000052           ends

Errors: 00000
Memory used: 15k
Elapsed time: 9 second(s)

                   nam      sieve2
                   ttl      primes    by sieve benchmark

* sieve
*
* benchmark, in 68000 assembler
* finds primes using sieve of Eratosthenes
*
* 2nd version - attempt at some optimization
* written to use 'C' start module

                   opt      m
                   opt      f

                   psect    Sieve,0,0,0,0,0

0000lffe size      equ      8190      flags array size - 1
00000800 lsize     equ      size/4+1  array size in long words
00000064 maxiter   equ      100       number of iterations

                   vsect
00000000 flags     ds.l     lsize
00000000           ends

* Register usage - Variable names are from 'C' program
*
*  D0.w = i     - main index in flags array
*  D1.w = prime - current prime number
*  D3.w = count - count of primes found
*  D4.w = iter  - main iteration loop counter
*  D7.l = scratch for fill loop
*
```

```
*  A0.l = pointer to start of flags array
*  A1.l = pointer to flags[i]
*  A2.l = pointer to flags[k]
*  A3.l = pointer to flags[size]

0000 41ee main:     lea      flags(a6),a0   point to flags array
0004 47e8           lea      size(a0),a3    point to flags[size]
0009 7863           moveq    #maxiter-1,d4
000a 4243 iterloop  clr      d3      count = 0
000c 303c           move     #size,d0
0010 2e3c           move.l   #$01010101,d7
0016 2248           move.l   a0,a1
0018 22c7 fillloop  move.l   d7,(a1)+   set all flags[i] true
001a 51c8           dbra     d0,fillloop
001e 70ff           moveq    #-1,d0     start i at -1
0020 2248           move.l   a0,a1      start flags[i] pointer
0022 5240 mainlpl   addq     #1,d0      ++i
0024 4a19           tst.b    (a1)+      search for next prime
0026 6716           beq.s    mainlp2
0028 3200           move     d0,d1      found - prime = i + i + 3
002a d241           add      d1,d1
002c 5641           addq     #3,d1
002e 45f1           lea      -1(a1,d1.w),a2  point to flags[k=i+prime]
0032 6004           bra.s    crosslp2
0034 4212 crosslpl  clr.b    (a2)       clear out flag[k]
0036 d4c1           adda.w   d1,a2      k += prime
0038 b5cb crosslp2  cmpa.l   a3,a2
003a 63f8           bls.s    crosslpl
003c 5243           addq     #1,d3      count++
003e b3cb mainlp2   cmpa.l   a3,a1
0040 63e0           bls.s    mainlpl
0042 51cc           dbra     d4,iterloop
0046 2f03           move.l   d3,-(a7)   printf("%d primes\n",count);
004a 487a           pea      msg(pc)
004c=6100           bsr      printf
0050 504f           addq.l   #8,a7
0052 4e75           rts

0054 2564 msg       dc.b     "%d primes",13,0

00000060           ends

Errors: 00000
Memory used: 15k
Elapsed time: 7 second(s)
```

READING NON-FLEX BASED DISKS

CONTINUED FROM LAST MONTH

```
* Encountered a tab character. If outputting
* to a file, the tab must be converted to the
* proper spaces, depending on the current
* column.
*
C463 34  04          PSHS  B      save current column ctr
C46A C4  07          ANDB  #%00000111  B = mod(curcol,8)
C46C 86  08          LDA   #8
C46E 34  04          PSHS  B
C470 A0  E0          SUBA  0,S+   A = 8 - mod(curcol,8)
C472 34  02          PSHS  A      save this value too
C474 1F  89          TFR   A,B    B = #spaces to insert

C476 86  20          LDA   #SP
        C478 PB5     EQU   *
C478 BD  CD18        JSR   PUTCHR  output a space
C47B 5A              DECB          until all done
C47C 26  FA          BNE   PB5

C47E 35  04          PULS  B      set back # spaces
C480 EB  E0          ADDB  0,S+   add to cur column ctr
C482 20  BB          BRA   PB1    and continue

        C484 PB4     EQU   *
C684 BD  CD1B        JSR   PUTCHR  output a char as is
C487 5C              INCB          incr col ctr
```

```
C438 20  85        BRA  PB1     continue
        C43A PB3   EQU  *
C43A 35  36        PULS A,B,X,Y  restore regs
C43C 39            RTS           and return
                *
                * Data area for PRTBLK (inited by COPYIT)
                *
C43D      EOFSEC   RMB  1
C43E      EOFOFF   RMB  1
C43F      EOBUF    RMB  2


                *
                * Name    - GETGRN
                * Function - This routine takes in a trk/sector
                *            value in D, and reads the granule
                *            starting at that position. A granule
                *            has GRANUL sectors with SSIZE bytes
                *            per sector.
                *
                *            On exit, acc D contains the next
                *            trk/sec after the granule just read.
                *
                *            All registers are preserved
                *
        C491 GETGRN EQU  *
C491 34  30        PSHS X,Y       save registers
C493 32  E9 FFFD   LEAS -L56,S    allocate local storage
C497 1F  01        TFR  D,X       save trk/sec to X
C499 C6  05        LDB  #GRANUL   # sectors per granule
C49B E7  E9 0000   STB  TMP1,S    save value
C49F 108E 0518     LDY  #BUFFER   where to put data
C4A3 1F  10        TFR  X,D       transfer trk/sec to D
        C4A5 GB1   EQU  *
C4A5 ED  E9 0001   STD  TMP3,S    save trk/sec
C4A9 8E  C840      LDX  #SVSFCB   set an FCB
C4AC 17  0027      LBSR READSS    and read the trk/sec
C4AF 1026 FCD0     LBNE ERRO2     leave if error
                *
                * Transfer bytes just read
                *
C4B3 30  88 40     LEAX FCB68,X   "from" field
C4B6 CC  0100      LDD  #SSIZE    len to move
C4B9 17  0024      LBSR MVC       move it
C4BC 31  A8        LEAY D,Y       incr buf addr
C4BE BC  E9 0001   LDD  TMP3,S    set current trk/sec
C4C2 5C            INCB           goto next sector
C4C3 C1  09        CMPB #MAXSEC   hit end of track?
C4C5 23  02        BLS  GB2       brnch if not
C4C7 4C            INCA           goto next track
C4C8 5F            CLRB           sector 0
        C4C9 GB2   EQU  *
C4C9 6A  E9 0000   DEC  TMP1,S    gotten all sectors?
C4CD 26  D6        BNE  GB1       brnch if not
C4CF 32  E9 0003   LEAS L56,S     free local storage
C4D3 35  30        PULS X,Y       restore regs
C4D5 39            RTS            and return
                *
                * Data area for GETGRN
                *
        C4D6 LPC   SET  *
0000               ORG  $0000
        0000 LCL   SET  *
0000      TMP1     RMB  1
0001      TMP3     RMB  2
        0003 L56   EQU  *-LCL     len of local storage
C4D6               ORG  LPC       restore PC


                *
                * Name    - READSS
                * Function - This routine reads in the track/sector of
                *            the disk in the drive specified by an FCB
                *            pointed to by X. Reg D specifies the
                *            track/sector to read in.


                *
                *   A BNE or BEQ should be used after calling
                *   this routine to check for possible read
                *   errors.
                *
                *   All registers except A are preserved.
                *
        C4D6 READSS EQU  *
C4D6 ED  88 1E     STD  FCBDCP,X  set trk/sec
C4D9 86  09        LDA  #RDSS     set function code
C4DB A7  84        STA  FCBFC,X   set code in FCB
C4DD 7E  0406      JMP  FMSCAL    read and return
                *
                * Name    - MVC
                * Function - This routine moves the "from" string
                *            to the "to" string as follows:
                *
                *            X -> "from" field
                *            Y -> "to" field
                *            D = # characters to move
                *
                *            Regs A,B,X,Y are preserved
                *
        C4E0 MVC   EQU  *
C4E0 34  36        PSHS A,B,X,Y   save regs
        C4E2 MOVE  EQU  *
C4E2 34  06        PSHS D         save len to move
C4E4 E6  80        LDB  0,X+      get a "from" char
C4E6 E7  A0        STB  0,Y+      trans to "to" field
C4E8 35  06        PULS D         get len
C4EA 83  0001      SUBD #1        decr br 1
C4ED 1083 0000     CMPD #0        done yet?
C4F1 26  EF        BNE  MOVE      brnch if not
C4F3 35  36        PULS A,B,X,Y   restore regs
C4F5 39            RTS            and return
                *
                * Name    - CLC
                * Function - This routine compares two strings
                *            as follows:
                *
                *            X -> string1
                *            Y -> string2
                *            A = length of strings to compare
                *
                *            String1 is compared to String2, and the
                *            appropriate condition code is set.
                *
                *            Regs A,B,X,Y are preserved.
                *
        C4F6 CLC   EQU  *
C4F6 34  36        PSHS A,B,X,Y   save regs
        C4F8 COMPR EQU  *
C4F8 E6  80        LDB  0,X+      get a string1 char
C4FA E1  A0        CMPB 0,Y+      compare to string2 char
C4FC 26  03        BNE  RPPROC    if neg then done
C4FE 4A            DECA           all through strings?
C4FF 26  F7        BNE  COMPR     brnch if not
        C501 RPPROC EQU  *
C501 35  36        PULS A,B,X,Y   restore regs
C503 39            RTS            and return
                *
                * Name    - PDATA
                * Function - This routine prints a string to an
                *            output device. On entry, X points
                *            to the string to print. As with the
                *            PSTRNG routine in FLEX, an EOT
                *            delimiter must appear after the
                *            string to print.
                *            Regs A and B will remain as is, and
```

```
                    *          I will be pointing to the EOT
                    *          delimiter char.
                    *
            C504 FDATA    EQU    *
C504 34  06              PSHS   A,B        save ress

            C506 PDATA1   EQU    *
C506 A6  80              LDA    0,X+       get char from string
C508 81  04              CMPA   #EOT       end of text?
C50A 27  05              BEQ    PDATA2     branch if yes
C50C BD  CD18            JSR    PUTCHR     print char
C50F 20  F5              BRA    PDATA1     and continue

            C511 PDATA2   EQU    *
C511 35  06              PULS   A,B        restore ress
C513 39                  RTS               and return


            *  Name     - ROUTE
            *  Function - This routine determines where the user
            *             wants his output to be routed. The user
            *             has three options:
            *
            *             RO=TERMINAL: In this case, no control
            *                info need be set, other than ensuring
            *                the output switch (OSWTCH) is non
            *                zero so FLEX will use the OUTCH2
            *                routine to print characters.
            *
            *             RO=PRINTER: In this case, the printer
            *                module routine must be loaded into
            *                memory if it is not already there,
            *                and the output switch must be cleared
            *                so FLEX will use OUTCH to process
            *                the characters
            *
            *             RO=FILE: In this case, the user is
            *                prompted for a file to which all
            *                output will be routed. FLEX's PUTCHR
            *                routine automatically routes outputted
            *                chars to the file's FCB if told
            *                to do so.
            *
            *             All registers are preserved
            *
            C514 ROUTE    EQU    *
C514 34  36              PSHS   A,B,X,Y    save ress

C516 9E  0000            LDX    #0         clear file output address
C519 BF  CC24            STX    FOA        in FLEX

C51C 8E  C273            LDX    #OUTFIL    prompt user for route
C51F BD  CD1E            JSR    PSTRNG
C522 BD  CD09            JSR    INCH       get response
C525 84  5F              ANDA   #$5F       lowercase->uppercase

C527 81  50              CMPA   #'P        printer?
C529 27  6F              BEQ    R2         branch if so

C52B 81  54              CMPA   #'T        terminal?
C52D 27  72              BEQ    R3         branch if so

C52F 81  00              CMPA   #CR        CR? (same as terminal)
C531 27  6E              BEQ    R3         if so brnch

C533 81  46              CMPA   #'F        file?
C535 26  71              BNE    R6         leave if not

            *
            * output to a file
            *
C537 8E  0257            LDX    #TOFILE    ask for "to" filename
C53A BD  CD1E            JSR    PSTRNG
C53D BD  CD1B            JSR    INBUF      get response
C540 8E  0306            LDX    #FILFCB    "to" FCB
C543 BD  C020            JSR    GETFIL     validate filename
C546 24  08              BCC    R4         check if file exists

C548 8E  0281            LDX    #INVSPC    invalid filename entered
```

```
C54B BD  CD1E            JSR    PSTRNG
C54E 20  58              BRA    R6         return

            C550 R4       EQU    *
C550 86  08              LDA    #OUT       set extension up
C552 BD  CD33            JSR    SETEXT
            *
            * Open the file
            *
C555 86  02              LDA    #XOWRIT    open for write
C557 A7  84              STA    FCBFC,X    save in FCB
C559 BD  D406            JSR    FMSCAL     call FMS
C55C 27  08              BEQ    R7         continue if file not there
            *
            * File already exists -> say so and return
            *
C55E 8E  029D            LDX    #FXIST
C561 BD  CD1E            JSR    PSTRNG
C564 20  42              BRA    R6         return

            C566 R7       EQU    *
C566 8E  02B8            LDX    #FTYPE     ask for file type
C569 BD  CD1E            JSR    PSTRNG
C56C BD  CD09            JSR    INCH       get response
C56F 84  5F              ANDA   #$5F       lowercase->uppercase

C571 5F                  CLRB
C572 81  54              CMPA   #'T        text?
C574 27  11              BEQ    R8         brnch if so

C576 81  00              CMPA   #CR        CR? (same as text)
C578 27  0D              BEQ    R8         brnch if so

C57A 81  42              CMPA   #'B        binary?
C57C 26  2A              BNE    R6         bad leave if not

C57E C6  A0              LDB    #OPN+BINRV set open-bin bits
C580 86  FF              LDA    #SCFWSC    type=binary
C582 B7  0411            STA    FILFCB+FCBSCF set compress. flag
C585 20  02              BRA    R1

            C587 R8       EQU    *
C587 C6  C0              LDB    #OPN+TEX   set open-text bits
            C589 R1       EQU    *
C589 8E  0306            LDX    #FILFCB    set all o/p to file
C58C BF  CC24            STX    FOA
C58F 7F  CC22            CLR    OSWTCH     o/p to the file
C592 F7  0519            STB    OPNFLG     save flag bits
C595 7F  CC04            CLR    WIDTH      zero TTY width value
C598 20  0A              BRA    R9         return

            C59A R2       EQU    *
            *
            * perform setup for output to printer
            *
C59A 7F  CC22            CLR    OSWTCH     o/p to aux. device
C59D 8D  0E              BSR    PRTSET     fetch printer module
C59F 20  03              BRA    R9         and return

            C5A1 R3       EQU    *
            *
            * perform setup for output to terminal
            *
C5A1 7C  CC22            INC    OSWTCH

            C5A4 R9       EQU    *
C5A4 1C  FE              CLC               set good RC
C5A6 20  02              BRA    R10        and leave

            C5A8 R6       EQU    *
C5A8 1A  01              SBC               set bad RC
            C5AA R10      EQU    *
C5AA 35  36              PULS   A,B,X,Y    restore ress
C5AC 39                  RTS               and return


            *  Name     - PRTSET
            *  Function - This routine is called to load the
            *             printer module if necessary.
            *
```

```
                    *       and init the PIA, so that output can
                    *       be routed to the printer.
                    *
                    *       No registers are preserved
                    *
          C5A0 PRTSET EQU   *
C5A0 7F CC09        CLR     PAU        disable pause feature
C5A0 B6 CCE4        LDA     POUT       set 1st byte of space
C5A3 81 39          CMPA    #$39       is it "RTS"?
C5A5 26 29          BNE     P15        if not the loaded

                    *
                    * Load printer routine
                    *
C5A7 8E 02F4        LDX     #PSYS      move in print rtn name
C5AA 108E C844      LDY     #SYSFCB+FCBNAM into system FCB
C5AE CC 0008        LDD     #11
C5C1 17 FF1C        LBSR    MVC
C5C4 7F C843        CLR     SYSFCB+FCBDN check drive 0

C5C7 8E C840        LDX     #SYSFCB    point to system FCB
C5CA 86 01          LDA     #XOREAD    open for read
C5CC A7 84          STA     FCBFC,X
C5CE BD D406        JSR     FMSCAL     call FMS
C5D1 27 05          BEQ     P1         brnch if open ok

C5D3 BD CC3F        JSR     RPTERR     report error
C5D6 20 11          BRA     P2         and return

          C5D8 P1   EQU     *
C5D8 86 FF          LDA     #SCFNSC    set for binary read
C5DA A7 88 38       STA     FCBSCF,X
C5DD BD CD30        JSR     LOAD       load module

          C5E0 P15  EQU     *
C5E0 BD CCC0        JSR     PRINIT     go init port
C5E3 8E CCE4        LDX     #POUT      get o/p address
C5E6 BF CD10        STX     OUTCH+1    stuff in FLEX
          C5E9 P2   EQU     *
C5E9 39             RTS                return

                    *
                    * Name     - RESET
                    * Function - This routine is called to reset the
                    *            FLEX output switch and close any file
                    *            that might be open through the FILFCB
                    *            FCB.
                    *
          C5EA RESET EQU    *
C5EA 86 01          LDA     #1
C5EC B7 CC22        STA     OSWTCH     reset output switch
C5EF B7 CC09        STA     PAU        enable pause
C5F2 7D 0519        TST     OPNFLG     is a file open?
C5F5 27 15          BEQ     RSI        return if not

                    *
                    * Output was going to file, close it
                    *
C5F7 B6 051A        LDA     TTYWID     restore TTY width
C5FA B7 CC04        STA     WIDTH

C5FD 8E 0306        LDX     #FILFCB    set FCB
C600 86 04          LDA     #XCLOSE    close code
C602 A7 84          STA     FCBFC,X
C604 BD D406        JSR     FMSCAL     call FMS
C607 27 03          BEQ     RSI        if ok return

C609 BD CC3F        JSR     RPTERR     report error
          C60C RSI  EQU     *
C60C 7F 0519        CLR     OPNFLG     indicate no file open
C60F 39             RTS                and return

                    END     START

SYMBOL TABLE:

AOOBI  CC36  ASREAD 0001  ASMOUT 0002  BAC    0008  BADFIL 026C
BADIN  038A  BAK    0005  BAS    0003  BELL   0007  BIN    0000
BINRV  0020  BS     CC00  BSE    CC07  BSIZ5  0500  BUFFER 051B
BUFPNT CC14  CLASS  CC21  CLC    C4F6  CLN    CC1A  CLOCK  F700
```

```
CMD    0002  CMDFLG CC28  COC    CC29  COLDS  C000  COMPR  C4F8
COPVIT C2C8  CR     0000  CRLF   000A  CTR1   0002  CURC   CC18
DAT    0007  DDRV   DE00  DEL    CC01  DEPTH  CC03  DIR    0009
DIRBUG C516  DIRMSG 014C  DIRPTR 0000  DIRSIZ 0002  DIRTS  0005
DOCMD  C548  DOS    CC00  DP1    C305  DP2    C33D  DP3    C320
DP4    C321  DRV    0518  DRVPNT 01D2  EJECT  CC08  ENDCOP 01A4
ENDIR  0168  ENTADR 0000  ENV    CC20  EOBUF  C43F  EOFUFF C48E
EOFSEC C480  EOL    CC02  EOT    0004  ERR    C179  ERRO2  C173
ESC    CC0A  ESCRR  CC16  FACP   0010  FADP   0040  FARP   0020
FAMP   0080  FCBAS  0002  FCBASE D409  FCBCDA 003F  FCBDP  001E
FCBDRN 0020  FCBDUR 0408  FCBDI  0022  FCBDN  0003  FCBEDA 0013
FCBESB 0001  FCBFA  000F  FCBFC  0000  FCBFCD 0019  FCBFDB 0032
FCBFS  0015  FCBFSN 0017  FCBLEN 0140  FCBLP  001C  FCBNAM 0004
FCBNMB 0024  FCBRI  0023  FCBRSI 0010  FCBRS2 0018  FCBSB  0040
FCBSCF 0038  FCBSDR 0035  FCBSDA 0011  FCBVER D435  FCDDAY 001A
FCDMTH 0019  FCDYR  0018  FDE    0000  FDEAPN 0012  FDEEN  0000
FDEFIF 0000  FDEFN  0005  FDEIGN 0001  FDELEN 0020  FDELRL 0004
FDEMD  001E  FDEOFH 0015  FDEOFL 0003  FDEOFN 0014  FDERSV 0002
FDEUPN 0010  FDEXEL 0016  FIA    CC26  FIEF   CC2F  FIFINV 0008
FIFPOE 0080  FIFREE 0010  FIFSYS 0040  FILFCB 0306  FINDIR C220
FLEX   CD00  FMS    D400  FMSCLS 0403  FMSCAL 0406  FMSERR CC20
FMSINT D400  FOA    CC24  FOUND  C403  FSIZ   0000  FSMRAM 0002
FSMSEQ 0000  FTYPE  0288  FXIST  0290  GB1    C4A5  GB2    C4C9
GET1   C353  GET2   C365  GET3   C367  GET4   C361  GETDRW C015
GETDRV C345  GETFIL C020  GETDRN C491  GETHEJ CD42  GE10   C3F4
GETSIZ C26E  GETKEP C2A3  GRANLL 0005  GS     CC82  GS2    C298
GT1    C384  GT2    C398  GT3    C3A1  GTBAD  C3A5  GTGOOD C3A7
GISPEC C36A  GIRETN C2C5  GIXIT  C2C4  HEAD   0100  INBUF  CD1B
INCH   CC09  INCH2  CD0C  INDBC  CD48  INDRV  0208  INFILE 01F4
INTRD  02FF  INVSPC 0281  IOFLG  CC21  ISWTCH CC23  JT     C138
LAO    CC1B  LCL    0000  LF     000A  LIBBUF C080  LOAD   CD30
LPC    C406  LS1    0007  LS2    0003  LS3    0014  LS5    0005
LS6    0003  LSTRN  CC11  M0     C143  M1     C148  M2     C155
M3     C160  MAP    CD00  MAXSEC 0009  MEMEND CC28  MEM2   C11C
MEMU   C119  MOVE   C402  MVC    C4E0  MX     C163  NULL   CC05
NXTCH  CD27  OPN    0080  OPNFLG 0519  OSWTCH CC22  OUT    0008
OUTADR CD45  OUTCH  CD0F  OUTCH2 CD12  OUTDEC CD39  OUTDRV 0167
OUTFIL 0223  OUTHED CC3C  OUTSIZ 0004  P1     C5D8  P15    C5E0
P2     C5E9  PAU    CC09  PB1    C43F  PB2    C41C  PB3    C48A
PB4    C484  PB5    C478  PB6    C430  PB7    C423  PB8    C438
PB9    C464  PCRLF  CD24  PD1    C102  PD3    C18C  PD4    C20F
PD5    C1E0  PD6    C1F7  PDATA  C504  PDATA1 C506  PDATA2 C511
PDIR   C17F  PDXIT  CC25  POUT   CCE4  PRCHK  CC0B  PREVC  CC19
PRINIT CCC0  PROM   C125  PRT    000A  PRTBLK C410  PRTSET C5A0
PRTTBL C247  PSTRNG CD1E  PSYS   02F4  PUTCHR CD18  PX1    C254
R1     C5B9  R10    C5AA  R2     C59A  R3     C5A1  R4     C550
R6     C5A8  R7     C566  R8     C5B7  R9     C5A4  RDERR  02E0
READSS C406  RENTER CD06  RESET  C5EA  RET    C409  ROUTE  C514
RPMOC  C501  RPTERR CC3F  RSTRID CD2A  RSI    C60C  SBDATA 0044
SBLNK  0040  SBRSI  0042  SCFNSC 00FF  SCFSC  0000  SCR    0006
SETEXT CD33  SETPAU C168  SFA    C980  SIRCRE 0023  SIRDAY 0024
SIRFSB 001D  SIRFSE 001F  SIRFSS 0021  SIRLEN 0028  SIRMTH 0023
SIRMTS 0026  SIRNAM 0010  SIRTS  0003  SIRVOL 0018  SIRYR  0025
SP     0020  SP4    01EF  SPS    C700  SRC1   C38C  SRC2   C303
SRCA   C5E7  SRCHR  C3AA  SRCXIT C3FF  SSIZ5  0100  START  C100
START1 C103  STAT   CD4E  STKA   C000  SVEFIL 0000  SVDR   CC0E
SYDRV  CC0B  SYS    0004  SYSCON CC4E  SYSCR1 CC00  SYSCR2 CC2A
SYSCR3 CC30  SYSCR4 CCF8  SYSFCB C840  TAB    CC06  TABCON 0009
TDSIZ  0002  TEMP   0002  TEX    0040  TFSIZ  0008  TMP1   0000
TMP3   0001  TMP4   0000  TMP5   0008  TMPXEL 000C  TMPTS  0003
TOFILE 0257  TRADDR CC1E  TRFLG  CC10  TTYWID 051A  TXT    0001
UCA    C100  UCTA   CC12  URAM   0000  WARPS  CD03  WELCOM 0129
WIDTH  CC04  WKDRV  CC0C  XBDR   0016  XCLOSE 0004  XDELET 000C
XDLDEC 00FE  XDLEND 00FF  XFND   0014  XGIR   0007  XGRB   0011
XNSS   000F  XOBIR  000A  XOREAD 0001  XOSIR  0010  XOUPUT 0003
XOWRIT 0002  XPIR   0008  XPOSN  0015  XPRB   0012  XREDMN 0000
XRES1  0008  XRES2  000E  XRES3  0013  XRELMD 0005  XRSS   0009
XRWMB  0000  XWSS   000A
```

SUPPORT YOUR ADVERTISERS

COMMUNICATING WITH OS/9

by Sidney Thompson
181 Greenbriar Court
Conyers, GA 30208
404-922-3097

and Bud Pass
1454 Latta Lane
Conyers, GA 30207
404-483-1717

INTRODUCTION

The following describes the application of OS/9 to the task of communicating (usually over modems and telephone lines) with other computer systems and with computer terminals.

Because telephone lines are inherently noisy, one of the major requirements which must be placed on communications hardware and software is error control and correction.

Because many computer systems and many terminals have unusual and different requirements, the communications software must be as flexible and as transparent as possible.

The program described below (named CMODEM) attempts to provide these facilities under OS/9, to allow communication with other systems, in a potentially error-free environment.

The program was written to overcome the many problems involved with trying to transfer data between not only various machines but between different operating systems on the same machine.

CMODEM FEATURES

CMODEM contains a combination of features found in the original BDS-C TeledIt program, a TTY program published in System 68, Yam (Yet Another Modem), and other features added for this version only ("I love it, but could you make it do ...? ").

It uses the Ward Christiansen MODEM file transfer protocol to facilitate the transfer of files between systems that support this protocol. Both MODEM and CMODEM support a checksum block verification that allows for error-free transfer of data between two computers supporting the same protocol.

For those systems that do not support a batch transfer protocol, CMODEM supports an ASCII file collection/dump mode for transfer of source files.

The use of multiple file transmission modes allows sending and receiving either binary or text files.

CMODEM will work at speeds of at least 1200 Baud for transfer of files at high rates of speed, for those systems with ACIA's or other asychronous communications support devices. It is used regularly at 4800 Baud between adjacent machines to transfer data between them. The COCO is capable of reliable transmission at rates of up to 2400 Baud, in general, and may (in some cases) be capable of transmission at rates of up to 4800 Baud or higher, when using the PIA printer port.

CMODEM is written in a high level language (C) and is available in both source and object formats to allow adaptation to other systems or for the addition of new options for specific requirements.

It uses the same source code for both the FLEX and OS/9 versions. This facilitates the transfer of files between FLEX and OS/9 systems, in addition to the ability of communicating with CP/M systems, as described above.

The FLEX version of CMODEM allows the user to change the modem port address at execution time, since there is no standard address for a modem, as there is (normally) for the console. The OS/9 version of CMODEM uses a standard OS/9 path descriptor name (by default, "/T1") to access the modem port; this is compatible with both OS/9 level 1 and OS/9 level 2. However, due to the overhead associated with COCO OS/9, a special version of CMODEM containing its own drivers is used for a COCO with a PIA printer/modem port.

Since it is inconvenient to modify system parameters upon each entry to the program, CMODEM supports the use of a parameter file (profile) which can be used to define the modem port address or name, baud rate of the modem port (for those operating systems and devices supporting variable modem port baud rate), the duplex status required (half or full), etc. This parameter file is described later in this discussion. It also allows the definition of an expert mode, which allows the use of CMODEM without the occasional display of the menu. This feature is useful when one has used CMODEM long enough that the menu has become completely memorized and it decreases the time required to transfer among the different operating modes.

The current FLEX version of CMODEM does direct I/O to the modem port and will not work with those systems not using ACIA's; however, a special version is available for COCO FLEX, just as a special version is available for COCO OS/9.

CMODEM OPERATIONS

CMODEM is menu-driven to make it as simple as possible to use. The menu is displayed upon entry into the program and also when the user strikes the defined ATTENTION key.

The selectable program modes are described below.

T: Terminal mode - no text collection

CMODEM simulates an ASCII terminal in this mode.

By default, eight-bit characters are sent and received without parity. The DEL character (7F hex) is the only character that will be removed from the conversational terminal mode input data stream. Most other characters are passed unchanged to the console, so formatting characters and nonsense noise characters are usually passed thru for the user's inspection.

To return to the selection menu, the user may hit the SPECIAL character. The current SPECIAL character of <ctrl>-@ (NULL) was chosen because it is unlikely to be struck accidentally, or to be required input to most systems. Changing the SPECIAL character requires recompiling CMODEM with the desired character code in the following statement:

#define SPECIAL ...

A BREAK key is also supported for those systems that require an actual break signal be placed on the line. This is set by default to <ctrl>-underline, but may be changed to any desired key. It must be emphasized that this key currently works only on a SWTPC-compatible

system using a 6850 ACIA under FLEX and for a
COCO system under FLEX or OS/9.

?: Toggle expert mode

This command flips expert mode, alternately
outputting and not outputting the menu to the
console. This saves time for those very
familiar with using the program.

G: Gather text in memory buffer

CMODEM processes text received in this mode
similar to that received in terminal mode,
except that any text characters received from
the communications link are saved into a text
buffer. Tab, carriage-return, line-feed, and
form-feed characters are placed into the
buffer; any other control characters are
discarded. The one exception to this is when an
end of line CR LF sequence is received, the
program only inserts the CR into the memory
buffer. This prevents the storage of
double-spaced text to the disk file which could
occur if both control characters are placed
into the data file. If the text buffer becomes
full, CMODEM will issue an X-OFF to the remote
system. The program then will continue to
capture data for a maximum of an additional 95
characters. This allows time for the remote
system to receive the X-OFF and to stop sending
data.

If the remote system at the other end of the
line does not honor the X-OFF, CMODEM will
flush the buffer to the disk storage file and
then return to accept more data from the
communications line. Data arriving during this
buffer-dumping process will almost certainly be
lost. In this case, since this loss is not
normally desirable, the amount of data
transmitted in each group should be limited to
less than the number of characters required to
fill the text buffer.

If, on the other hand, the remote system does
honor X-ON/X-OFF, no data will be lost while
CMODEM flushes the memory buffer to disk. Upon
resuming its data capture mode, CMODEM issues
an X-ON to restart the remote transmission.

There are some systems which either do not
recognize X-ON/X-OFF or require characters such
as the ESCape to do both the halt and resume
function. Using this option of CMODEM on these
systems will require either that the values
within the program for STOP and RESUME be
modified.

Since the standard printer port on a COCO works
in half-duplex mode only, transmitting the
X-OFF will garbage any characters being
received. The user must be aware of this fact
and request the retransmission of the garbaged
data or somehow arrange for the gather buffer
never to be overflowed.

V: View text buffer

This mode allows the viewing of the data which
currently is in the memory capture buffer.
This is helpful when one wishes to review a
long transmission from a remote system;
although this mode allows only paging forward,
the view process may be restarted at the
beginning, as required. On non-COCO systems,
the carriage return displays the next line, the
space bar displays the next page, and the
ATTENTION key returns the menu. On COCO
systems, the space bar toggles a pause and the

ATTENTION key returns the menu.

The memory capture buffer and the batch
transfer buffer share the same internal memory
area. This means that if one initiates a batch
file transfer, any data which may be in the
buffer will be destroyed during the process.

A: Enter ASCII file dump mode

CMODEM will transfer a text file over the
communications line. It can be used to send a
file to those systems that do not support the
MODEM protocol, but do support paper tape
capture. This mode honors the X-ON/X-OFF
protocol, so that the remote system may control
the flow of data during the process.

K: Kill text buffer

This command marks the text buffer as empty and
exits ASCII text capture mode. It is normally
used when the user has initiated capture mode,
but has captured unexpected data and does not
wish to save it on disk.

E: Toggle Echo (duplex) mode

This option determines whether characters input
from the console are echoed back to the display
screen locally or not.

    It should be toggled to "full" if the user is
    communicating in echoplex mode and is
    receiving an echo from the remote station.

    It should be toggled to "half" if the user is
    working with a system which does not echo to
    the sender or is in half duplex mode.

The current setting of this option is displayed
in the menu.

M: Modify program option parameters

The non-COCO, FLEX version of CMODEM is able to
modify several of the current program
parameters with this option. A submenu of
current options guides the entry of program
parameter changes. These include the following
parameters:
        port address for modem
        baud rate of the modem port
        parity settings of the modem port

B: Set Baud rate

The COCO versions of CMODEM are able to set the
Baud rate of the attached PIA printer/modem
port with this option. A submenu of available
Baud rates guides the entry of program
parameter changes. Although Baud rates higher
than 2400 Baud appear in the menu, they are not
reliable enough, in general, for normal usage.

D: Set Delay rate

The COCO versions of CMODEM are able to "tweak"
the Baud rate of the attached PIA printer/modem
port with this option. A submenu of available
Baud rates guides the entry of program
parameter changes. Although Baud rates higher
than 2400 Baud appear in the menu, they are not
reliable enough, in general, for normal usage.
Since the PIA printer/modem port is driven in
a bit-banging mode by software, it is not as
tolerant of Baud rate variations as a hardware
device such as an ACIA. This option allows the
variation of the standard delay values to
attempt to reduce communications errors.

S: Send a file with MODEM protocol

CMODEM prompts for the name of the file to send, then waits for the receiving computer (which must be using this program or one that uses the same protocol) to get into synchronization. The details of the protocol are provided later.

CMODEM returns to Terminal mode after completion of this option, whether the transfer was successful or not.

R: Receive a file with MODEM protocol

CMODEM prompts for the name of the file to receive, then waits for the sending computer (which must be using this program or one that uses the same protocol) to get into synchronization. The details of the protocol are provided later.

CMODEM returns to Terminal mode after completion of this option, whether the transfer was successful or not.

X: Binary file transfer with MODEM protocol

CMODEM prompts for the name of the file to send, then waits for the receiving computer (which must be using this program or one that uses the same protocol) to get into synchronization. The details of the protocol are provided later.

CMODEM returns to Terminal mode after completion of this option, whether the transfer was successful or not.

This option may be used to transfer compiled binary files from one system to another like system. It can also be used between FLEX systems to send files in space-compressed mode to save transmission time.

This file transfer does not involve character transliteration of the contents of the file being transmitted. There is no conversion of CR to NL, CR to CRNL, or CRNL to CR. This may cause unexpected results, depending upon the system from which a file is being received or to which it is being sent.

Y: Binary file receive with MODEM protocol

CMODEM prompts for the name of the file to receive, then waits for the sending computer (which must be using this program or one that uses the same protocol) to get into synchronization. The details of the protocol are provided later.

CMODEM returns to Terminal mode after completion of this option, whether the transfer was successful or not.

This option may be used to transfer compiled binary files from one system to another (like) system. It can also be used between FLEX systems to send files in space-compressed mode to save transmission time. This file transfer does not involve character transliteration of the contents of the file being received.

When this option is used under OS/9, the file must then be processed with ATTR to make the program executable at the receiving end, assuming an executable OS/9 module was transmitted successfully. This is true because the file attributes are associated with the

disk directory, and not with the contents of the file.

Q: Quit

For non-COCO, FLEX versions of CMODEM, this option resets the modem port, dropping the telephone line or other equipment using the RTS signal on an ACIA as a DTR indication. For all versions, it returns to the operating system.

O: Operating system return

For non-COCO FLEX versions of CMODEM, this option returns to the operating system without resetting the modem port. This can be used to return to the operating system to perform various functions without disturbing the equipment using the RTS signal on the ACIA as a DTR indication.

H: Hang up the phone line

This option is used to hang up the phone line by dropping the DTR(RTS) signal on the modem port, on FLEX versions of CMODEM using ACIA's. This is very useful for the auto-dial type modems in which the user may wish to hang up from one system but is not ready to exit from the program. The port is reset after approximately one second so that it is then available to call another remote system.

F: Flush data collection buffer to capture file

CMODEM flushes the text buffer to disk and resets the memory pointer to the beginning of the buffer. This would be used if it were desirable to capture several small files and concatenate them onto disk or to capture files longer than the available buffer size. The capture file is currently closed on exit from the program or upon receipt of a Close command, so that the buffer may be flushed multiple times to the same file.

C: Close text collection file

CMODEM flushes the memory buffer to the collection disk file and then closes the file. This allows the capture of multiple files without the necessity of exiting CMODEM.

L: Line feed generated locally for CR

While this may not be the most popular of all options, it proves to be very useful for those systems which send only a carriage return or do not echo anything after an end of line character is sent. This includes the COCO printer port and many other systems. This option allows the production of a local CR NL sequence to prevent repeatedly overwriting the same line with successive lines.

CMODEM PARAMETER FILE (PROFILE)

As described earlier, CMODEM supports a parameter file for the purpose of automatically modifying certain default parameters. For FLEX, this file is named PROFILE.TXT and must be placed on the working drive. For OS/9, this file is named PROFILE and must be placed in the current directory. The user is responsible for creating the parameter file according to the description below. If the file is not available or a parameter is not modified, the default parameter values will be used.

Each record in the parameter file contains a

keyword and an optional operand, and is terminated with a carriage return.

For non-COCO FLEX CMODEM, the parameter file has the following contents:

```
BAUD    300/1200  (1200)  baud rate
DUPLEX  F/H       (F)     duplex switch
MODEM   xxxx      (E074)  modem port address
UNITS   nn        (10)    disk buffers per I/O (1-25)
XPERT             (no)    expert mode toggle
```

For non-COCO OS/9 CMODEM, the parameter file has the following contents:

```
DUPLEX  F/H       (F)     duplex switch
PORT    /aaaa     (/T1)   modem path descriptor name
UNITS   nn        (10)    disk buffers per I/O (1-25)
XPERT             (no)    expert mode toggle
```

For COCO versions of CMODEM, the parameter file has the following contents:

```
BAUD     300/1200 (1200)  baud rate
CC110    xxxx     (04CC)  110 baud delay factor
CC300    xxxx     (018F)  300 baud delay factor
CC600    xxxx     (00DE)  600 baud delay factor
CC1200   xxxx     (006C)  1200 baud delay factor
CC2400   xxxx     (0033)  2400 baud delay factor
CC4800   xxxx     (0019)  4800 baud delay factor
CC9600   xxxx     (000E)  9600 baud delay factor
CC19200  xxxx     (0007)  19200 baud delay factor
DUPLEX   F/H      (F)     duplex switch
XPERT             (no)    expert mode toggle
```

COCO PIA MODEM PORT WIRING

The COCO version of CMODEM requires that the PIA modem port be wired as follows:

```
pins 1 and 2   received data
pin 3          ground
pin 4          transmitted data
```

Note that this is different from that used by Tandy and Microware.

CMODEM INSTALLATION

This section is of interest only to those who have purchased the source version of CMODEM.

The source version of CMODEM is composed of nine modules. This is because of the composite size of the various modules and the ability of some editors to work well only with files that can fit into main memory.

The CMODEM modules are as follows:

```
cmodem.c       option selections
cmodem.inc     common information
cmodterm.c     terminal emulation
cmodsend.c     modem file transfer
cmodrecv.c     modem file receive
cmodfile.c     file open, close, read, write
cmodxmit.c     ASCII file transmission
cmodsupt.c     utility functions
make.c         includes all header files and .asm modules
makefile       compilation command file
```

The "makefile" file provides a command file which will perform the entire compilation and assembly process on the CMODEM modules. The "makefile" modules are somewhat different among the various versions of the C compilers available under OS/9 and FLEX.

Since CMODEM was rewritten into Dyna-C, the Make.c file is used to include all of the required library files and the assembly language files that

are produced by the compiler (.asm). There are also some rewritten library files provided with CMODEM since the standard versions available with Dyna-C did not support all of the features required and did not comply with the standards normally found on UNIX-type machines.

While this may seem to be troublesome, it does make the source to CMODEM usable to more people since it does not require the purchase of one of the $400 C compilers currently available for the 6809. The new version of Microware C for the COCO was not available when this program was being developed.

While conversions have not been attempted, there is no reason that some of the other small C's could not also be used if the proper library functions were written for them. There are versions of CMODEM which have been developed for Microware C and Introl C in the past.

SYSTEM-DEPENDENT DEFINITIONS

This section is of interest only to those who have purchased the source version of CMODEM. It describes some of the "#define"s that are used in the source version of CMODEM. Some of these may require modification to suit the requirements of particular systems.

TWIDTH

This is the width of the terminal display in characters.

TLENGTH

This is the number of horizontal lines that can be displayed on the terminal.

MYMODEM

This is the default address of the ACIA port being used for the modem.

MYTERMINAL

This is the default address used for the console terminal.

LPSEC

This is an internal timing loop value used for time delay.

CPUMHZ

This is the default clock speed for the processor and is used as part of the timing loop formula.

SECSIZ

This is the size of each received or transmitted data sector. It is set to 128 bytes to be compatible with CP/M MODEM transfer protocols.

CAPSIZ

This is the total buffer capacity in bytes. It is the size of each sector times the number of sectors that will be sent or captured before a disk read or write.

SPECIAL

This is the control sequence that is recognized by the program from the console as a request to display the menu. It may be reset but has the default value <ctrl>~@.

BREAK

This is the control sequence that is recognized by the program from the console as a request to transmit a physical break condition. It may be reset but has the default value <ctrl>-underline.

BRKCODE

This is the value that will be sent to the modem ACIA port to initiate a break code on the line.

SYSDEPENO

Since the various C compilers available seem to return different codes for OPEN, this variable is defined as required for a given C compiler. It is defaulted to NULL for Dyna-C.

MODEM PROTOCOL DEFINITION

The following description of the Ward Christiansen MODEM protocol was derived from various sources, including the original MODEM description, the TELENET description, the TTY description, and a description on the NEWSNET by Keith Peterson, with additions for CMODEM.

This description provides the criteria for operation of the MODEM protocol if it is to be compatible with the various CP/M and UNIX systems in operation.

Using this protocol, CMODEM has been used to transfer files from OS/9-based, UNIFLEX-based, and FLEX-based systems to and from each other, to and from CP/M-based systems using MODEM, and to and from UNIX-based systems using TMODEM, UMODEM, and XMODEM. It has also been used to send and receive files from other assembly language MODEM programs, as well as programs written in C, that exist on the various C-Nodes across the country.

The control characters that define the MODEM data block are as follows:

    <soh>   01H

    <eot>   04H

    <ack>   06H

    <nak>   15H

    <can>   18H

TRANSMISSION-MEDIUM LEVEL PROTOCOL

Following are the attributes of the transmitted and received data:

    asynchronous

    8 data bits

    no parity

    one stop bit

This protocol does not place any restrictions on the contents of the data being transmitted. Any type of data can accurately be sent using this protocol. This includes the following types of files:

    ASCII text files

    binary compiled program files

    command files containing control characters

any other arbitrary files

While this protocol is designed for use with an 8-bit data format, it could easily be adapted for use in a 7-bit environment and used for the transmission of ASCII-only (or unpacked-hex) data. This could be done simply by having both the sender and receiver logically mask any protocol-dependent data to clear the eighth bit before transmitting and after receiving it. This would be limited to the variable-data portion of the transferred data, and would not include the following 8-bit protocol control data, described later:

    the checksum

    the block numbers

    the one's-complement of the block number

To maintain compatibility with the CP/M file structure, the data file must follow the following data format:

    ASCII tabs must be used (09H); tabs are assumed set every 8 positions;

    All lines must be terminated by CR/LF (0DH 0AH);

    End-of-file must be indicated by one or more <ctrl>-Z (1AH) characters;

    Data is variable length, but while the file is being handled by the transfer program, it should be considered a continuous stream of data bytes. This continuous stream is then broken into 128-byte chunks by the program for transmission and is regrouped upon reception.

    If the data ends exactly on a 128-byte boundary, i.e. CR in 127, and LF in 128, an additional block containing the <ctrl>-Z EOF character(s) is optional, but is preferred, as some CP/M utilities and user programs do not handle EOF without <ctrl>-Z correctly.

    The last block sent is identical to all the others; there is no "short block" supported by the MODEM protocol. Padding is added to the block to complete the required 128 byte block size on the last data block. While one would be tempted to pad this block with <ctrl>-Z, this will work reliably only with CP/M-based systems. Other systems, such as OS/9, UNIX, FLEX, and, UNIFLEX, would not usually process the <ctrl>-Z characters correctly. It is safer to use spaces for padding even though this could possibly add a slight length to the file, and potentially cause difficulties with binary transmissions to non-CP/M systems.

MESSAGE BLOCK-LEVEL PROTOCOL

The format of every data block transferred in either direction under the MODEM protocol is as follows:

    <SOH> <blk #> <255-blk #> <--128 data bytes--> <cksum>

    In which:

    <soh> = 01 hex;

    <blk #> = binary block number (starts at 01H, increments by 01H, and wraps around from 0FFH to 00H;

<255-blk #> = one's-complement of binary block number;

<cksum> = the last eight bits of the sum of the data bytes.

PROGRAM-LEVEL PROTOCOL

COMMON TO BOTH SENDER AND RECEIVER:

All errors are retried 10 times.

Some versions of the protocol (but not CMODEM) use <can> (18H), to cancel the transmission operation. This has never been adopted as a standard, since a single "abort" character makes the transmission susceptible to false termination caused by an <ack> <nak> or <soh> being corrupted into a <can> and cancelling transmission.

The protocol may be considered "receiver driven", that is, the sender need not automatically re-transmit, although it does in most of the current implementations, including CMODEM.

RECEIVING PROGRAM CONSIDERATIONS:

The receiver has a 10-second timeout.

It sends a <nak> each time it times out.

The receiver's first timeout, which sends a <nak>, signals the transmitter to start the transfer of data.

The receiver could send a <nak> immediately, in case the sender is ready. This would work if the sender were a version of XMODEM, which is a variant of MODEM which must be initiated remotely by the receiver.

This would save the initial 10 second timeout, and is used by CMODEM. However, the receiver must continue to timeout every 10 seconds in case the sender wasn't ready.

Once the receiver has begun receiving a block of data it will use a one-second timeout for each character and the checksum. If the receiver wishes to <nak> a block for any reason (invalid header, timeout receiving data), it must wait for the line to clear. See "programming considerations" for various techniques used by different modem programs for handling error conditions.

If a valid block number is received, it will be one of the following:

1) the expected one, in which case everything is fine;

2) a repeat of a previously received block; this should be considered OK, since it indicates that the receiver's <ack> was glitched, and the sender re-transmitted; the only special handling is to discard the received block of data;

3) any other block number will indicate a loss of synchronization, such as the sender getting a line-glitch that appeared as an <ack>; this condition normally is not recoverable, so the receiver normally aborts the transmission by sending a <can>.

SENDING PROGRAM CONSIDERATIONS

While waiting for the transmission to begin, the sender may have only a single long timeout, normally one minute in length, or it may have a shorter timeout, normally 10 seconds in length, before retrying the transmission, for some number (such as 10) of retries. Cmodem uses the latter method, as this aborts fewer transmissions. The use of this 10 second timeout makes the transmission time-sensitive, whereas the one long timeout allows the entire process to be completely receiver-driven. The 10 second timeout is compatible with any of the existing MODEM protocol programs.

When the sender has no more data, it will send an <eot>. It will then wait for an <ack>. The sender will resend the <eot> if an <ack> is not received, just as in normal transmission.

Another procedure, used by some MODEM protocol programs, although not by CMODEM, is to have the sender implement only a high-level one-minute timeout after sending the <eot> before aborting the transmission. This would give the receiving end more control of the data exchange procedure.

DATA FLOW EXAMPLE

To show an example of a data flow session, a 3-block message is diagrammed below. It includes the two most common line hits: a garbaged block, and an <ack> reply getting garbaged. <xx> represents the checksum byte.

```
SENDER                              RECEIVER
                           (times out after 10 seconds)
                    <---           <nak>
<soh> 01 FE -data- <xx>   --->
                    <---           <ack>
<soh> 02 FD -data- xx     ---> (data gets line hit)
                    <---           <nak>
<soh> 02 FD -data- xx     --->
                    <---           <ack>
<soh> 03 FC -data- xx     --->
(ack gets garbaged) <---           <ack>
<soh> 03 FC -data- xx     --->     <ack>
<eot>                     --->
                    <---           <ack>
```

PROGRAMMING CONSIDERATIONS

Following are suggestions published in various sources for potential MODEM-compatible program writers or modifiers. Most of them are included in the CMODEM program.

The character-receive subroutine should be called with a parameter that specifies the number of seconds to wait. The receiver should first call it with a time of 10, then <nak> and try again, 10 times.

After receiving the <soh>, the receiver should call the character receive subroutine with a 1-second timeout, for the remainder of the message and the <cksum>.

Since they are sent as a continuous stream, timing out of this implies a serious problem that may have been caused by the receipt of only 127 characters instead of 128.

When the receiver wishes to transmit a <nak>, it should call a "PURGE" subroutine, and wait for the line to clear. The sender should have discarded any characters in its internal

hardware and software receive buffers immediately upon sending a block, to help prevent misinterpretation of line glitches.

The most common technique is for "PURGE" to call the character receive subroutine, specifying a 1-second timeout, and looping back until a timeout actually occurs.

The receiver then sends the <nak>, hopefully ensuring that the transmitter will receive it properly.

Some may wish to add code to the character receive routine to set an error flag if the ACIA or other device on the modem port shows framing error or overrun. This code is not currently included in CMODEM.

This will help catch a few more glitches, the most common of which is a hit in the high bits of the byte in two consecutive bytes. The checksum is unaffected in this case, since counting in eight bits and discarding the carry bits produces the same results when adding (80H + 80H) as with adding (00H + 00H).

SUMMARY

The preceding has discussed the application of OS/9 to communicating with other systems and with other terminals. The method described, a program named CMODEM, implements several modes of communication (some of which are compatible with CP/M and other systems), which attempt to provide an error-free means of communication despite potentially-noisy telephone lines, and other modes of communications, which, while not error-free, are compatible with other systems and terminals.

POSTSCRIPT

The development of this program has proven to be a real learning experience. This was due to the many pieces of code that had to be written to handle issues that are not a part of average applications programming environment. Much of the program can be considered closer to operating system programming than to applications.

There also tends to be a never ending supply of "one more little feature" requests that keep the program in a constant state of change and also bring out latent bugs that did not seem to exist before.

REVIEW OF SDISK, BOOTFIX, AND FILTER KIT 1

REVIEW OF D P JOHNSON'S
SDISK, BOOTFIX, AND
FILTER KIT 1

by E. M. (Bud) Pass, Ph.D.
Computer Systems Consultants, Inc.
1454 Latta Lane, Conyers, GA 30207
Telephone Number 404-483-1717/4570

The standard COCO OS/9 disk drivers support only the SSDD 35 track non-standard disk format used by Tandy on the COCO. This is very inconvenient for those users and developers concerned with buying or marketing OS/9 software, as most existing OS/9

software was developed before COCO OS/9 was available. In order to port software to COCO OS/9, it was necessary to send it thru the TI port on the COCO at 300 Baud (and hope that OS/9 did not garbage it too much), or use the FHL O-PAK XCOPY utility (which works, but is tedious for many files), or use the new GIMIX COCO drivers (if you have a GIMIX system, which I do not), or type it in by hand, or ....

D P Johnson has a solution to the incompatible disk format problem which also extends the capabilities of the COCO for those who have drives with more capacity or speed than the SS 35-track drives sold by Tandy. It is called SDISK and costs $29.95 (+$1.00 shipping), but is worth several times that amount in the terms of the convenience it affords the user. It supports 1 to 3 SS or DS, SD or DD, 35 or 40 or 80 track 5.25" drives.

SDISK is composed of an OS/9 device driver (SDISK), several device descriptors (/SDx), a format program (SFORMAT), and a configurator (DESCGEN).

If all that is desired is to access and create standard OS/9 diskettes under COCO OS/9, the user runs DESCGEN once to generate a new device descriptor (/SD0, /SD1, ...) for each drive and saves them, along with a copy of the SDISK module, on a COCO OS/9 diskette. Then, whenever the SDISK and /SDx modules are have been loaded, each drive has a dual identity: /Dx for COCO OS/9 format, and /SDx for standard OS/9 format. All standard OS/9 programs, with the exception of FORMAT, work equally well with either type of device descriptor. The SFORMAT program is used in place of FORMAT; it works with either type of descriptor, so the original FORMAT program could be deleted and replaced by a renamed SFORMAT.

If the user desires to construct a bootable SS diskette already containing SDISK and /SDx, the manual accompanying SDISK provides the detailed directions for accomplishing it. Essentially, the user constructs the device descriptors with DESCGEN and uses OS9GEN to include them in the boot, along with SDISK.

In order to construct a bootable DS diskette (or to construct a single-stage bootable diskette for those systems without the DOS command), Johnson offers the BOOTFIX program for $9.95. It is used on a diskette freshly formatted by SFORMAT and COBBLER to rearrange the bootfile and kernal on track 34 so that the boot will be able to properly access them.

SDISK also provides three extensions to the GETSTT/SETSTT OS/9 functions, as follows:

```
SS.DREAD (GETSTT code $80)
    direct sector read
    with specified sector size,
        side, density, tracks
SS.DWRIT (SETSTT code $80)
    direct sector read
    with specified sector size,
        side, density, tracks
SS.UNFRZ (SETSTT code $81)
    unfreeze DD. information
```

In summary, the SDISK and BOOTFIX package provide the facilities for standard OS/9 disk format operations which should have been provided under COCO OS/9, rather than the restricted form actually present. The implementation is performed in an almost transparent manner, using the normal facilities of OS/9.

The other package from D P Johnson that I reviewed was FILTER KIT 1. It contains the following utility

programs, and costs $29.95:

ls	lists file names in current directory, with matching logic
buf	buffers input to eof, then passes it to output
cp	copies files in current directory to files of same names on output path, restricted to list of files on standard input
dl	deletes list of files from current directory
flist	copies contents of list of files from current directory
info	displays detailed file information
mv	moves list of files from current directory to output path
pag	reads standard input, producing a paginated listing
remove	removes file name from directory without releasing space
sell	changes owner numbers of list of file names
setat	changes file attributes of list of file names
sort	performs in-memory sort of records on standard input to standard output

The filter kit may be used on any OS/9 system, and is not restricted to the COCO version of OS/9. The utilities which I tried all seemed to perform as expected. If even one of them is useful, it is probably worth the cost of the entire package.

The address and telephone number for D P Johnson are as follows:

D P Johnson
7655 Cedarcrest Street
Portland, OR 97223
(503) 244-8152

--- ---

DISASSEMBLER

CONTINUED FROM LAST MONTH

```
                       * SEARCHES TAG TABLE FOR ADDRESS IN D REG.
                       * IF FOUND, CARRY IS CLEAR; ELSE IT IS SET.
                       *
OF80 34 06    FINDTG  PSHS  D
OF82 CC 6000          LDD   #6000   *3 x 2^13
OF85 DD 1E            STD   BIND
OF87 9E 07            LDX   TAGST
OF89 30 1D            LEAX  -3,X
OF8B 30 8B    FINDT1  LEAX  D,X     *BINARY ADJUST
OF8D 9C 09            CMPX  TAGEND  *WITHIN TABLE?
OF8F 24 09            BCC   FINDT2  *NO! GO LOWER
OF91 EC E4            LDD   0,S     *TAG VALUE
OF93 10A3 01          CMPD  1,X     *TABLE VALUE
OF96 27 12            BEQ   FINDT4  *FOUND TAG
OF98 24 08            BCC   FINDT3  *ADD NEXT OFFSET
OF9A 8D 0F    FINDT2  BSR   FINDT5  *DO BINARY DIVIDE
OF9C 25 08            BCS   FINDT4  *TAG NOT FOUND
OF9E 43              COMA          *NEGATE FOR SUBTRACT
OF9F 53              COMB
OFA0 C3 0001          ADDD  #1
OFA3 20 E6            BRA   FINDT1  *NEXT TRY
OFA5 8D 04    FINDT3  BSR   FINDT5  *BINARY DIVIDE
OFA7 24 E2            BCC   FINDT1  *NEXT TRY
OFA9 35 B6    FINDT4  PULS  D,PC    *RETURN TO PGM
OFAB 04 1E    FINDT5  LSR   BIND    *BINARY DIVIDE
OFAD 06 1F            ROR   BIND+1  *CARRY SET = DONE
OFAF DC 1E            LDD   BIND
OFB1 39              RTS
             PAG
                       * PUTS THE ORG PSEUDO OP IN
                       *THE PRINT LINE.
```

```
OFB2 8E 1260   DOORG  LDX  #ORGS
OFB5 108E 0069        LDY  #POPCD
OFB9 C6 07            LDB  #7
OFBB A6 80    DOORG1  LDA  0,X+
OFBD A7 A0            STA  0,Y+
OFBF 5A              DECB
OFC0 26 F9            BNE  DOORG1
OFC2 96 19            LDA  NITOP
OFC4 17 FE94          LBSR HEXASC
OFC7 ED A1            STD  0,Y++
OFC9 96 1A            LDA  NITOP+1
OFCB 17 FE8D          LBSR HEXASC
OFCE ED A4            STD  0,Y
OFD0 8D 40            BSR  PRINT
OFD2 8D 31            BSR  CLRPLN
OFD4 39              RTS
             PAG
                       *
                       * WRITES THE TAG, OPCODE, & OPERAND
                       * TO DISC, SUPPRESSING EXTRA SPACES (#A0).
OFD5 8E 0259   WRTDSC  LDX  #FCBOUT  *WRITE SOURCE TO DISC
OFD8 108E 0063         LDY  #PTAG    *STARTING AT TAG
OFDC 108C 0088  WRTDS1  CMPY  #PLINE+62
OFE0 27 1D             BEQ   WRTDS3   *DONE
OFE2 A6 A0             LDA   0,Y+
OFE4 84 7F     WRTDS5  ANDA  #$7F
OFE6 BD D406           JSR   FMS
OFE9 26 19             BNE   WRTDS4   *ERROR
OFEB A6 3F             LDA   -1,Y     *GET IT BACK
OFED B1 A0             CMPA  #$A0
OFEF 26 EB             BNE   WRTDS1
OFF1 108C 0088  WRTDS2  CMPY  #PLINE+62
OFF5 27 08             BEQ   WRTDS3
OFF7 A6 A0             LDA   0,Y+     *SQUISH SPACES
OFF9 B1 A0             CMPA  #$A0     *SPECIAL SPACE
OFFB 26 E7             BNE   WRTDS5
OFFD 20 F2             BRA   WRTDS2
OFFF 86 0D     WRTDS3  LDA   #$0D     *C/R
1001 BD D406           JSR   FMS
1004 39       WRTDS4  RTS            *TEST ERROR ELSEWHERE
             PAG
```

```
1005 8E 004A   CLRPLN  LDX  #PLINE   *CLEAR PRINTLINE
1008 B6 A0            LDA  #$A0
100A C6 4F            LDB  #79
100C A7 80    CLRPL1  STA  0,X+
100E 5A              DECB
100F 26 FB            BNE  CLRPL1
1011 39              RTS
                       *
                       * PRINTS THE PRINTLINE.
                       *
1012 96 13    PRINT   LDA  LINENO
1014 17 FE44         LBSR HEXASC
1017 DD 4A           STD  PLNO
1019 96 14           LDA  LINENO+1
101B 17 FE3D         LBSR HEXASC
101E DD 4C           STD  PLNO+2
1020 96 14           LDA  LINENO+1  *BUMP THE LINE #
1022 8B 01           ADDA #1
1024 19              DAA
1025 97 14           STA  LINENO+1
1027 96 13           LDA  LINENO
1029 89 00           ADCA #0
102B 19              DAA
102C 97 13           STA  LINENO
102E 8E 004A         LDX  #PLNO
1031 8D 5E           BSR  ZSUPP    *ZERO SUPPRESS
1033 86 CC03         LDA  DEPTH
1036 27 09           BEQ  PRINT3   *NO HEADINGS
1038 80 04           SUBA #4
103A B1 CC1A         CMPA CURLN
103D 26 02           BNE  PRINT3   *NOT TOP PAGE
103F 8D 3A           BSR  PAGE     *PRINT HEADING
1041 8E 004A  PRINT3 LDX  #PLINE
1044 BD CD1E         JSR  FSTRNG   *PRINT IT
1047 8D 8C           BSR  WRTDSC   *ALL LINES GO TO DISC
1049 39              RTS
```

```
104A FC 0117  PHEAD  LDD  HPGNO    *PRINT HEADING
104D 1E 89           EIG  A,B
104F 8B 01           ADDA #1
1051 19              DAA
1052 1E 89           EIG  A,B
1054 89 00           ADCA #0
1056 19              DAA
1057 FD 0117         STD  HPGNO
105A 17 FDFE         LBSR HEXASC
105D FD              STD  #PAGE
1060 86 011B         LDA  HPGNO+1
1063 17 FDF5         LBSR HEXASC
1066 FD 0114         STD  #PAGE+2
1069 8E 0112         LDX  #HPAGE
106C 8D 23           BSR  ZSUPP    *ZERO SUPPRESS
106E 8D 1A           BSR  FOOT1
1070 8D 18           BSR  FOOT1
1072 8E 0003         LDX  #HEAD
1075 BD CD1E         JSR  FSTRNG
1078 8D 10           BSR  FOOT1
107A 39              RTS
                       *
107B 86 CC1A  PAGE   LDA  CURLN    *PRINT FOOTER (SPACES)
107E B1 CC03         CMPA DEPTH
1081 27 04           BEQ  PAGE1
1083 8D 05           BSR  FOOT1
1085 20 F4           BRA  PAGE
```

```
1087 8D  C1      PAGE1  BSR   PHEAD
1089 39                 RTS
*
108A BE  0099    FOOT1  LDX   #HEAD4
108D BD  CD1E           JSR   PSTRNG
1090 39                 RTS
*
1091 A6  80      ZSUPP  LDA   0,X+     *ZERO SUPRESS
1093 81  30             CMPA  #'0
1095 26  06             BNE   ZSUPP1
1097 86  20             LDA   #$20
1099 A7  1F             STA   -1,X
109B 20  F4             BRA   ZSUPP
109D 39          ZSUPP1 RTS
                        PAG
*SORTS XRTAG INTO THE CROSS REFERENCE
*TABLE.
*
109E 34  16      XRSORT PSHS  X,D
10A0 9E  44             LDX   XREND
10A2 30  05             LEAX  5,X
10A4 BC  CC28           CMPX  MEMEND
10A7 25  06             BCS   XRSOR1
10A9 30  1B             LEAX  -5,X
10AB 9F  42             STX   XRST     *BEYOND MEMORY
10AD 20  75             BRA   XRSOR9
10AF CC  5000    XRSOR1 LDD   #$5000   * 5 * 2^12
10B2 DD  1E             STD   BIND
10B4 9E  42             LDX   XRST
10B6 30  1B             LEAX  -5,X
10B8 30  88      XRFIN1 LEAX  0,X
10BA 9C  44             CMPX  XREND
10BC 24  09             BCC   XRFIN2   *LOWER
10BE DC  47             LDD   XRTAG+1
10C0 10A3 01            CMPD  1,X
10C3 27  13             BEQ   XRFIN4   *FOUND
10C5 24  0C             BCC   XRFIN3   *ADD
10C7 17  FEE1    XRFIN2 LBSR  FIND15   *SUBTRACT
10CA 25  0C             BCS   XRFIN4   *NOT THERE
10CC 43                 COMA
10CD 53                 COMB
10CE C3  0001           ADDD  #1
10D1 20  E5             BRA   XRFIN1
10D3 17  FE05    XRFIN3 LBSR  FIND15
10D6 24  E0             BCC   XRFIN1
10D8 9C  44      XRFIN4 CMPX  XREND
10DA 27  08             BEQ   XRFIN6   *GOES HERE
10DC DC  47             LDD   XRTAG+1
10DE 10A3 01            CMPD  1,X
10E1 25  04             BCS   XRFIN6   *AT OR BEYOND
10E3 30  05             LEAX  5,X
10E5 20  F1             BRA   XRFIN4
10E7 DC  46      XRFIN6 LDD   XRTAG
10E9 2A  11             BPL   XRFIN8   *GOES HERE
10EB 9C  42      XRFIN7 CMPX  XRST
10ED 27  00             BEQ   XRFIN8   *GOES HERE
10EF DC  47             LDD   XRTAG+1
10F1 10A3 1C            CMPD  -4,X
10F4 25  02             BCS   XRFI10
10F6 26  04             BNE   XRFIN8   *GOES HERE
10F8 30  1B      XRFI10 LEAX  -5,X
10FA 20  EF             BRA   XRFIN7
10FC 9F  1E      XRFIN8 STX   BIND     *TEMP STORE
10FE 9E  44             LDX   XREND
1100 30  05             LEAX  5,X
1102 9F  44             STX   XREND
1104 30  1B      XRFIN9 LEAX  -5,X
1106 9C  1E             CMPX  BIND
1108 27  0E             BEQ   XRFI11
110A A6  1B             LDA   -5,X
110C A7  84             STA   0,X
110E DC  1C             LDD   -4,X
1110 ED  01             STD   1,X
1112 EC  1E             LDD   -2,X
1114 ED  03             STD   3,X
1116 20  EC             BRA   XRFIN9
1118 96  46      XRFI11 LDA   XRTAG
111A A7  84             STA   0,X
111C DC  47             LDD   XRTAG+1
111E ED  01             STD   1,X
1120 DC  13             LDD   LINEND
1122 ED  03             STD   3,X
1124 35  96      XRSOR9 PULS  X,D,PC
                        PAG
*
*PRINTS THE CROSS REFERENCE
*
1126 B6  CC03    XRPRNT LDA   DEPTH
1129 27  03             BEQ   XRPRN6
112B 17  FF40           LBSR  PAGE
112E 9E  42      XRPRN6 LDX   XRST
1130 9C  44      XRPRN1 CMPX  XREND
1132 27  5B             BEQ   XRPRN5   *DONE
1134 34  10             PSHS  X
1136 B6  CC03           LDA   DEPTH
1139 27  0A             BEQ   XRPRN7
113B 80  04             SUBA  #4
113D B1  CC1A           CMPA  CURLN
1140 26  03             BNE   XRPRN7
1142 17  FF36           LBSR  PAGE
1145 BD  CD24   XRPRN7  JSR   PCRLF
1148 35  10             PULS  X
114A EC  01             LDD   1,X
114C C6  0E             LDB   #14     *MAX ADDR'S IN LINE
114F 8D  42             BSR   XRPLN   *PRINT LINE & SPACE
1151 34  34             PSHS  X,Y,B
```

```
1153 A6  84             LDA   0,X
1155 BD  CD18           JSR   PUTCHR
1158 AE  61             LDX   1,S
115A 30  01             LEAX  1,X
115C BD  CD45           JSR   OUTADR   *REST OF TAG
115F 86  20             LDA   #$20
1161 BD  CD18           JSR   PUTCHR
1164 86  20             LDA   #$20
1166 BD  CD18           JSR   PUTCHR
1169 86  20             LDA   #$20
116B BD  CD18           JSR   PUTCHR
116E 35  34             PULS  X,Y,B
1170 30  05      XRPRN2 LEAX  5,X
1172 10AC 01            CMPY  1,X
1175 26  B9             BNE   XRPRN1   *NEW TAG
1177 5D                 TSTB
1178 26  11             BNE   XRPRN4
117A C6  00             LDB   #13
117C 34  34             PSHS  X,Y,B
117E BD  CD24           JSR   PCRLF
1181 86  20      XRPRN3 LDA   #$20
1183 BD  CD18           JSR   PUTCHR   *OUTPUT 13 SPACES
1186 5A                 DECB
1187 26  F8             BNE   XRPRN3
1189 35  34             PULS  B,X,Y
118B BD  06      XRPRN4 BSR   XRPLN    *PRINT TAG LINE & SPACE
118D 20  E1             BRA   XRPRN2
118F BD  CD24   XRPRN5  JSR   PCRLF
1192 39                 RTS
*
1193 34  34      XRPLN  PSHS  X,Y,B
1195 A6  03             LDA   3,X
1197 17  FCC1           LBSR  HEXASC
119A 94                 STD   HEAD4-5
119C A6  04             LDA   4,X
119E 17  F8BA           LBSR  HEXASC
11A1 DD  96             STD   HEAD4-3
11A3 86  20             LDA   #$20
11A5 97  98             STA   HEAD4-1
11A7 8E  0094           LDX   #HEAD4-5 *ZERO SUPRESS
11AA A6  80      XRPLN1 LDA   0,X+
11AC 81  30             CMPA  #'0
11AE 26  06             BNE   XRPLN2
11B0 86  20             LDA   #$20
11B2 A7  1F             STA   -1,X
11B4 20  F4             BRA   XRPLN1
11B6 C6  05      XRPLN2 LDB   #5
11B8 8E  0094           LDX   #HEAD4-5
11BB A6  80      XRPLN4 LDA   0,X+
11BD BD  CD18           JSR   PUTCHR
11C0 5A                 DECB
11C1 26  FB             BNE   XRPLN4
11C3 6A  E4             DEC   0,S
11C5 35  84             PULS  X,Y,B,PC
                        PAG
11C7 4E 4F 54 20 MSG2   FCC   "NOT ENOUGH MEMORY: ABORTING."
11CB 45 4E 4F 55
11CF 47 4B 20 4D
11D3 45 4D 4F 52
11D7 59 3A 20 41
11DB 42 4F 52 54
11DF 49 4E 47 2E
11E3 04                 FCB   4
11E4 42 49 4E 41 MSG4   FCC   "BINARY FORMAT ERROR"
11EB 52 59 20 46
11EC 4F 52 4D 41
11F0 54 20 45 52
11F4 52 4F 52
11F7 04                 FCB   4
11F8 A0         TFXG    FCB   $A0     *TRANSFER/EXCHANGE OPNDS
11F9 44                 FCC   "D"
11FA A0                 FCB   $A0
11FB 58                 FCC   "X"
11FC A0                 FCB   $A0
11FD 59                 FCC   "Y"
11FE A0                 FCB   $A0
11FF 55                 FCC   "U"
1200 A0                 FCB   $A0
1201 53 50 43           FCC   "SPC"
1204 A0                 FCB   $A0
1205 41                 FCC   "A"
1206 A0                 FCB   $A0
1207 42 43 43 44        FCC   "BCCD"
1208 50
120C 43 43     PSPL    FCC   "CC"    *PUSH/PULL OPERANDS
120E A0                 FCB   $A0
120F 41                 FCC   "A"
1210 A0                 FCB   $A0
1211 42 44 50           FCC   "BDP"
1214 A0                 FCB   $A0
1215 58                 FCC   "X"
1216 A0                 FCB   $A0
1217 59 53 55 50        FCC   "YSUPC"
1218 43
121C 44 50 20 4C DPMSG  FCC   "DP LOADED"
1220 4F 41 44 45
1224 44
1225 44 49 52 45 DPMSG1 FCC   "DIRECT ADDR"
1229 43 54 20 41
122D 44 52
1230 2A 57 41 52 DPMSG2 FCC   "*WARNING: DIRECT PAGE ADDRESSING "
1234 4E 49 4E 47
1238 3A 20 44 49
123C 52 45 43 54
1240 20 50 41 47
1244 45 20 41 44
```

```
1248 44 52 45 53
124C 53 49 4E 47
1250 20
1251 55 53 45 44          FCC    "USED!"
1255 21
1256 53 45 54 44  OPMSG3  FCC    "SETUP 0"
125A 50 20 30
125D 4E 41 4D    NAMS    FCC    "NAM"
1260 4F 52 47    ORGS    FCC    "ORG"
1263 A0 A0 A0            F B    $A0,$A0,$A0
1266 24                  FCC    "$"
1267 45 51 55    EQUS    FCC    "EQU"
126A 46 43 42    FCBS    FCC    "FCB"
126D A0 A0 A0            FCB    $A0,$A0,$A0
1270 24                  FCC    "$"
1271 45 4E 44    ENDS    FCC    "END"
1274 46 43 43    FCCS    FCC    "FCC"
1277 A0 A0 A0            FCB    $A0,$A0,$A0
127A 22                  FCB    $22
127B 4F 50 54    OPTS    FCC    "OPT"
127E A0 A0 A0            F B    $A0,$A0,$A0
              *END OF SUPPORT MODULES
1281 50 41 47            FCC    "PAG"
              * LIB 1.DIST81.TXT
1284 2122 2324   LOOK10  FDB    $2122,$2324,$2526,$2728,$292A
1288 2526 2728
128C 292A
128E 292C 202E           FDB    $282C,$202E,$2F3F,$838C,$8E93,$9C9E
1292 2F3F 838C
1296 8E93 9C9E
129A 9FA3 ACAE           FDB    $9FA3,$ACAE,$AFB3,$BCBE,$BFCE,$DEDF
127E AFB3 BCBE
12A2 BFCE DEDF
12AA EE EF FE FF          FCB    $EE,$EF,$FE,$FF
        12AA LK10E  EQU    *         *DON'T SCREW WITH THIS TAG
12AA 3F83 8C93   LOOK11  FDB    $3F83,$8C93,$9CA3,$ACB0
12AE 9CA3 ACB3
12B2 BC                  FCB    $BC
        12B3 LK11E  EQU    *         *DON'T MISTREAT EITHER!
              ILLEG  MACRO
                     FCB    $FF
                     RMB    6
                     ENDM
              *END NOTHING START 0x
        12B3 ZZZZZ  EQU    *
12B3 4E 45 47    OPDTBL  FCC    "NEG"     *00
12B6 A0 A0               FCB    $A0,$A0   *SPECIAL SPACE
12B8 2288               FDB    $2288
12BA                    ILLEG
12C1                    ILLEG
12C8 43 4F 4D           FCC    "COM"     * 03
12CB A0 A0              FCB    $A0,$A0
12CD 2288              FDB    $2288
12CF 4C 53 52          FCC    "LSR"     * 04
12D2 A0 A0             FCB    $A0,$A0
12D4 2288             FDB    $2288
12D6                  ILLEG
12DD 52 4F 52         FCC    "ROR"     * 06
12E0 A0 A0            FCB    $A0,$A0
12E2 2288            FDB    $2288
12E4 41 53 52        FCC    "ASR"     *07
12E7 A0 A0           FCB    $A0,$A0
12E9 2288           FDB    $2288
12EB 41 53 4C       FCC    "ASL"     * 08
12EE A0 A0          FCB    $A0,$A0
12F0 2288          FDB    $2288
12F2 52 4F 4C      FCC    "ROL"     *09
12F5 A0 A0         FCB    $A0,$A0
12F7 2288         FDB    $2288
12F9 44 45 43     FCC    "DEC"     * 0A
12FC A0 A0        FCB    $A0,$A0
12FE 2288        FDB    $2288
1300             ILLEG
1307 49 4E 43    FCC    "INC"     *0C
130A A0 A0       FCB    $A0,$A0
130C 2288       FDB    $2288
130E 54 53 54   FCC    "TST"     * 0D
1311 A0 A0      FCB    $A0,$A0
1313 2288      FDB    $2288
1315 4A 4D 50  FCC    "JMP"     * 0E
1318 A0 A0     FCB    $A0,$A0
131A AABB     FDB    $AABB
131C 43 4C 52 FCC    "CLR"     * 0F
131F A0 A0    FCB    $A0,$A0
1321 2288    FDB    $2288
              *END 0x START 1x
1323 10              FCB    $10
1324                 RMB    6
132A 11              FCB    $11
132B                 RMB    6
1331 4E 4F 50        FCC    "NOP"     *12
1334 A0 A0           FCB    $A0,$A0
1336 0180           FDB    $0180
1338 53 59 4E 43    FCC    "SYNC"    *13
133C A0            FCB    $A0
133D 0180         FDB    $0180
133F             ILLEG
1346             ILLEG
134D 4C 42 52 41  FCC    "LBRA"    *16
1351 A0          FCB    $A0
1352 D88C       FDB    $D88C
1354 4C 42 53 52 FCC    "LBSR"
1358 A0         FCB    $A0
1359 D88C      FDB    $D88C
135B           ILLEG
1362 44 41 41  FCC    "DAA"
```

```
1365 A0 A0           F B    $A0,$A0
1367 0180            FDB    $0180
1369 4F 52 43 43     FCC    "ORCC"
136D A0              FCB    $A0
136E 4288            FDB    $4288
1370                 ILLEG
1377 41 4E 44 43     FCC    "ANDCC"
137B 43
137C 4288            FDB    $4288
137E 53 45 58        FCC    "SEX"
1381 A0              FCB    $A0
1382 0180            FDB    $0180
1385 45 58 47        FCC    "EXG"
1388 A0              FCB    $A0
1388 0288            FDB    $0288
138C 54 46 52        FCC    "TFR"
138F A0 A0           FCB    $A0,$A0
1391 0288            FDB    $0288
              *END 1x START 2x
1393 42 52 41        FCC    "BRA"
1396 A0 A0           FCB    $A0,$A0
1398 DAB8            FDB    $DAB8
139A 42 52 4E        FCC    "BRN"
139D A0 A0           FCB    $A0,$A0
139F D288            FDB    $D288
13A1 42 48 49        FCC    "BHI"
13A4 A0 A0           FCB    $A0,$A0
13A6 D288            FDB    $D288
13A8 42 4C 53        FCC    "BLS"
13AB A0 A0           FCB    $A0,$A0
13AD D288            FDB    $D288
13AF 42 43 43        FCC    "BCC"
13B2 A0 A0           FCB    $A0,$A0
13B4 D288            FDB    $D288
13B6 42 43 53        FCC    "BCS"
13B9 A0 A0           F B    $A0,$A0
13BB D288            FDB    $D288
13BD 42 4E 45        FCC    "BNE"
13C0 A0 A0           FCB    $A0,$A0
13C2 D288            FDB    $D288
13C4 42 45 51        FCC    "BEQ"
13C7 A0 A0           FCB    $A0,$A0
13C9 D288            FDB    $D288
13CB 42 56 43        FCC    "BVC"
13CE A0 A0           FCB    $A0,$A0
13D0 D288            FDB    $D288
13D2 42 56 53        FCC    "BVS"
13D5 A0 A0           FCB    $A0,$A0
13D7 D288            FDB    $D288
13D9 42 50 4C        FCC    "BPL"
13DC A0 A0           FCB    $A0,$A0
13DE D288            FDB    $D288
13E0 42 4D 49        FCC    "BMI"
13E3 A0 A0           FCB    $A0,$A0
13E5 D288            FDB    $D288
13E7 42 47 45        FCC    "BGE"
13EA A0 A0           FCB    $A0,$A0
13EC D288            FDB    $D288
13EE 42 4C 54        FCC    "BLT"
13F1 A0 A0           FCB    $A0,$A0
13F3 D288            FDB    $D288
13F5 42 47 54        FCC    "BGT"
13F8 A0 A0           FCB    $A0,$A0
13FA D288            FDB    $D288
13FC 42 4C 45        FCC    "BLE"
13FF A0 A0           FCB    $A0,$A0
1401 D288            FDB    $D288
              *END 2x START 3x
1403 4C 45 41 58     FCC    "LEAX"
1407 A0              FCB    $A0
1408 1288            FDB    $1288
140A 4C 45 41 59     FCC    "LEAY"
140E A0              FCB    $A0
140F 1288            FDB    $1288
1411 4C 45 41 53     FCC    "LEAS"
1415 A0              FCB    $A0
1416 1288            FDB    $1288
1418 4C 45 41 55     FCC    "LEAU"
141C A0              FCB    $A0
141D 1288            FDB    $1288
141F 50 53 48 53     FCC    "PSHS"
1423 A0              FCB    $A0
1424 0288            FDB    $0288
1426 50 55 4C 53     FCC    "PULS"
142A A0              FCB    $A0
142B 0288            FDB    $0288
142D 50 53 48 55     FCC    "PSHU"
1431 A0              FCB    $A0
1432 0288            FDB    $0288
1434 50 55 4C 55     FCC    "PULU"
1438 A0              FCB    $A0
1439 0288            FDB    $0288
143B                 ILLEG
1442 52 54 53        FCC    "RTS"
1445 A0 A0           FCB    $A0,$A0
1447 0980            FDB    $0980
1449 41 42 58        FCC    "ABX"
144C A0 A0           FCB    $A0,$A0
144E 0180            FDB    $0180
1450 52 54 49        FCC    "RTI"
1453 A0 A0           FCB    $A0,$A0
1455 0980            FDB    $0980
1457 43 57 41 49     FCC    "CWAI"
145B A0              FCB    $A0
145C 4288            FDB    $4288
145E 4D 55 4C        FCC    "MUL"
```

```
1461 A0 A0        FCB    $A0,$A0
1463 0180         FDB    $0180
1465              ILLEG
146C 53 57 49     FCC    "SWI"
146F A0 A0        FCB    $A0,$A0
1471 0180         FDB    $0180
                  *END 3x START 4x
1473 4E 45 47 41  FCC    "NEGA"
1477 A0           FCB    $A0
1478 0180         FDB    $0180
147A              ILLEG
147B              ILLEG
1488 43 4F 4D 41  FCC    "COMA"
148C A0           FCB    $A0
148D 0180         FDB    $0180
148F 4C 53 52 41  FCC    "LSRA"
1493 A0           FCB    $A0
1494 0180         FDB    $0180
1496              ILLEG
1498 52 4F 52 41  FCC    "RORA"
14A1 A0           FCB    $A0
14A2 0180         FDB    $0180
14A4 41 53 52 41  FCC    "ASRA"
14A8 A0           FCB    $A0
14A9 0180         FDB    $0180
14AB 41 53 4C 41  FCC    "ASLA"
14AF A0           FCB    $A0
14B0 0180         FDB    $0180
14B2 52 4F 4C 41  FCC    "ROLA"
14B6 A0           FCB    $A0
14B7 0180         FDB    $0180
14B9 44 45 43 41  FCC    "DECA"
14BD A0           FCB    $A0
14BE 0180         FDB    $0180
14C0              ILLEG
14C7 49 4E 43 41  FCC    "INCA"
14CB A0           FCB    $A0
14CC 0180         FDB    $0180
14CE 54 53 54 41  FCC    "TSTA"
14D2 A0           FCB    $A0
14D3 0180         FDB    $0180
14D5              ILLEG
14DC 43 4C 52 41  FCC    "CLRA"
14E0 A0           FCB    $A0
14E1 0180         FDB    $0180
                  *END 4x START 5x
14E3 4E 45 47 42  FCC    "NEGB"
14E7 A0           FCB    $A0
14E8 0180         FDB    $0180
14EA              ILLEG
14F1              ILLEG
14F8 43 4F 4D 42  FCC    "COMB"
14FC A0           FCB    $A0
14FD 0180         FDB    $0180
14FF 4C 53 52 42  FCC    "LSRB"
1503 A0           FCB    $A0
1504 0180         FDB    $0180
1506              ILLEG
150D 52 4F 52 42  FCC    "RORB"
1511 A0           FCB    $A0
1512 0180         FDB    $0180
1514 41 53 52 42  FCC    "ASRB"
1518 A0           FCB    $A0
1519 0180         FDB    $0180
151B 41 53 4C 42  FCC    "ASLB"
151F A0           FCB    $A0
1520 0180         FDB    $0180
1522 52 4F 4C 42  FCC    "ROLB"
1526 A0           FCB    $A0
1527 0180         FDB    $0180
1529 44 45 43 42  FCC    "DECB"
152D A0           FCB    $A0
152E 0180         FDB    $0180
1530              ILLEG
1537 49 4E 43 42  FCC    "INCB"
153B A0           FCB    $A0
153C 0180         FDB    $0180
153E 54 53 54 42  FCC    "TSTB"
1542 A0           FCB    $A0
1543 0180         FDB    $0180
1545              ILLEG
154C 43 4C 52 42  FCC    "CLRB"
1550 A0           FCB    $A0
1551 0180         FDB    $0180
                  *END 5x START 6x
1553 4E 45 47     FCC    "NEG"
1556 A0 A0        FCB    $A0,$A0
1558 1280         FDB    $1280
155A              ILLEG
1561              ILLEG
1568 43 4F 4D     FCC    "COM"
156B A0 A0        FCB    $A0,$A0
156D 1280         FDB    $1280
156F 4C 53 52     FCC    "LSR"
1572 A0 A0        FCB    $A0,$A0
1574 1280         FDB    $1280
1576              ILLEG
157D 52 4F 52     FCC    "ROR"
1580 A0 A0        FCB    $A0,$A0
1582 1280         FDB    $1280
1584 41 53 52     FCC    "ASR"
1587 A0 A0        FCB    $A0,$A0
1589 1280         FDB    $1280
158B 41 53 4C     FCC    "ASL"
158E A0 A0        FCB    $A0,$A0
1590 1280         FDB    $1280
1592 52 4F 4C     FCC    "ROL"
1595 A0 A0        FCB    $A0,$A0
1597 1280         FDB    $1280
1599 44 45 43     FCC    "DEC"
159C A0 A0        FCB    $A0,$A0
159E 1280         FDB    $1280
15A0              ILLEG
15A7 49 4E 43     FCC    "INC"
15AA A0 A0        FCB    $A0,$A0
15AC 1280         FDB    $1280
15AE 54 53 54     FCC    "TST"
15B1 A0 A0        FCB    $A0,$A0
15B3 1280         FDB    $1280
15B6 4A 4D 50     FCC    "JMP"
15B8 A0 A0        FCB    $A0,$A0
15BA 9A88         FDB    $9A88
15BC 43 4C 52     FCC    "CLR"
15BF A0 A0        FCB    $A0,$A0
15C1 1280         FDB    $1280
                  *END 6x START 7x
15C3 4E 45 47     FCC    "NEG"
15C6 A0 A0        FCB    $A0,$A0
15C9 338C         FCB    $338C
15CA              ILLEG
15D1              ILLEG
15D8 43 4F 4D     FCC    "COM"
15DB A0 A0        FCB    $A0,$A0
15DD 338C         FDB    $338C
15DF 4C 53 52     FCC    "LSR"
15E2 A0 A0        FCB    $A0,$A0
15E4 338C         FDB    $338C
15E6              ILLEG
15ED 52 4F 52     FCC    "ROR"
15F0 A0 A0        FCB    $A0,$A0
15F2 338C         FDB    $338C
15F4 41 53 52     FCC    "ASR"
15F7 A0 A0        FCB    $A0,$A0
15F9 338C         FDB    $338C
15FB 41 53 4C     FCC    "ASL"
15FE A0 A0        FCB    $A0,$A0
1600 338C         FDB    $338C
1602 52 4F 4C     FCC    "ROL"
1605 A0 A0        FCB    $A0,$A0
1607 338C         FDB    $338C
1609 44 45 43     FCC    "DEC"
160C A0 A0        FCB    $A0,$A0
160E 338C         FDB    $338C
1610              ILLEG
1617 49 4E 43     FCC    "INC"
161A A0 A0        FCB    $A0,$A0
161C 338C         FDB    $338C
161E 54 53 54     FCC    "TST"
1621 A0 A0        FCB    $A0,$A0
1623 338C         FDB    $338C
1625 4A 4D 50     FCC    "JMP"
1628 A0 A0        FCB    $A0,$A0
162A BB8C         FDB    $BB8C
162C 43 4C 52     FCC    "CLR"
162F A0 A0        FCB    $A0,$A0
1631 338C         FDB    $338C
                  *END 7x START 8x
1633 53 55 42 41  FCC    "SUBA"
1637 A0           FCB    $A0
1638 4280         FDB    $4280
163A 43 4D 50 41  FCC    "CMPA"
163E A0           FCB    $A0
163F 4280         FDB    $4280
1641 53 42 43 41  FCC    "SBCA"
1645 A0           FCB    $A0
1646 4280         FDB    $4280
1648 53 55 42 44  FCC    "SUBD"
164C A0           FCB    $A0
164D 438C         FDB    $438C
164F 41 4E 44 41  FCC    "ANDA"
1653 A0           FCB    $A0
1654 4280         FDB    $4280
1656 42 49 54 41  FCC    "BITA"
165A A0           FCB    $A0
165B 4280         FDB    $4280
165D 4C 44 41     FCC    "LDA"
1660 A0 A0        FCB    $A0,$A0
1662 4280         FDB    $4280
1664              ILLEG
1668 45 4F 52 41  FCC    "EORA"
166F A0           FCB    $A0
1670 4280         FDB    $4280
1672 41 44 43 41  FCC    "ADCA"
1676 A0           FCB    $A0
1677 4280         FDB    $4280
1679 4F 52 41     FCC    "ORA"
167C A0 A0        FCB    $A0,$A0
167E 4280         FDB    $4280
1680 41 44 44 41  FCC    "ADDA"
1684 A0           FCB    $A0
1685 4280         FDB    $4280
1687 43 4D 50 58  FCC    "CMPX"
168B A0           FCB    $A0
168C 438C         FDB    $438C
168E 42 53 52     FCC    "BSR"
1691 A0 A0        FCB    $A0,$A0
1693 0A88         FDB    $0A88
1695 4C 44 58     FCC    "LDX"
1698 A0 A0        FCB    $A0,$A0
169A 438C         FDB    $438C
169C              ILLEG
                  *END 8x START 9x
16A3 53 55 42 41  FCC    "SUBA"
16A7 A0           FCB    $A0
16A8 2280         FDB    $2280
16AA 43 4D 50 41  FCC    "CMPA"
16AE A0           FCB    $A0
16AF 2280         FDB    $2280
16B1 53 42 43 41  FCC    "SBCA"
16B5 A0           FCB    $A0
16B6 2280         FDB    $2280
16B8 53 55 42 44  FCC    "SUBD"
16BC A0           FCB    $A0
16BD 2280         FDB    $2280
16BF 41 4E 44 41  FCC    "ANDA"
16C3 A0           FCB    $A0
16C4 2280         FDB    $2280
16C6 42 49 54 41  FCC    "BITA"
16CA A0           FCB    $A0
16CB 2280         FDB    $2280
16CD 4C 44 41     FCC    "LDA"
16D0 A0 A0        FCB    $A0,$A0
16D2 2280         FDB    $2280
16D4 53 54 41     FCC    "STA"
16D7 A0 A0        FCB    $A0,$A0
16D9 2280         FDB    $2280
16DB 45 4F 52 41  FCC    "EORA"
16DF A0           FCB    $A0
16E0 2280         FDB    $2280
16E2 41 44 43 41  FCC    "ADCA"
16E6 A0           FCB    $A0
16E7 2280         FDB    $2280
16E9 4F 52 41     FCC    "ORA"
16EC A0 A0        FCB    $A0,$A0
16EE 2280         FDB    $2280
16F0 41 44 44 41  FCC    "ADDA"
16F4 A0           FCB    $A0
16F5 2280         FDB    $2280
16F7 43 4D 50 58  FCC    "CMPX"
16FB A0           FCB    $A0
16FC 2280         FDB    $2280
16FE 4A 53 52     FCC    "JSR"
1701 A0 A0        FCB    $A0,$A0
1703 AA88         FDB    $AA88
1705 4C 44 58     FCC    "LDX"
1708 A0 A0        FCB    $A0,$A0
170A 2280         FDB    $2280
170C 53 54 58     FCC    "STX"
170F A0 A0        FCB    $A0,$A0
1711 2280         FDB    $2280
                  *END 9x START Ax
1713 53 55 42 41  FCC    "SUBA"
1717 A0           FCB    $A0
1718 1280         FDB    $1280
171A 43 4D 50 41  FCC    "CMPA"
171E A0           FCB    $A0
171F 1280         FDB    $1280
1721 58 42 43 41  FCC    "SBCA"
1725 A0           FCB    $A0
1726 1280         FDB    $1280
1728 53 55 42 44  FCC    "SUBD"
172C A0           FCB    $A0
172D 1280         FDB    $1280
172F 41 4E 44 41  FCC    "ANDA"
1733 A0           FCB    $A0
1734 1280         FDB    $1280
1736 42 49 54 41  FCC    "BITA"
173A A0           FCB    $A0
173B 1280         FDB    $1280
173D 4C 44 41     FCC    "LDA"
1740 A0 A0        FCB    $A0,$A0
1742 1280         FDB    $1280
1744 53 54 41     FCC    "STA"
1747 A0 A0        FCB    $A0,$A0
1749 1280         FDB    $1280
174B 45 4F 52 41  FCC    "EORA"
174F A0           FCB    $A0
1750 1280         FDB    $1280
1752 41 44 43 41  FCC    "ADCA"
1756 A0           FCB    $A0
1757 1280         FDB    $1280
1759 4F 52 41     FCC    "ORA"
175C A0 A0        FCB    $A0,$A0
175E 1280         FDB    $1280
1760 41 44 44 41  FCC    "ADDA"
1764 A0           FCB    $A0
1765 1280         FDB    $1280
1767 43 4D 50 58  FCC    "CMPX"
176B A0           FCB    $A0
176C 1280         FDB    $1280
176E 4A 53 52     FCC    "JSR"
1771 A0 A0        FCB    $A0,$A0
1773 9A88         FDB    $9A88
1775 4C 44 58     FCC    "LDX"
1778 A0 A0        FCB    $A0,$A0
177A 1280         FDB    $1280
177C 53 54 58     FCC    "STX"
177F A0 A0        FCB    $A0,$A0
1781 1280         FDB    $1280
                  *END Ax START Bx
1783 53 55 42 41  FCC    "SUBA"
1787 A0           FCB    $A0
1788 338C         FDB    $338C
178A 43 4D 50 41  FCC    "CMPA"
178E A0           FCB    $A0
178F 338C         FDB    $338C
1791 58 42 43 41  FCC    "SBCA"
1795 A0           FCB    $A0
1796 338C         FDB    $338C
```

```
1798 53 55 42 44    FCC  "SUBD"
179C A0             FCB  &A0
179D 338C           FDB  $338C
179F 41 4E 44 41    FCC  "ANDA"
17A3 A0             FCB  &A0
17A4 338C           FDB  $338C
17A6 42 49 54 41    FCC  "BITA"
17AA A0             FCB  &A0
17AB 338C           FDB  $338C
17AD 4C 44 41       FCC  "LDA"
17B0 A0 A0          FCB  &A0,&A0
17B2 338C           FDB  $338C
17B4 53 54 41       FCC  "STA"
17B7 A0 A0          FCB  &A0,&A0

17B9 338C           FDB  $338C
17BB 45 4F 52 41    FCC  "EORA"
17BF A0             FCB  &A0
17C0 338C           FDB  $338C
17C2 41 44 43 41    FCC  "ADCA"
17C6 A0             FCB  &A0
17C7 338C           FDB  $338C
17C9 4F 52 41       FCC  "ORA"
17CC A0 A0          FCB  &A0,&A0
17CE 338C           FDB  $338C
17D0 41 44 44 41    FCC  "ADDA"
17D4 A0             FCB  &A0
17D5 338C           FDB  $338C
17D7 43 4D 50 58    FCC  "CMPX"
17DB A0             FCB  &A0
17DC 338C           FDB  $338C
17DE 4A 53 52       FCC  "JSR"
17E1 A0 A0          FCB  &A0,&A0
17E3 888C           FDB  $888C
17E5 4C 44 58       FCC  "LDX"
17E8 A0 A0          FCB  &A0,&A0
17EA 338C           FDB  $338C
17EC 53 54 58       FCC  "STX"
17EF A0 A0          FCB  &A0,&A0
17F1 338C           FDB  $338C
                    *END Bx start Cx
17F3 53 55 42 42    FCC  "SUBB"
17F7 A0             FCB  &A0
17F8 4288           FDB  $4288
17FA 43 4D 50 42    FCC  "CMPB"
17FE A0             FCB  &A0
17FF 4288           FDB  $4288
1801 53 42 43 42    FCC  "SBCB"
1805 A0             FCB  &A0
1806 4288           FDB  $4288
1808 41 44 44 44    FCC  "ADDD"
180C A0             FCB  &A0
180D 438C           FDB  $438C
180F 41 4E 44 42    FCC  "ANDB"
1813 A0             FCB  &A0
1814 4288           FDB  $4288
1816 42 49 54 42    FCC  "BITB"
181A A0             FCB  &A0
181B 4288           FDB  $4288
181D 4C 44 42       FCC  "LDB"
1820 A0 A0          FCB  &A0,&A0
1822 4288           FDB  $4288
1824               ILLEG
1829 45 4F 52 42    FCC  "EORB"
182F A0             FCB  &A0
1830 4288           FDB  $4288
1832 41 44 43 42    FCC  "ADCB"
1836 A0             FCB  &A0
1837 4288           FDB  $4288
1839 4F 52 42       FCC  "ORB"
183C A0 A0          FCB  &A0,&A0
183E 4288           FDB  $4288
1840 41 44 44 42    FCC  "ADDB"
1844 A0             FCB  &A0
1845 4288           FDB  $4288
1847 4C 44 44       FCC  "LDD"
184A A0 A0          FCB  &A0,&A0
184C 438C           FDB  $438C
184E               ILLEG
1855 4C 44 55       FCC  "LDU"
1858 A0 A0          FCB  &A0,&A0
185A 438C           FDB  $438C
185C               ILLEG
                    *END Cx START Bx
1863 53 55 42 42    FCC  "SUBB"
1867 A0             FCB  &A0
1868 2288           FDB  $2288
186A 43 4D 50 42    FCC  "CMPB"
186E A0             FCB  &A0
186F 2288           FDB  $2288
1871 53 42 43 42    FCC  "SBCB"
1875 A0             FCB  &A0
1876 2288           FDB  $2288
1878 41 44 44 44    FCC  "ADDD"
187C A0             FCB  &A0
187D 2288           FDB  $2288
187F 41 4E 44 42    FCC  "ANDB"
1883 A0             FCB  &A0
1884 2288           FDB  $2288
1886 42 49 54 42    FCC  "BITB"
188A A0             FCB  &A0
188B 2288           FDB  $2288
188D 4C 44 42       FCC  "LDB"
1890 A0 A0          FCB  &A0,&A0
1892 2288           FDB  $2288
1894 53 54 42       FCC  "STB"
1897 A0 A0          FCB  &A0,&A0

1899 2288           FDB  $2288
189B 45 4F 52 42    FCC  "EORB"
189F A0             FCB  &A0
18A0 2288           FDB  $2288
18A2 41 44 43 42    FCC  "ADCB"
18A6 A0             FCB  &A0
18A7 2288           FDB  $2288
18A9 4F 52 42       FCC  "ORB"
18AC A0 A0          FCB  &A0,&A0
18AE 2288           FDB  $2288
18B0 41 44 44 42    FCC  "ADDB"
18B4 A0             FCB  &A0
18B5 2288           FDB  $2288
18B7 4C 44 44       FCC  "LDD"
18BA A0 A0          FCB  &A0,&A0
18BC 2288           FDB  $2288
18BE 53 54 44       FCC  "STD"
18C1 A0 A0          FCB  &A0,&A0
18C3 2288           FDB  $2288
18C5 4C 44 55       FCC  "LDU"
18C8 A0 A0          FCB  &A0,&A0
18CA 2288           FDB  $2288
18CC 53 54 55       FCC  "STU"
18CF A0 A0          FCB  &A0,&A0
18D1 2288           FDB  $2288
                    *END Dx START Ex
18D3 53 55 42 42    FCC  "SUBB"
18D7 A0             FCB  &A0
18D8 1288           FDB  $1288
18DA 43 4D 50 42    FCC  "CMPB"
18DE A0             FCB  &A0
18DF 1288           FDB  $1288
18E1 53 42 43 42    FCC  "SBCB"
18E5 A0             FCB  &A0
18E6 1288           FDB  $1288
18E8 41 44 44 44    FCC  "ADDD"
18EC A0             FCB  &A0
18ED 1288           FDB  $1288
18EF 41 4E 44 42    FCC  "ANDB"
18F3 A0             FCB  &A0
18F4 1288           FDB  $1288
18F6 42 49 54 42    FCC  "BITB"
18FA A0             FCB  &A0
18FB 1288           FDB  $1288
18FD 4C 44 42       FCC  "LDB"
1900 A0 A0          FCB  &A0,&A0
1902 1288           FDB  $1288
1904 53 54 42       FCC  "STB"
1907 A0 A0          FCB  &A0,&A0
1909 1288           FDB  $1288
190B 45 4F 52 42    FCC  "EORB"
190F A0             FCB  &A0
1910 1288           FDB  $1288
1912 41 44 43 42    FCC  "ADCB"
1916 A0             FCB  &A0
1917 1288           FDB  $1288
1919 4F 52 42       FCC  "ORB"
191C A0 A0          FCB  &A0,&A0
191E 1288           FDB  $1288
1920 41 44 44 42    FCC  "ADDB"
1924 A0             FCB  &A0
1925 1288           FDB  $1288
1927 4C 44 44       FCC  "LDD"
192A A0 A0          FCB  &A0,&A0
192C 1288           FDB  $1288
192E 53 54 44       FCC  "STD"
1931 A0 A0          FCB  &A0,&A0
1933 1288           FDB  $1288
1935 4C 44 55       FCC  "LDU"
1938 A0 A0          FCB  &A0,&A0
193A 1288           FDB  $1288
193C 53 54 55       FCC  "STU"
193F A0 A0          FCB  &A0,&A0
1941 1288           FDB  $1288
                    *END Ex START Fx
1943 53 55 42 42    FCC  "SUBB"
1947 A0             FCB  &A0
1948 338C           FDB  $338C
194A 43 4D 50 42    FCC  "CMPB"
194E A0             FCB  &A0
194F 338C           FDB  $338C
1951 53 42 43 42    FCC  "SBCB"
1955 A0             FCB  &A0
1956 338C           FDB  $338C
1958 41 44 44 44    FCC  "ADDD"
195C A0             FCB  &A0
195D 338C           FDB  $338C
195F 41 4E 44 42    FCC  "ANDB"
1963 A0             FCB  &A0
1964 338C           FDB  $338C
1966 42 49 54 42    FCC  "BITB"
196A A0             FCB  &A0
196B 338C           FDB  $338C
196D 4C 44 42       FCC  "LDB"
1970 A0 A0          FCB  &A0,&A0
1972 338C           FDB  $338C
1974 53 54 42       FCC  "STB"
1977 A0 A0          FCB  &A0,&A0
1979 338C           FDB  $338C
197B 45 4F 52 42    FCC  "EORB"
197F A0             FCB  &A0
1980 338C           FDB  $338C
1982 41 44 43 42    FCC  "ADCB"
1986 A0             FCB  &A0
1987 338C           FDB  $338C
1989 4F 52 42       FCC  "ORB"

198C A0 A0          FCB  &A0,&A0
198E 338C           FDB  $338C
1990 41 44 44 42    FCC  "ADDB"
1994 A0             FCB  &A0
1995 338C           FDB  $338C
1997 4C 44 44       FCC  "LDD"
199A A0 A0          FCB  &A0,&A0
199C 338C           FDB  $338C
199E 53 54 44       FCC  "STD"
19A1 A0 A0          FCB  &A0,&A0
19A3 338C           FDB  $338C
19A5 4C 44 55       FCC  "LDU"
19A8 A0 A0          FCB  &A0,&A0
19   338C           FDB  $338C
19AC 53 54 55       FCC  "STU"
19AF A0 A0          FCB  &A0,&A0
19B1 338C           FDB  $338C
          1983  ZZZZY  EQU  *
19B3 4C 42 52 4E TENDMD FCC  "LBRN"
19B7 A0             FCB  &A0
19B8 D308           FDB  $D308
19BA 4C 42 48 49    FCC  "LBHI"
19BE A0             FCB  &A0
19BF D308           FDB  $D308
19C1 4C 42 4C 53    FCC  "LBLS"
19C5 A0             FCB  &A0
19C6 D308           FDB  $D308
19C8 4C 42 43 43    FCC  "LBCC"
19CC A0             FCB  &A0
19CD D308           FDB  $D308
19CF 4C 42 43 53    FCC  "LBCS"
19D3 A0             FCB  &A0
19D4 D308           FDB  $D308
19D6 4C 42 4E 45    FCC  "LBNE"
19DA A0             FCB  &A0
19DB D308           FDB  $D308
19DD 4C 42 45 51    FCC  "LBEQ"
19E1 A0             FCB  &A0
19E2 D308           FDB  $D308
19E4 4C 42 56 43    FCC  "LBVC"
19E8 A0             FCB  &A0
19E9 D308           FDB  $D308
19EB 4C 42 56 53    FCC  "LBVS"
19EF A0             FCB  &A0
19F0 D308           FDB  $D308
19F2 4C 42 50 4C    FCC  "LBPL"
19F6 A0             FCB  &A0
19F7 D308           FDB  $D308
19F9 4C 42 4D 49    FCC  "LBMI"
19FD A0             FCB  &A0
19FE D308           FDB  $D308
1A00 4C 42 47 45    FCC  "LBGE"
1A04 A0             FCB  &A0
1A05 D308           FDB  $D308
1A07 4C 42 4C 54    FCC  "LBLT"
1A0B A0             FCB  &A0
1A0C D308           FDB  $D308
1A0E 4C 42 47 54    FCC  "LBGT"
1A12 A0             FCB  &A0
1A13 D308           FDB  $D308
1A15 4C 42 4C 45    FCC  "LBLE"
1A19 A0             FCB  &A0
1A1A D308           FDB  $D308
1A1C 53 57 49 32    FCC  "SWI2"
1A20 A0             FCB  &A0
1A21 01CD           FDB  $01CD
1A23 43 4D 50 44    FCC  "CMPD"
1A27 A0             FCB  &A0
1A28 43D8           FDB  $43D8
1A2A 43 4D 50 59    FCC  "CMPY"
1A2E A0             FCB  &A0
1A2F 43D8           FDB  $43D8
1A31 4C 44 59       FCC  "LDY"
1A34 A0 A0          FCB  &A0,&A0
1A36 43D8           FDB  $43D8
1A38 43 4D 50 44    FCC  "CMPD"
1A3C A0             FCB  &A0
1A3D 22D0           FDB  $22D0
1A3F 43 4D 50 59    FCC  "CMPY"
1A43 A0             FCB  &A0
1A44 22D0           FDB  $22D0
1A46 4C 44 59       FCC  "LDY"
1A49 A0 A0          FCB  &A0,&A0
1A4B 22D0           FDB  $22D0
1A4D 53 54 59       FCC  "STY"
1A50 A0 A0          FCB  &A0,&A0
1A52 22D0           FDB  $22D0
1A54 43 4D 50 44    FCC  "CMPD"
1A58 A0             FCB  &A0
1A59 12D0           FDB  $12D0
1A5B 43 4D 50 59    FCC  "CMPY"
1A5F A0             FCB  &A0
1A60 12D0           FDB  $12D0
1A62 4C 44 59       FCC  "LDY"
1A65 A0 A0          FCB  &A0,&A0
1A67 12D0           FDB  $12D0
1A69 53 54 59       FCC  "STY"
1A6C A0 A0          FCB  &A0,&A0
1A6E 12D0           FDB  $12D0
1A70 43 4D 50 44    FCC  "CMPD"
1A74 A0             FCB  &A0
1A75 33D8           FDB  $33D8
1A77 43 4D 50 59    FCC  "CMPY"
1A7B A0             FCB  &A0
1A7C 33D8           FDB  $33D8
1A7E 4C 44 59       FCC  "LDY"
```

```
1A81 A0 A0              FCB    $A0,$A0
1A83 3308              FDB    $3308
1A85 53 54 59         FCC    "STY"
1A88 A0 A0              FCB    $A0,$A0
1A8A 3308              FDB    $3308
1A8C 4C 44 53         FCC    "LDS"
1A8F A0 A0              FCB    $A0,$A0
1A91 4308              FDB    $4308
1A93 4C 44 53         FCC    "LDS"
1A96 A0 A0              FCB    $A0,$A0
1A98 53 54 53         FCC    "STS"
1A9B 2200              FDB    $2200
1A9D 53 54 53         FCC    "STS"
1AA0 A0 A0              FCB    $A0,$A0
1AA1 4C 44 53         FCC    "LDS"
1AA4 A0 A0              FCB    $A0,$A0
1AA6 1200              FDB    $1200
1AA8 53 54 53         FCC    "STS"
1AAB A0 A0              FCB    $A0,$A0
1AAD 1200              FDB    $1200
1AAF 4C 44 50         FCC    "LDP"
1AB2 A0 A0              FCB    $A0,$A0
1AB4 3308              FDB    $3308
1ABA 50 54 50         FCC    "STS"
1AB9 A0 A0              FCB    $A0,$A0
1ABB 3308              FDB    $3308
1ABD 53 57 49 33     ELVCMD FCC    "SWI3"
1AC1 A0                FCB    $A0
1AC2 01C0              FDB    $01C0
1AC4 43 4D 50 55     FCC    "CMPU"
1AC8 A0                FCB    $A0
1AC9 4308              FDB    $4308
1ACB 43 4D 50 50     FCC    "CMPS"
1ACF A0                FCB    $A0
1AD0 4308              FDB    $4308
1AD2 43 4D 50 55     FCC    "CMPU"
1AD6 A0                FCB    $A0
1AD7 2200              FDB    $2200
1AD9 43 4D 50 53     FCC    "CMPS"
1ADD A0                FCB    $A0
1ADE 2200              FDB    $2200
1AE0 43 4D 50 55     FCC    "CMPU"
1AE4 A0                FCB    $A0
1AE5 1200              FDB    $1200
1AE7 43 4D 50 53     FCC    "CMPS"
1AEB A0                FCB    $A0
1AEC 1200              FDB    $1200
1AEE 43 4D 50 55     FCC    "CMPU"
1AF2 A0                FCB    $A0
1AF3 3308              FDB    $3308
1AF5 43 4D 50 53     FCC    "CMPS"
1AF9 A0                FCB    $A0
1AFA 3308              FDB    $3308
                       OPT    LIS

*DUMPS TAG TABLE FOR ANALYSIS.
*ACCESSED BY A *D AFTER THE
*REST OF THE COMMAND LINE.
*NOT DOCUMENTED. IF YOU FOUND
*IT YOU CAN USE IT, BUT IT WAS
*MEANT FOR DEBUGGING THE PROGRAM.
*
1AFC 9E 07        DUMP   LDX    TAGST      *DEBUG
1AFE C6 07        DUMP1  LDB    #07
1B00 9C 09        DUMP2  CMPX   TAGEND
1B02 27 30               BEQ    DUMP4
1B04 BD C03C             JSR    OUTHEX
1B07 A6 80               LDA    0,X+
1B09 26 02               BNE    DUMP3
1B0B 86 20               LDA    #$20
1B0D BD CD18      DUMP3  JSR    PUTCHR
1B10 86 20               LDA    #$20
1B12 BD CD18             JSR    PUTCHR
1B15 34 10               PSHS   X
1B17 BD CD45             JSR    OUTADR
1B1A 35 10               PULS   X
1B1C 30 02               LEAX   2,X
1B1E 86 20               LDA    #$20
1B20 BD CD18             JSR    PUTCHR
1B23 86 20               LDA    #$20
1B25 BD CD18             JSR    PUTCHR
1B28 5A                  DECB
1B29 26 D5               BNE    DUMP2
1B2B 34 10               PSHS   X
1B2D BD CD24             JSR    PCRLF
1B30 35 10               PULS   X
1B32 20 CA               BRA    DUMP1
1B34 BD CD24      DUMP4  JSR    PCRLF
1B37 39                  RTS

* PRINT "FCC" LINE
1B38 0D 15        FCCPRT TST    FCCCNT
1B3A 27 1E               BEQ    FCCPR3     *NOTHING TO PRINT
1B3C 86 22               LDA    #$22       *CLOSE QUOTE
1B3E A7 9F 0016          STA    [FCCLOC]
1B42 8E 009A             LDX    #CLINE
1B45 108E 0050           LDY    #PADDR
1B49 C6 38               LDB    #56
1B4B A6 80        FCCPR1 LDA    0,X+
1B4D A7 A0               STA    0,Y+
1B4F 5A                  DECB
1B50 26 F9               BNE    FCCPR1
1B52 17 F4BD             LBSR   PRINT
1B55 26 07               BNE    FCCPR2
1B57 17 F4AB             LBSR   CLRPLN

1B5A 8D 03        FCCPR3 BSR    CLRDLN
1B5C 85 00               BITA   #0
1B5E 39          FCCPR2 RTS
*
1B5F 86 A0        CLRDLN LDA    #$A0
1B61 C6 38               LDB    #56
1B63 8E 009A             LDX    #CLINE
1B66 A7 80        CLRFC1 STA    0,X+
1B68 5A                  DECB
1B69 26 FB               BNE    CLRFC1
1B6B D7 15               STB    FCCCNT
1B6D CC 008A             LDD    #CCPND+1
1B70 DD 16               STD    FCCLOC
1B72 39                  RTS
*
*MOVES FILE NAME FROM 0,X TO 0,Y.
1B73 A6 80        MOVEXM LDA    0,X+
1B75 27 02               BEQ    MOVEX2
1B77 A7 A0               STA    0,Y+
1B79 5A          MOVEX2 DECB
1B7A 26 F7               BNE    MOVEXM
1B7C C6 2E               LDB    #'.
1B7E E7 A0               STB    0,Y+
1B80 C6 03               LDB    #3
1B82 A6 80        MOVEN1 LDA    0,X+
1B84 A7 A0               STA    0,Y+
1B86 5A                  DECB
1B87 26 F9               BNE    MOVEN1
1B89 39                  RTS
*
*
1B8A 9E 07        TAGCLN LDX    TAGST      *CONDENSES TAG TABLE
1B8C 1F 12               TFR    X,Y
1B8E 109C 09      TAGCL1 CMPY   TAGEND
1B91 27 12               BEQ    TAGCL3     *DONE
1B93 A6 A0               LDA    0,Y+
1B95 86 21               BITA   #$21       *REFERENCED OR 1ST
1B97 27 08               BEQ    TAGCL2     *NOT NEEDED
1B99 84 FE               ANDA   #$FE
1B9B A7 80               STA    0,X+
1B9D EC A4               LDD    0,Y
1B9F ED 81               STD    0,X++
1BA1 31 22        TAGCL2 LEAY   2,Y
1BA3 20 E9               BRA    TAGCL1
1BA5 9F 09        TAGCL3 STX    TAGEND
1BA7 9F 0B               STX    TTGST
1BA9 9F 0D               STX    TTGEND
1BAB 30 06               LEAX   6,X
1BAD 9F 42               STX    XRST
1BAF 9F 44               STX    XREND
1BB1 39                  RTS
*
* GET KNOWN DATA AREAS
*
1BB2 B6 CC22      GETDAT LDA    OUTSW      *SAVE TTY PARMS
1BB5 F6 CC1A             LDB    CURLN
1BB8 34 06               PSHS   D
1BBA 7C CC22             INC    OUTSW      *GO TO TERM
1BBD 8E 1C16             LDX    #MSG5
1BC0 BD C01E             JSR    PSTRNG
1BC3 9E 03               LDX    DATST
1BC5 9F 05               STX    DATEND
1BC7 86 3F        GETD1  LDA    #'?
1BC9 BD CD18             JSR    PUTCHR
1BCC BD C01B             JSR    INBUFF     *GET DATA
1BCF BD CD42             JSR    GETHEX     *GET 1ST ADDR (FROM)
1BD2 25 28               BCS    GETD2      *NOT HEX: EXIT
1BD4 109E 05             LDY    DATEND
1BD7 AF A4               STY    0,Y
1BD9 BD CD42             JSR    GETHEX     *2ND ADDR (TO)
1BDC 25 21               BCS    GETD2
1BDE 109E 05             LDY    DATEND
1BE1 31 24               LEAY   4,Y
1BE3 AF 3E               STY    -2,Y
1BE5 EC 3E               LDD    -2,Y
1BE7 10A3 3C             CMPD   -4,Y
1BEA 25 08               BCS    GETD3      *NOT RIGHT!
1BEC 109F 05             STY    DATEND
1BEF BD CD24             JSR    PCRLF
1BF2 20 D3               BRA    GETD1
1BF4 BD CD24      GETD3  JSR    PCRLF
1BF7 8E 1C56             LDX    #MSG6
1BFA BD C01E             JSR    PSTRNG
1BFD 20 C8               BRA    GETD1
1BFF 9E 05        GETD2  LDX    DATEND     *ADJUST OTHER POINTERS
1C01 9F 07               STX    TAGST
1C03 30 03               LEAX   3,X
1C05 9F 09               STX    TAGEND
1C07 30 03               LEAX   3,X
1C09 9F 0B               STX    TTGST
1C0B 9F 0D               STX    TTGEND
1C0D 35 06               PULS   D
1C0F B7 CC22             STA    OUTSW
1C12 F7 CC1A             STB    CURLN
1C15 39                  RTS
*
1C16 45 4E 54 45   MSG5   FCC   "ENTER KNOWN DATA AREAS "
1C1A 52 20 4B 4E
1C1E 4F 57 4E 20
1C22 44 41 54 41
1C26 20 41 52 45
1C2A 41 53 20
1C2D 28 4F 52 20          FCC   "(OR 'END')"
1C31 27 45 4E 44
```

```
1C35 27 29                   FCB    $0,$A,0,0,0,0
1C37 00 0A 00 00
1C3B 00 00
1C3D 46 52 4F 4D            FCC    "FROM,TO  (INCLUSIVE)"
1C41 2C 54 4F 20
1C45 20 20 2B 49
1C49 4E 43 4C 55
1C4D 53 49 56 45
1C51 29
1C52 00 0A 0A 04            FDB    $0A,$A04
1C56 07              MSG6    FCB    7            *RING BELL
1C57 4E 4F 21 20            FCC    "NO!  1ST ADDR > 2ND ADDR!"
1C5B 20 31 53 54
1C5F 20 41 44 44
1C63 52 20 3E 20
1C67 32 4E 44 20
1C6B 41 44 44 52
1C6F 21
1C70 00 0A 00 00            FCB    $0,$A,0,0,0,0,4
1C74 00 00 04
         1C77  PGMEND  EQU    *            *TAG TABLE OVERLAYS

                           *DOES PRELIMINARY SETUP OF FILES,
                           *ETC.  IT IS OVERLAID BY THE TAG
                           *TABLE ONCE IT HAS DONE ITS THING.
                           *
1C77 8E  0119    PRELIM  LDX    #FCBIN        *POINT TO CONTROL BLOCK
1C7A 8D  CD20            JSR    GETFIL        *GET FILE SPEC
1C7D 1025 00CE           LBCS   PRE3          *ERROR DETECTED
1C81 4F                  CLRA                 *.BIN DEFAULT
1C82 BD  C033            JSR    SETEXT        *SET EXTENSION
1C85 86  01              LDA    #1
1C87 A7  84              STA    FUNC,X        *OPEN FOR READ
1C89 BD  D406            JSR    FMS           *CALL FILE MGMT SYSTEM
1C8C 1026 00BF           LBNE   PRE3          *ERROR
1C90 BD  D406            JSR    FMS           *ONE READ KEEPS
1C93 1026 D0B9           LBNE   PRE3          * FLEX HAPPY
1C97 EC  88 11           LDD    STRSEC,X
1C9A ED  88 1E           STD    NEXT,X        *ALLOW INITIAL REWIND
1C9E 8E  0259            LDX    #FCBOUT       *POINT TO OUTPUT BLOCK
1CA0 BD  C020            JSR    GETFIL
1CA3 24  12              BCC    PRE1          *GOOD NAME; ELSE
1CA5 10B 8E 011C          LDY    #FCBIN+DRV    *TRANSFER NAME
1CA9 30  03              LEAX   DRV,X
1CAB C6  09              LDB    #9
1CAD A6  A0      PRE2    LDA    0,Y+
1CAF A7  80              STA    0,X+
1CB1 5A                  DECB
1CB2 26  F9              BNE    PRE2
1CB4 8E  0259            LDX    #FCBOUT
1CB7 86  44      PRE1    LDA    #'D           *DSA EXTENSION
1CB9 A7  0C              STA    DRV+9,X
1CBB 86  53              LDA    #'S
1CBD A7  00              STA    DRV+10,X
1CBF 86  41              LDA    #'A
1CC1 A7  0E              STA    DRV+11,X
1CC3 86  02      PRE10   LDA    #2
1CC5 A7  84              STA    FUNC,X        *OPEN FOR WRITE
1CC7 BD  D406            JSR    FMS
1CCA 27  1D              BEQ    PRE9
1CCC A6  01              LDA    STAT,X
1CCE 81  03              CMPA   #3
1CD0 26  7D              BNE    PRE3          *ERROR
1CD2 A6  04              LDA    DRV+1,X
1CD4 A7  9F 0009         STA    [TAGEND]
1CD8 86  0C              LDA    #12           *DELETE DUPLICATE
1CDA A7  84              STA    FUNC,X
1CDC BD  D406            JSR    FMS
1CDF 26  6E              BNE    PRE3          *ERROR
1CE1 A6  9F 0009         LDA    [TAGEND]
1CE5 A7  04              STA    DRV+1,X       *RESTORE NAME
1CE7 20  8A              BRA    PRE10
1CE9 6F  88 30   PRE9    CLR    COMP,X        *COMPRESS SPACES
1CEC 8E  011D            LDX    #FCBIN+DRV+1
1CEF 108E 00E2           LDY    #HFILE
1CF3 C6  08              LDB    #8
1CF5 17  FE7B            LBSR   MOVENM        *MOVE NAME TO HEADING
1CF8 8E  0250            LDX    #FCBOUT+DRV+1
1CFB 108E 00FC           LDY    #HDFILE
1CFF C6  08              LDB    #8
1D01 17  FE6F            LBSR   MOVENM
1D04 17  F343            LBSR   PHEAD
1D07 8E  CC14            LDX    #LNBFPT       *BACK POINTER UP
1D0A 30  18              LEAX   -5,X
1D0C 8F  CC14            STX    LNBFPT
1D0F BD  CD27    PRE4    JSR    NXTCH         *GET NEXT CHAR
1D12 81  0D              CMPA   #$0D
1D14 27  23              BEQ    PRE5          *C/R
1D16 81  CC02            CMPA   TTYEOL
1D19 27  1E              BEQ    PRE5          *END OF LINE
1D1B 81  2B              CMPA   #'+
1D1D 26  F0              BNE    PRE4
1D1F BD  CD27    PRE6    JSR    NXTCH         *CHECK FOR DEBUG
1D22 81  0D              CMPA   #$0D
1D24 27  13              BEQ    PRE5          *CR
1D26 81  CC02            CMPA   TTYEOL
1D29 27  0E              BEQ    PRE5
1D2B 81  44              CMPA   #'D
1D2D 26  02              BNE    PRE7          *DEBUG
1D2F 97  1B              STA    DEBUG
1D31 81  43      PRE7    CMPA   #'C
1D33 26  EA              BNE    PRE6
1D35 97  1D              STA    RRFLAG
1D37 20  E6              BRA    PRE6
1D39 B6  CC03    PRE5    LDA    DEPTH
1D3C 49                  STA    TTYDEP
```

```
1D3E FC  CD0F            LDD    OUTCH
1D41 1083 CD12           CMPD   OUTCH2
1D45 27  05              BEQ    PRE8          *CRT OUTPUT
1D47 96  00              LDA    PDEPTH
1D49 B7  CC03            STA    DEPTH         *66 LINES
1D4C 1C  FE      PRE8    CLC
1D4E 39                  RTS
1D4F BD  C03F    PRE3    JSR    RPTERR
1D52 1A  01              SEC
1D54 39                  RTS
1D55 57 49 4C 4C          FCC    "WILLIAM STOCK"
1D59 49 41 4D 20
1D5D 53 54 4F 43
1D61 4B
1D62 31 31 32 35          FCC    "1125 LOIS DRIVE"
1D66 20 4C 4F 49
1D6A 53 20 44 52
1D6E 49 56 45
1D71 43 49 4E 43          FCC    "CINCINNATI, OHIO 45237"
1D75 49 4E 4E 41
1D79 54 49 2C 20
1D7D 4F 48 49 4F
1D81 20 34 35 32
1D85 33 37
1D87 35 31 33 2D          FCC    "513-641-0101"
1D88 36 34 31 2D
1D8F 30 31 38 31

         END    START
```

1 ERRORIS! DETECTED

SYMBOL TABLE:

ABORTF	001C	BADOP	0023	BINO	D01E	BY1CNT	002F	CLOSE	0406
CLRDLN	1B5F	CLRFC1	1B66	CLRPL1	100C	CLRPLN	1005	CRDCNT	002E
CRDTBL	12B3	CNTR	0011	CODFLG	0021	COMP	003B	CONT1	03DA
CONT2	03F4	CONT3	0403	CONT4	0303	CURDLN	CC1A	CURTAG	0039
DADDR	009A	DATA	0040	DATEND	0005	DATST	0003	DC01	09AB
DC02	09CB	DC02A	0903	DC02B	09DA	DC03	09DF	DC03A	0A12
DC03B	0A28	DC03C	0A10	DC03D	09E7	DC03RT	0A4C	DC03CMD	D998
DEBUG	001B	DEPTH	CC03	DIEX	009F	DIDX	0022	DIR	0BF3
DIR1	0C08	DLINE	009A	DO10	0A4D	DO10A	0A79	DO10C	0AA2
DO11	0AAC	DO11A	0AA8	DO11B	0A91	DOORG	0F82	DOORG1	0F88
DDFCD	0083	DOPMD	0089	DPFLAG	0012	DPMSG	121C	DPMSG1	1275
DPMSG2	1230	DPWARN	0E47	DRV	0003	DTAG	00AD	DUMP	1AFC
DUMP1	1AFE	DUMP2	1B00	DUMP3	1B00	DUMP4	1B34		
ELVCMD	1AB0	ENDS	1271	EQUS	1267	EXIT	0C10	FCBIN	0119
FCBOUT	0259	FCBS	126A	FCCONT	0015	FCD.DC	0016	FCCPR1	1B4B
FCCPR2	1B5E	FCCPR3	1B5A	FCCPRT	1B38	FCCS	1274	FIND	003E
FIND1	0058	FIND2	0089	FIND3	0FA5	FINDT1	0FBB	FINDT2	0F9A
FINDT3	0FA5	FINDT4	0FA9	FINDT5	0FAB	FINDTG	0F80	FIN1	0434
FIN1A	0425	FLEX	C000	FMS	0406	FMSCLS	0403	FOOT1	108A
FUNC	0000	GOADDR	0035	GOCNTR	0039	GDTRK	0037		
GET1	0E2E	GET2	0E24	GETCHR	CD15	GETD1	1BC7	GETD2	1BFF
GETD3	1BF4	GETDAT	1BB2	GETFIL	CD20	GETHEX	CD42	GETRET	0E46
HEAD	0003	HEAD4	0099	HEXAS1	0E63	HEXAS2	0E67	HEXAS3	0E71
HEXASC	0E5B	IEIXFMT	0031	HFILE	00E2	HDFILE	00FC	HPAGE	0112
HPGND	0117	IDX	0AAB	IDX1	0AC1	IDX10	0B4D	IDX11	0BAD
IDX12	0BAF	IDX13	0B72	IDX14	0874	IDX15	0B6A	IDX16	0BAA
IDX17	0897	IDX18	0BC7	IDX19	0877	IDX2	0ACC	IDX20	0881
IDX20A	0888	IDX20B	0897	IDX3	0ADE	IDX4	0AEB	IDX5	0AF8
IDX6	0AF0	IDX8	0B42	IDX9	0B4A	IDXR	0B4C	IDXRE1	0BEB
IDXREG	0B06	IMM	0C35	IMMO	CD18	INH	0CS5		
INH1	0C90	INH10	0CF8	INH11	0D01	INH12	0D0E	INH13	0D14
INH14	0C90	INH15	0E52	INH16	0CA9	INH17	0CB2	INH18	0CC1
INH19	0CC7	INH2	0C9A	INH20	0CCD	INH21	0CDC	INH22	0CEB
INH3	0C99	INH4	0C53	INH4B	0C65	INH5	0C96	INH6	0C8C
INH7	0CEE	INH9	0D06	LASTD	0025	LINENO	0013	LK10E	12AA
LOXREG	0B06	LK11E	1283	LNBFPT	CC14	LOOK10	1284	LSTBLK	0027
MEMEAD	CC2B	MODE	0030	MOVEN1	1882	MOVEN2	1B79	MOVENM	1B73
MRIDX	0041	MSEC	003F	MSG2	11C7	MSG4	11E4	MSG5	1C16
MSG6	1C56	NAMS	125D	NEXT	D01E	NEXT1	0F66	NEXTT1	0F6A
NEXTT2	0F7D	NONCTG	0022	NITOP	0019	OPTS	1278		
ORGS	1260	OUTADR	CD45	OUTCH	CD0F	OUTCH2	CD12	OUTHEX	CD3C
OUTSW	CC22	P1A	0481	P1B	04SD	P1C	0489	P1D	04A0
P1E	04BE	P1F	0479	P1G	048C	P1H	04C2	P1I	04C5
P1J	04C9	P1K	04BF	P1L	04DE	P2A	0589	P2B	04EE
P2C	0519	P2D	0529	P2E	0552	P2E1	0556	P2F	0562
P2F1	056C	P2F2	057F	P2G	059A	P2TAG	003D	P3A	060A
P3C	06A5	P30	05CA	P3E	0402	P3G	08F3		
P3H	05E8	P4A	0627	P4AA	08C0	P4B	0637	P4C	0630
P4C1	0653	P4D	0671	P4E	0688	P4END	0BD5	P4END1	0BE4
P4END2	08F3	P4END3	0919	P4F	0925	P4G	069E		
P4H	06DA	P4I	06ED	P4J	06F1	P4K	0700	P4K1	0720
P4L	074A	P4M	0760	P4M1	0773	P4M2	0780	P4M3	0704
P4M4	0789	P4M5	07CD	P4M6	0798	P4N	07D8	P4O	07FF
P4O1	0800	P4P	0817	P4Q	086B	P4R	0872	P4S	087A
P4T	087F	P4U	0889	P4V	0892	P4W	08A6		
P4X	08AD	P4Y	0886	P4Z	088E	PADDR	0050	PAGE	107B
PAGE1	1087	PASC11	0088	PASS1	043A	PASS2	04E3		
PASS4	0618	PCOM	008E	PCRLF	CD24	PDEPTH	0000	PGMEND	1C77
PHEAD	104A	PHEX	0055	PLINE	004A	PLNO	004A	POPCD	0069
POPND	006F	PRE1	1CB7	PRE10	1CC3	PRE2	1CAD	PRE3	104F
PRE4	1D0F	PRE5	1D39	PRE6	101F	PRE7	1D31	PRE8	104C
PRE9	1CE9	PRELIM	1C77	PRINT	1012	PRINT3	03A3	PSPL	120C
PSTRNG	CD1E	PTAG	0063	PUTCHR	CD18	READ	0070	READ1	0DC0
READ2	0D00	READ3	0D0C	READ4	0DE4	READ5	0DEE	READ6	0093
READ7	0DF3	READ8	0DEC	READ9	0085	READR	00FB	READR1	0E13
READR2	0E1F	READR3	0E1C	REL	0C1B	REL1	0C2B	REL2	0C2D
REPAS1	0977	REPAS2	0977	REPAS5	043A	REPAS6	0960	REPASS	0928
REWIN1	0F63	REWIN2	0F2E	REWIND	0F16	RIDX	0023	RIP1	0ECC
RIP3	0EE6	RIP5	0EF2	RIP6	0EF8	RIP8	0ED9	RIP9	0F00
RIPPLE	0EC7	RRFLAG	001D	RRIDX	003F	RPTERR	C03F		
START	0399	START1	03A3	STAT	0001	STRSEC	0011	TAGBLD	0032
TAGCL1	1B8E	TAGCL2	1BA1	TAGCL3	1BA5	TAGCLN	1B8A	TAGEND	0009
TAGST	0007	TENCMD	1983	TFIG	11FB	TRIP4	0E97	TRIP5	0E8F

```
TRIPPL 0E72    TTGEND 0000    TTGST  0008    TTYDEP 0049    TTYEOL CC02
WARNS  C003    WRTDS1 0FDC    WRTDS2 0FF1    WRTDS3 0FFF    WRTDS4 1004
WRTDS5 0FE4    WRTOSC 0F05    WRTERM 08E0    XFER   0024    XFRADD 000F
XREND  0044    XRFI10 10F8    XRFI11 1118    XRFIN1 108B    XRFIN2 10C7
XRFIN3 10B3    XRFIN4 100B    XRFIN6 10E7    XRFIN7 10EB    XRFIN8 10FC
XRFIN9 1104    XRFLAG 001D    XRPLN  1193    XRPLN1 11AA    XRPLN2 11B6
XRPLN4 11B9    XRPRN1 1130    XRPRN2 1170    XRPRN3 1181    XRPRN4 1189
XRPRN5 119F    XRPRN6 112E    XRPRN7 1145    XRPRN8 1126    XRSOR1 10AF
XRSOR9 1124    CRSORT 109E    WRST   0042    XRTAG  0046    ZAPFLG 0020
ZAPT   0E99    ZAPT2  0EAC    ZAPT3  0EB0    ZAPT4  0EAE    ZAPT5  0BC2
ZAPT6  0BC3    ZSUPP  1091    ZSUPP1 1090    ZZZZY  1983    ZZZZZ  1283
```

BIT BUCKET

SWTPc - Prospering Pioneer

Microcomputers. See that word and you think of those ubiquitous marvels of technology that represent the miracle of modern electronics in the home and workplace. With the variety of machines available today, it is difficult to visualize a world that does not include these machines. But there was a time when there were no microcomputers on the market at all. In the early 1970's, if computing was done, it was done on mainframes or minicomputers. That is, until 1975...

Southwest Technical Products Corporation, San Antonio, Texas, began manufacturing microcomputer systems that year with kit systems based on the Motorola 6800. With RAM capacity of 32K, these systems provided hobbyists with the ability to have computer systems of their own, with considerable power, at a reasonable price. Running an 8K, cassette-loaded BASIC, these early systems brought computers into the home for the first time.

BEGINNINGS   1975 was the beginning of SWTPc's involvement with selling microcomputers, but the company had begun some eleven years earlier with kit electronics produced in the garage of entrepreneur Daniel Meyer. Electronics hobbyists will remember the product line of amplifiers, graphic equalizers, color organs, digital meters, strobe lights, ultrasonic burglar alarms, timers, counting units, the Beachcomber metal detector and the Theremin, an innovative electronic musical instrument. It was as a natural extension of this varied product line that Southwest took its first steps into microcomputers.

Microprocessor - based machines were introduced at about the same time by SWTPc, MITS (with the Altair 8800) and IMS Associates (with the IMSAI 8080). For the 6800 computer, Southwest invented the SS-50 bus, with 7 slots for processor, memory and controllers, and including a separate 30-pin I/O bus with 8 slots on the motherboard. The system ran at a clock speed of 1.0 MHz. Auxiliary storage was accomplished on this early system through audio cassette player/recorder.

DISK OPERATING SYSTEM   The first disk operating system for the 6800 computer was introduced to the micro world in 1977. Running on floppys, FLEX was developed by Technical Systems Consultants, now of Chapel Hill, North Carolina. Designed to be powerful and user-friendly, FLEX became the defacto standard operating system for the 6800.

6809 COMPUTERS   In 1978, Southwest introduced the /09 computer based on the new Motorola 6809 microprocessor. This improved processor gave the system user a greatly enlarged instruction set, as compared with the 6800, and provided the programmer with four pointer registers and a program counter... each of 16 bits. Of the Motorola models, Southwest chose to use the 68B09,

for 2.0 MHz operation. For users wishing to upgrade their 6800 systems, Southwest provided update documentation to accomodate the new processor.

MULTI-USER SYSTEMS   With the power of the 6809 processor now available, the decision was made to implement a multi-user operating system for the SWTPc computer. After close examination of the available OS designs, SWTPc chose UniFLEX*... a multi-user

OS closely modeled on the Bell Labs' UNIX** system. Also implemented by TSC, UniFLEX incorporated some of the user - friendly attributes of FLEX.

S/09 AND S+ SYSTEMS   The multi-user system, dubbed the S/09, was offered for the first time in 1979. This system provided features previously expected only from minicomputers and mainframes... Multi-terminal (up to 12) operation, Dynamic Memory Allocation and Direct Memory Access. Furthermore, the S/09 system was configurable to include "Winchester" hard disk drive technology. With the addition of a hard disk, the S/09 achieved full status as a new, hybrid computer classification... the MICRO-MINI.

The state-of-the-art in SWTPc micro-minis is the S+ system. Designed for office, school lab and industrial data processing, the S+ provides for operation of up to 32 terminals through the use of efficient data handling, larger memory capability and peripheral processor interface. Running in a supervisor and user state, the S+ CPU monitors system functions to prevent user - generated system crashes. The S+ can also run the MUMPS Operating system with up to 16 Terminals.

Both the S+ and the S/09 support 14" and 5-1/4" Winchester disk drives, logical tape backup, and up to 5Mbytes of floppy disk storage. A variety of letter-quality and dot-matrix printers are available for use with either system.

X12+ AND BEYOND...   Southwest Technical Products continues to develop and manufacture microcomputer systems to meet the increasing data processing needs of the marketplace.

The new X12+ is a desk-top, 256K computer integrated with a SWTPc-manufactured intelligent terminal. Running UniFLEX, the system features Mini-Winchester auxiliary storage, data communications, optional hardware floating point computation and supports 2 additional work stations.

Other hardware under development at the SWTPc 5-building facility in San Antonio includes plug-in 68000 processor, floating point processor, virtual system processor, 1 Mbyte memory board and networking interfaces.

SUMMARY   In the fast-paced and volatile world of microcomputer manufacturing, it takes innovative engineering and aggressive pricing to stay in competition. Since the very birth of the micro, Southwest Technical Products has provided this kind of leadership in design and production of computer systems. Southwest Technical Products is the Prospering Pioneer of microcomputers.

* UniFLEX and is a trademark of Technical Systems Consultants ** UNIX is a trademark of Bell Labs.

The following is a description of the X12+ system from SWTPc:

X-12+ Multi-user computer system

Concept:

The X-12+ system is designed as a stand-alone 256K computer capable of supporting one to three users simultaneously. The system incorporates as standard features many capabilities that micro users are coming to expect from their systems--hard disk capacity; multi-user, multi-tasking, multi-processing capability; expandability to 1024K RAM; variety of available programming languages and proven operating systems.

The Hardware:

The X-12+ CPU resides inside the SWTPc X12 terminal, with a 12 inch (diagonal) CRT and a detached 91-key keyboard. Standard auxiliary storage sits alongside the CRT in an attractive "Mailbox Memory" unit that contains a high speed 20M-byte mini Winchester and a 1.25M-byte mini floppy drive.

System architecture is built around the Motorola 68809 processor, and includes extended addressing, optional TMS 320 32-bit processor for floating point work (transparent to the user), 256K of dynamic RAM, buffered disk I/O to reduce redundant disk reads, two RS-232 ports for additional terminals, and one parallel port for future communications with loop network. The X-12+ communicates with it's own CRT in parallel for ultra fast output display. One RS-232 printer port and one 'Centronics Parallel' printer port are included as standard. An additional RS-232 serial port is included to allow the X-12+ to act as a terminal on a remote system.

CRT Features

The X-12+ display is controlled by a separate 6809 processor, and an on-board vocabulary of 255 words may be spoken by the voice processor installed as standard equipment. User-programmable character sets, multiple screen formats, 15 programmable function keys, tone generator, reverse fielding, under and over-lining, blinking characters, field protection, multiple screen formats, display status line, graphics and ergonomic design are additional features of the unit.

Software:

The standard X-12+ will run the powerful *UniFLEX Operating System from Technical Systems Consultants. UniFLEX is optimized for the 6809, and provides the same file structure and 'shell' facility that is available with **UNIX. UniFLEX dynamically allocates up to 64K of memory for each running task in 4K increments, and supports BASIC, FORTRAN, Pascal, 'C', COBOL, a relocating assembler and Pilot. Input/Output redirection, piping, random and sequential files and virtual array capability provide for the complete range of file access needs.

As an additional option, the X-12+ will be configurable to run the single-user FLEX+ operating system, with dual-floppy operation.

Special Feature:

The X-12+ has capability to run in Local and Remote modes. The unit can function as an intelligent terminal on another system while two other terminals attached to it are using the local system resources. Future development will include synchronous loop network capability for up to 255 X-12+ units, each with up to 2 additional workstations.

Pricing: The X-12+ multi-user configuration of CPU, 256K RAM, CRT, detached Keyboard, Voice and

Sound synthesizers, three parallel ports, four serial ports, 1.25M floppy, 20M mini- Winchester and UniFLEX Operating System ... $6,595.

Single-user configuration with dual 1.25M floppies, FLEX+ Operating system, full CRT features and BASIC... $4,495.

*UniFLEX is a trademark of Technical Systems Consultants, Inc.
**UNIX is a trademark of Bell Laboratories.

- - -

Dear Sir:

I have just finished reading the June issue. It was great. It looks like the 68000 (or at least the 68008) has arrived on the SS-50 bus with a vengence. The Helix offer in June and the rumored Smoke Signal offer in July look like excellent ways to get going quickly with the 68000 and OS9/68k's UNIX clone. Please keep up the 68000 news. It looks as if that is where we will all eventually be going.

I was also pleased to see that Southeast Media is now offering John Alford's SCREDITOR III word processor. It is a great program which until last month was missing from Southeast's product list.

My wife and I have been happily using SCREDITOR for our law practice for almost two years. We started with the 6800 version for FLEX 2 and now have moved up to the FLEX 9 version. (I also have the OS9 version.) All versions use the same commands and work the same from the user's standpoint. They provide a good solid what-you-see-it-is-what-you-get type word processor with all of the usual features. We usually use SCREDITOR as a screen editor with word wrap at the end of a line, but it can also be used for multiple column documents or as a line editor. The only item which SCREDITOR does not have and would be useful to us is the ability to handle footnotes. (If you have ever read a legal brief, you know that attorneys are fond of footnotes.)

The configuration programs which SCREDITOR comes with allow it to be used with almost any type of terminal or printer. We use it with a Freedom 100 and H-19 terminals. The terminal configuration program lets us use the function and word processing keys on our terminals instead of having to use predefined control codes. This saves us a keystroke every time we use one of the single key functions.

We use two different printers with SCREDITOR. The printer configuration program both use the same text files. When printing, SCREDITOR takes care of sending the right code for the printer which is being used.

I hope you keep up the good work publishing and selling 68XX articles and software.

Sincerely

Kenneth Drexler

Mr. Larry Williams
'68' Micro Journal
5900 Cassandra Smith Road
Hixson, Tennessee 37343

Larry,

After reading the "Where's the 68000?" article last month I decided it was time to sit down and write one of those "Reader Response" letters! I feel that the readers should be aware of one area where there is a tremendous amount of 68000 activity.

We here at Federal Express have become involved with what we feel is the optimum solution to microsystems design problems - VME / 68000. VME stands for "Versa-Module European" and is a standardized Bus structure and hardware configuration.

There were three major contributors to the specification.... Motorola, MOSTEK, and Signetics (Phillips.) The VME specification has its' roots in what is commonly refered to as "Euro-card." One of the more noticeable differences between standard Euro-card and VME (as specified by Motorola, et al.) is the physical size, 220mm depth for Euro-card vs 160mm for VME. The VME "form factor" was more appealing due to compactness and availibilty.

Some of the reasons that we have for choosing the VME / 68000 combination are:

- Broad base of product support...,both domestic and international.
- Readily available "state-of-the-industry" technology including --
    - Widely accepted m68000 family processor architecture
    - Large selection of peripheral device support modules
    - Fast, flexible memory options such as CMOS Static, high-density Dynamic and "Bubble"
- The availability of "High Level" operating systems environments and programming aids.
- The trend toward high quality, consistent documentation across a large number of VME product manufacturers.
- The willingness for the participating manufactures to place all required information into the hands of the system integrators and end-users.

We are very comfortable with the direction we have chosen. A tremendous amount of effort was put into the process. The results have been both successful and rewarding. Finally, we are looking forward to a long and productive involvement with VME / 68000 based products.

Kenneth R. Lewis
MICROSYSTEMS

MICRO-MATION INCORPORATED

801 Duchess Road
Bothell, WA 98012
(206) 481-2812

Computer Publishing Center
68 Micro Journal
P.O. Box 849
Hixson, TN 37343

attn: Don Williams & staff

Dear Don,

I haven't had time to write many letters the past couple of years, but I still find time to read your magazine. I've looked at a couple of the competitors but they don't seem to even finish out my years subscription before disappearing. I've recently solved a small problem that has been nagging me for a couple of years on Flex based systems. I've owned a couple of systems that provide a ready input to the floppy disk controller, either from the drives themselves or from an index pulse detector, with the idea that if a drive isn't ready then trying to access it will result in an error message rather than a hung system. Somehow it never seemed to work quite right and strange things seemed to happen, such as getting a "NOT FOUND" message when trying to use a system utility that was definitely present. I don't want to come out and say that there is a bug, either in Flex or in the documentation, because I might be the only one that has had problems.

First, let me state that I have written my own disk drivers, so the problem might be mine alone. However, I should also state that these drivers are similar to and patterned after those suggested by TSC in the Flex Adaptation Manual for General Flex. Now that I've included all these disclaimers, let me tell you how the problem occurs, and one possible solution. The Western Digital series of floppy disk controller chips (1771,1971,2791) have a ready input which can be used to detect if the drive is ready for access (motor on, speed up, disk in place, etc.) What sometimes happens is that the disk operating system (DOS) issues a read sector command (say for the directory) and the controller attempts to read the sector called for; however, if the drive isn't ready the controller chip will immediately abort the operation and return with the "not ready" flag set. If the READ sector subroutine doesn't test this bit from the controller, and the example provided by TSC doesn't, then the DOS thinks that a valid read has occurred without any data whatsoever being read from the disk. NOW THAT CAN CAUSE SOME STRANGE RESULTS !!

Two possible fixes suggest themselves: one is to add the ready bit to the read sector error test; the other is to perform a drive ready test before trying to read the sector. The latter is what I chose to do, adding a 1/2 second delay & retest if not ready. The same addition was made to the write sector routine.

very truly yours,

Joe Wicklund

651 Pascal Court
Ames, Iowa 50010
June 3, 1984

Computer Publishing Center
68 MICRO JOURNAL
5900 Cassandra Smith Rd.
P.O. Box 849
Hixson, TN 37343

Dear Sirs:

In response to the letter of Mr. LeFarr Stuart which appeared in your June issue, I would like to ask Mr. Stuart, why, if he truly believes that each computer system has its good and bad points, does he make the totally negative statement calling the Color Computer a "useless toy" inferior to the Commodore 64"?

Well, I am the owner of a 64K Color Computer running OS-9 and although it is not my idea of the ideal computer system it is far from useless. I have had my complaints with the machine, the limited memory, the bad keyboard and, yes, the useless display but have solved many of these problems to an extent myself and it seems that Tandy too is solving some of them. Aside from that the CoCo has several very good points. For starters, where else can you get a 6809 based machine

running OS-9 or FLEX for under $1000? As a computer science major at Iowa State University I have found my CoCo a very valuable computer. For one thing it has given me an opportunity to use and study an advanced UNIX-like operating system on my "toy" computer. Secondly, it has given me a chance to program in assembler and high level languages at home, not just in classwork. For example, the C language is not currently taught to undergraduates at ISU but with my CoCo and Microware's C compiler I now have a chance to learn C at home and with the full compiler I can write useful, transportable code which I could not do with other micros and their Small C's. Aside from C, I can program in BASIC09 which I vastly prefer over Microsoft BASIC or any of the other BASIC dialects on the market, once you are used to modular programming it is hard to go back to using GOTO's and GOSUB's. Within a few months Microware's Pascal should also be on the market giving another full Pascal compiler for the CoCo, one exists for RS-DOS and another for FLEX already. What other low cost micro on the market has all these full languages available to it and under several different operating systems?

Thus I see the Color Computer as being far from a "useless toy" and I also see it as far superior to the Commodore 64 and all the other low cost micros on the market. My views are not singular either, the CoCo has a large following as can be seen by the large number of clubs, magazines and software suppliers who support it. I know alot of the software is games but there is getting to be more serious software out now too from FHL, Computerware, JBM, SouthEast Media and Tandy's Microware's releases. Besides it is nice to sit back and play a game now and then. If I was running a business it would be nice to have a S-50 bus 6809 or 68000 machine but for me at home the CoCo is just right and has been a very useful "toy".

Sincerely,

Tim Harris
Tim Harris

A while back I needed a terminal for my "Mikbug Board" (G-Job) to be able to use the thing at home. I was always using a terminal at work. Now with a little work I have a "semi-intelligent" terminal. The terminal uses the Motorola family of chips, ie a 6802 processor, 6847 video generator, and 6821 for input/output. Since I was using the 6847 in something like "TVBUG" I had to wait for some kind of sync pulse to load or read the display ram. Now the 6802 is in a Interleaved Direct Memory Access mode. The 6802 is dedicated to the 6847 in a terminal mode. There used to be snow when the 6802 talked to the 6847, now there is no, I repeat no snow when display ram is accessed! This is done by syncing the 6802 to the 6847 at power-up with a either-edge triggered device. Together with a 8 bit latch, the 6802 and 6847 share the same memory and they do not know about each other (kind of like the Radio Shack 6883 setup). The reason for this modification is for the 8 point move, draw, box, rectangle and crosshair routines. Originally the routines took a lot of time to draw any line because of the waiting for the sync pulse to do memory accesses. Finally the full speed of these routines can be used to an advantage. Yes the processor runs at color-burst crystal speed, but I can tell you that the graphics routines are quite fast. Also the "TVBUG" can be modified to accept these routines (and hardware mod) without having to use the handshaking for blanking sync thereby increasing throughput and eliminating any snow on the screen in any graphics mode. So, now I have a semi intelligent terminal that runs at processor speed as the input/output is 8 bit parallel handshaking. The firm ware is just under 2K (hex) bytes of data, including the graphics routines. If you would like the schematics and firmware, please contact me about these items. I will be glad to make these public.

After this terminal was built, I wanted to run 6800 type programs a little faster so I upped my 6800 to a 6809. Currently I am running Santa Barbara Tiny Basic with extensions (poke, peek, wait and various terminal oriented functions).

All in all I have a delightful combination to use. This is only the beginning of course, there is always FLEX to add in someday.

Paul T. Barton
1412 N.E. 46th. Ave.
Portland, Oregon
97213

Analog Micro Systems
5660 Valmont Road
Boulder, Colorado 80301
(303) 444-6809

January 1984

V1.9

News Release

Robot-1

With the advent of large scale integrated circuitry (LSI), the availability of powerful home personal computers has become a reality. This same technology has also shown up in industry to further automate dangerous or tedious and precision assembly procedures in mass production lines around the world.

Now, for the first time in history the availability of this technology has made possible the introduction of low cost home personal robotics and low cost industrial robotic systems. A vast interest in artificial intelligence and robotics has arisen due to the availability of the small powerful computer system that makes intelligent robot systems possible.

As an entrance into the field of robotics Analog Micro Systems is offering a complete line of computer controlled robotics for entertainment, education, and small industry. The first product to be released for national sale is the "Robot-1" computer servo controlled robot arm. Two versions of this robot arm are now being offered on the general market. One version is a plug in compatible output device for the Radio Shack Color Computer, the "Robot-1" is controlled by either keyboard or joystick inputs to the color computer. The operator can put the computer in a learn mode and operate the robot arm to perform a given task. After the operator has guided the Robot-1 through the various movements and functions, the operator may then instruct the computer to remember and repeat the sequence of movements and functions any number of times. The movement sequences may also be saved on tape or disk for later use. The Robot-1C comes complete with all software and includes a power supply, a six channel servo controller, all cables and a Robot-1. The Robot-1C is priced at $395.00 complete.

The next version of Robot-1 comes with different interface electronics in order to function on a larger computer system which like the Color Computer uses the 6809 microprocessor. This will allow Color Computer users to upgrade their applications to multi robot systems while using the same software that they developed for the color computer. This microcomputer like system is commonly known as the SS-50 bus. The 6809-1S uses a sixteen address thirty pin input-output connector on the SS-50 bus to control a six axis servo controller and power supply interface card. The Robot-1 takes advantage of the larger computer bus by allowing up to eight robot arms to run interactively and simultaneously using the AMS multi robot arm software. All movement sequences may be saved in memory or on disk to be retrieved later repeating the multi interactive robot arm movement sequences. Source code is provided with all robot software to enhance the ease of research and experimentation in the field of robotics.

The techniques that are learned from using Robot-1 may be directly transferred to the use of Robot-2 and Robot-3 industrial work robot arms as the software techniques, the control techniques, and the interface hardware are identical. Robot-1 is aimed at robotic entertainment, research, and education. Robot-2 is useful for small industrial assembly such as electronic circuit boards. Robot-3 is a larger version used for medium duty operations such as chassis assembly, painting operations, or the handling of dangerous materials. All three robot arms plug into the same interface electronics allowing low cost users to to industrial applications. Additional software will be supplied with each robot arm.

A number of accessories shall be available for Robot-1 and it's successors. Software packages shall be available to move robot-1 from the input of AMS biofeedback equipment allowing certain brainwave patterns, muscle movements, and body functions to control the robot arm movements. These are available for the Analog Micro Systems model 8266 Electroencephalograph Brainwave Analyzer, the Model 8264 Biofeedback Precision Temperature Monitor, the Model 8262 Electromyograph, and the Model 8260 Dermograph. A low cost digital video TV camera shall be available for robotic sight and pattern recognition. An ultrasonic range finder shall be available for distance measuring. A mobile cart to sit the robot arm base into will give the robot arm mobility. Should cables to the robot arm be undesirable a radio link shall be available for remote control of the mobile based robot arm. Computer generated voice output along with sound recognition is available directly to the computer as well is over the radio link to the mobile robot system. A four joystick and switch interface is available for computers not having such inputs. The above accessories shall be available for SS-50 based computer systems.

The robotics systems outlined above are modular in nature and may be assembled in any number of possible configurations. For example, a remote radio controlled mobile robot with speech, sound recognition, ultra sonic ranging and detection, and robot vision may be assembled with the above modular components. The resulting system can be programmed in a high level computer language resulting in a superior artificial intelligence system with a minimum of human effort. The performance to cost ratio of the above system far exceeds anything that is available on today's market.

Crummy CoCo

Lane P. Lester, Ph.D.
Professor of Biology
Liberty Baptist College
Lynchburg, VA 24506

In his letter printed in the June issue of 68 Micro Journal, LaFarr Stuart calls the Color Computer a "useless toy", and says that "nobody with a grain of sense would every (sic) consider the Color Computer for anything serious". It's fortunate for me that I lack a grain of sense, because the following are some of the things I do with my "useless toy".

1. Word processing: Lecture notes, tests, correspondence, articles for magazines, and laboratory manuals.

2. List management: lists of several hundred 35mm slides, supplies to be ordered, addresses, and phone numbers are maintained. Selecting and sorting functions allow reporting in selected formats.

3. Scheduling: All appointments, lecture and test schedules, and special dates are kept in a single file which can be searched in order to print specialized schedules.

4. Grade maintenance: Multiple choice tests are graded and questions analyzed for quality. Test scores are stored and assignment scores are entered. Functions allow points to be converted to letter grades.

5. Income tax management: quarterly evaluations of tax liability minimize withholding and the chore at year's end. Multiple forms are provided.

6. Lecture graphics: certain topics in biology lend themselves to graphic presentation in color and with animation.

7. Simulations: My genetics students use a program with which each student simulates animal crosses. The offspring can be used in further crosses in order to determine the type of inheritance involved in the various traits.

No one claims that the CoCo is the equivalent of a Sime, but for $200 a beginner in personal computing can purchase a 64k 6809 machine with Extended BASIC, cassette interface, TV interface, RS-232 port, and two A/D converter ports. If his interest wanes, his doorstop hasn't cost him a fortune. If like mine his interest grows, he has a machine that can grow with him.

If Disk BASIC ceases to satisfy for whatever reason, there is FLEX ("bastardized" though it may be... LaFarr's term, not mine) and OS-9 (although its appropriateness on the CoCo can be questioned). These additional DOSes open great vistas of programming in additional languages (PL/9 is my current fascination). And expansion interfaces allow the use of the types of boards which SS-50 users enjoy: 80x25 video displays, serial and parallel ports, clock/calendars, static memory, and stereo music synthesis.

Ron Anderson says that the small size of the SS-50 software market may eventually kill the bus. The "useless toy" has introduced many thousands to the pleasure and power of 6809 computing. If the efforts of software producers in "getting it to go on the CoCo" (LaFarr) are any indication of the potential market, the Color Computer may postpone the death of the SS-50.

Dear Don,

Getting out of XBASIC

There's a much easier way:

```
29999 EXEC. "exec,flex.txt"
```

And "flex.txt" just reads "asn" or anything.
After executing "flex.txt", exec.cmd returns to
FLEX.

Yours sincerely

Hans-Josef Heck

Breslauerstr.25
5630 Remscheid
Western Germany

May 8, 1984
1201 Bradley Rd.
Lynden, WA 98264

"68" Micro Journal

Dir Sirs:

The folling program is an extension of the os-9 command, procs e. What this program does is take certain information from a procs e. Then it compiles this information into an easy to read format.

First it will take the uaer name from the proca, then it will look at what they are doing. After it has taken this information it will dump it onto the screen, giving the name of the user and what they are doing at the time you execute the program.

I suggest that this program be packed and put on the cmds directory so it can be executed from os-9.

Before you can run the program, you have to set up a data file on the sys directory. I have also written a program to do this. What it does is to take the user

number and name from the password word file and put into a file of its own.

This program makes it easier to monitor the activies of other users on the system, making it easier to maintain security (which by the way was what it was originally designed for).

Sincerely

Michael W Klein
Systems Manager
Lynden High School

```
PROCEDURE procsu_fancy
0000        REM •••••••••••••••••••••••••••••••••••••••••••
0029        REM •                                        •
0052        REM •  Security Program Designed and         •
0078        REM •  Written at Lynden High School by       •
00A4        REM •  Michael W. Klein on May 2, 1984.      •
00CD        REM •                                        •
00F6        REM •••••••••••••••••••••••••••••••••••••••••••
011F        DIM path:BYTE
0126        DIM line:STRING[80]
0132        DIM num,procs,proc(50):STRING
0146        DIM count,number(50):INTEGER
0156        SHELL "procs e )/h0/sys/proc_dat"
0173        OPEN =path,"/h0/sys/proc_dat":READ
018E        FOR i=1 TO 4
01A0          READ =path,line
01AA        NEXT i
01B5        count=0
01BC        WHILE NOT(EOF(=path)) DO
01C7          count=count+1
01D2          READ =path,line
01DC          num=MID$(line,10,4)
01E9          procs=MID$(line,43,16)
01F6          proc(count)=procs
0202          number(count)=VAL(num)
0210        ENDWHILE
0214        CLOSE =path
021A        SHELL "del /h0/sys/proc_dat"
0232        DIM name,password_number:STRING
023D        OPEN =path,"/h0/sys/user_no.":READ
0258        PRINT "Date:    "; DATE$
0265        PRINT "User Name","Process"
027C        PRINT "-----------------------------"
0290        PRINT
029F        WHILE NOT(EOF(=path)) DO
02AA          READ =path,name,password_number
02B8          FOR j=1 TO count
02CD            IF VAL(password_number)=number(j) THEN
02DE              PRINT name,proc(j)
02EB            ENDIF
02EC          NEXT j
02F8        ENDWHILE
02FC        CLOSE =path

PROCEDURE user_num_fancy
0000        DIM path,p:BYTE
000B        DIM line:STRING[80]
0017        DIM name,number:STRING
0022        OPEN =path,"password":READ
0035        CREATE =p,"user_no.":WRITE
0048        WHILE NOT(EOF(=path)) DO
0053          READ =path,line
005D          x=SUBSTR(",",line)
006A          name=LEFT$(line,x-1)
0078          line=RIGHT$(line,LEN(line)-x)
008E          x=SUBSTR(",",line)
0098          line=RIGHT$(line,LEN(line)-x)
00AE          z=SUBSTR(",",line)
00BE          number=LEFT$(line,z-1)
00CC          WRITE =p,name,number
00DA        ENDWHILE
00DE        CLOSE =path
00E4        CLOSE =p
```

HYPERDISK

```
OPT PAG
TTL HELI1 DISK SIMULATOR
PAG
* HYPERDISK -- IN MEMORY DISK SIMULATOR FOR H0L.I1 COMPUTER
*  UTILIZES EXPANDED MEMORY TO SIMULATE A DISK DRIVE

* COPYRIGHT 1982 COMPUTER SYSTEMS CENTER OF HAZELWOOD, INC.
```

```
* WHEN EXECUTED AS A COMMAND EXPANDED MEMORY IS SEARCHED
* OUT AND FORMATTED AS A DISK, DISK I/O CALLS ARE THEN
* INTERCEPTED AND ALL REFERENCES TO DISK 3 ARE DIRECTED
* TO THE SIMULATED DISK, ALL OTHERS ARE PASSED ON TO THE
* PHYSICAL DISK DRIVERS.

* METHOD:
* THE 'E' DAT REGISTER IS USED AS A WINDOW TO THE EXTENDED
* MEMORY.  THIS ASSURES THERE WILL NO CONFLICT WITH ANY
* SYSTEM REFERENCES SINCE 'E' IS NORMALLY RESERVED FOR I/O
* AND DURING DISK SIMULATION IT IS THE I/O.
* THE SIMULATED DISK IS 'FORMATTED' INTO 'TRACKS' OF 16
* 'SECTORS' WHICH IS EXACTLY 4096 BYTES, THE SIZE OF A DAT
* PAGE.  THE TRACK/SECTOR LINKS ARE SET UP SO THAT THE
* 'TRACK' IS THE ACTUAL VALUE TO STUFF INTO THE DAT AND THE
* 'SECTOR' IS THE HIGH ADDRESS BYTE OF THE BLOCK TO REFERENCE.
* THE 'TRACKS' ARE FORMATTED WITH NON-CONTIGUOUS LINKS IN ORDER
* TO SKIP OVER THE 'E' WINDOW ADDRESS AND THE UNMAPPABLE 'F'
* ADDRESSES.  THE 'SECTOR' ADDRESS IS ACTUALLY ONE MORE THAN
* THE ACTUAL MEMORY ADDRESS BYTE IN CASE SOME PROGRAM ASSUMES
* THAN SECTOR ADDRESSES CAN NEVER BE ZERO OR THAT A SECTOR LINK
* ADDRESS OF ZERO IS AS GOOD AS TRK/SEC OF ZERO TO INDICATE
* END OF FILE.
* THE ABSOLUTE DISK TRK/SEC OF 0003 (STR) AND 0005 (DIR START)
* ARE MAPPED INTO SIMULATED 0101 AND 0102. 'TRACKS' 01 AND 02
* ARE FORMATTED AS THE DIRECTORY GIVING 31 SECTORS WHICH IS
* APPROXIMATELY THE SAME RATIO AS ON ACTUAL DISKS.
  PAG

* SYSTEM EQUATES

WARMS EQU $CD03 RETURN TO SYSTEM
PSTRNG EQU $CD1E PRINT STRING
NXTCH EQU $CD27 SET NEXT CHAR
OUTDEC EQU $CD39 OUTPUT DECIMAL NUM
INDEC EQU $CD4B INPUT DECIMAL FROM INBUF
TTYEOL EQU $CC02 COMMAND SEPARATOR
LSTERM EQU $CC11 LAST TERMINATOR
DATE EQU $CC0E SYSTEM DATE
DSKVEC EQU $DE00 DISK VECTOR TABLE
LBFPTR EQU     $CC14 FLEX LINE BUFFER POINTER
OUTHEX EQU $CD3C   OUTPUT HEX NUMBER
PUTCHR EQU     $CD1B  PUT CHARACTER

* FIXED DISK TRK/SEC ADDRS

SIRSEC EQU $0003 SYSTEM INFORMATION RECORD
DIRSEC EQU $0005 DIRECTORY START

* HARDWARE REGISTERS

DAT EQU $FFFE DAT REGISTER USED AS WINDOW
WINDOW EQU $E000 BASE ADDR OF WINDOW REFERENCE
STDDAT EQU $FE 'STANDARD' DAT SETTING

* CHARACTER EQUATES

CR EQU $D CARRIAGE RETURN
EOL EQU 4 END OF LINE MARKER
PAG
  ORG $C100 RUN FORMATTER IN UTILITY AREA

* SIZE AND 'FORMAT' MEMORY

START LDA #3 SET DEFAULT DRIVE NUM
  STA DRVNUM
        LDD     #$10FF
        STD     STBLCK  SET DEFAULT START AND END BLOCKS
PARSE4  CLR     STFLAG  CLEAR 'START BLOCK PROCESSED' FLAG
        CLR     DONFLG  CLEAR 'COMMAND LINE PROCESSED' FLAG
PARSE2  JSR     GETNEX
PARSE1  TSTB
        BEQ     NOTNUM  GO IF NUMBER NOT FOUND
        CMPB    #2
        BEQ     TWODIG  GO IF TWO DIGIT NUMBER FOUND
        CMPB    #5
        BEQ     TWODIG  5 DIGIT PROCESSING SAME AS 2 DIGIT
        CMPB    #1
        LBNE    SYNERR  SYNTAX ERROR IF NUMBER OTHER THAN 1, 2, OR 5 DIGITS
        CMPA    #9
        LBHI    SYNERR  SYNTAX ERROR IF NUMBER >9
        STA     DRVNUM  STORE DRIVE NUMBER
```

```
PARSE3 JSR    GETHEX  GET NEXT ITEM
       CMPB   #1      DON'T ALLOW ANOTHER : DIGIT NUMBER
       LBEQ   SYNERR
       BRA    PARSE3  CONTINUE PARSE
NOTNUM LDA    TERMCH
       CMPA   #'-
       BEQ    DASH
       CMPA   #'*
       BEQ    OPTION
       CMPA   #CR
       LBEQ   ENDCMD
       CMPA   TTYEOL
       LBEQ   ENDCMD
       CMPA   #$20
       BEQ    PARSE2
       BRA    SYNERR
DASH   INC    STFLAG  SET 'START BLOCK PROCESSED' FLAG
       BRA    PARSE3  CONTINUE PARSE
TWODIG TST    STFLAG  PROCESSED START BLOCK YET?
       BNE    SETEBK  YES, SET END BLOCK
       INC    STFLAG  SET FLAG NOW
       STA    STBLCK  SET START BLOCK
       LDA    TERMCH  GET TERMINATING CHARACTER
       CMPA   #'-     BETTER BE DASH
       BNE    SYNERR  ELSE SYNTAX ERROR
       BRA    PARSE3  CONTINUE PARSE
SETEBK CMPA   STBLCK  MAKE SURE END>START
       BLO    SYNERR
       STA    ENDBLK
       LDA    TERMCH  SEE IF WE'RE DONE
       CMPA   #CR
       BEQ    ENDCMD
       CMPA   TTYEOL
       BEQ    ENDCMD
       CMPA   #$20    BETTER BE SPACE THEN
       BNE    SYNERR
       LDA    [LBFPTR] CHECK NEXT CHARACTER
       CMPA   #'*     OPTION?
       BNE    FORMAT  NO, MUST BE NEW DRIVE 0
       JSR    NXTCH   SKIP OVER *
OPTION JSR    NXTCH   GET OPTION
       PSHS   A       SAVE CHAR
       JSR    NXTCH
       CMPA   #CR
       BEQ    SETECM  SET END OF COMMAND FLAG IF CR
       CMPA   TTYEOL  ALSO IF TTYEOL
       BEQ    SETECM
DCONT  PULS   A
       CMPA   #'N
       LBEQ   NOFMT   DONT FORMAT MEMORY
       CMPA   #'n
       LBEQ   NOFMT
       CMPA   #'R
       LBEQ   REMOVE  REMOVE ALL SIMULATED DRIVES
       CMPA   #'r
       LBEQ   REMOVE
       CMPA   #'D
       LBEQ   DELETE  DELETE SPECIFIED DRIVE 0 ONLY
       CMPA   #'d
       LBEQ   DELETE
       LDX    #BADARG
       JMP    ERRMSG  TELL THEM AND LEAVE
SETECM INC    DONFLG
       BRA    DCONT
SYNERR LDX    #SYNMSG
       JMP    ERRMSG
ENDCMD INC    DONFLG  SET DONE FLAG
FORMAT LDA    DRVNUM
       ORA    #'0     MAKE ASCII
       STA    DRMSG   PUT IN MSG
       LDX    #FMTMSG
       JSR    PSTRNG
       LDB    STBLCK
       JSR    OUTHEX
       LDA    #'-
       JSR    PUTCHR
       LDX    #ENDBLK
       JSR    OUTHEX
       LDX    #DRVMSG TELL THEM
       JSR    PDATA


       LDY    #0      INIT FREE SEC CTR
       LDA    STBLCK  GET SEGMENT START ADDR
       STA    GOODTK  LAST 'GOOD' TRACK #
TRKLP  LDX    #WINDOW SET BASE ACCESS ADDRESS
       STA    DAT     SET FOR TESTING
       LDB    #$45    GET TEST BYTE
       STB    $7FF,X  PUT IT
       CMPB   $7FF,X  IS IT SAME?
       BNE    NXTTRK  NO, TRY NEXT TRACK
       S?B    $FFF,X  TRY DIFFERENT ADDR JUST TO MAKE SURE
       CMPB   $FFF,X
       BNE    NXTTRK
       LDB    #2      YES, FORMAT IT
       STA    GOODTK  THIS IS GOOD TRACK
SECLP  STD    ,X++    SET FWD LINK
       PSHS   B       SAVE
       LDB    #$254   COUNTER
CLRSEC CLR    ,X+
       DECB           CNT DOWN
       BNE    CLRSEC
       PULS   B       GET BACK
       INCB           BUMP
       LEAY   1,Y     COUNT SECTORS
       CMPX   #WINDOW+$1000 LAST ON TRACK?
       BLO    SECLP   NOT LAST
NXTTRK LDB    GOODTK
       STB    MAXTRK  SAVE HIGHEST TRACK
       STD    DAT     PAGE IT IN
       LDB    #1      FIRST SECTOR, NEXT TRACK
       INCA           BUMP TO NEXT TRACK
       BEQ    MRKEND  END OF ALL MEMORY
       CMPA   ENDBLK  DONE?
       BHI    MRKEND
SET    STD    WINDOW+$F00 SET LINK
       BRA    TRKLP   DO NEXT SEGMENT
MRKEND LDA    GOODTK
       CMPA   STBLCK  MAKE SURE SOME GOOD MEMORY WAS FOUND
       LBEQ   NOMEM
       CLRA
       CLRB
       STD    WINDOW+$F00


* MARK DIRECTORY END - ASSIGN ONLY ONE DIRECTORY SECTOR & LET
* FLEX EXTEND IT AS NECESSARY

       LDA    STBLCK  GET FIRST BLOCK
       STA    DAT     SET
       CLRA
       CLRB
       STD    WINDOW+$100 MARK END OF DIR

* BUILD SIR

       LDA    STBLCK  GET FIRST TRACK
       STA    DAT
       LDX    #WINDOW
       CLR    ,X+
       CLR    ,X+     CLEAR OUT LINK
       LEAX   14,X
       LDU    #VOLNAM SET VOLUME NAME
NAMLP  LDB    ,U+
       STB    ,X+
       CMPU   #VOLNAM+11
       BLO    NAMLP
       LDB    #1      SET VOLUME NUMBER
       STD    ,X++
       LDA    STBLCK  SET FIRST AVAIL SECTOR
       LDB    #3
       STD    ,X++
       LDA    MAXTRK  GET LAST TRK
       LDB    #$10    MAX SEC ON TRK
       STD    ,X++
       PSHS   D       SAVE
       LEAY   -2,Y    REDUCE SEC CNT FOR SIR & DIR SEC
       STY    ,X++    SET SECTOR COUNT
       LDD    DATE    SET DATE
       STD    ,X++
       LDA    DATE+2
       STA    ,X+
       PULS   D       GET MAX TRK/SEC
```

```
        STD   ,I++ SET MAI TRK/SEC              BNE  RMLP NO
        BRA   INIT                              BRA  EXIT YES

* PRESERVE EXISTING INFO                 DELETE LDA  DRVNUM
                                                LDU  @STBLKS
NOFMT LDA   STBLCX  SET DAT FOR SIR             CLR  A,U
      STA DAT                                   LDA  #$FF    DESELECT
      LDI @INDCN+16 SET FOR COMPARE             STA  SELECT
      LDU @VOLNAM                               BRA  EXIT
CMPLP LDB ,U+
      CMPB ,I+                          * HEI INPUT SUBROUTINE - ONLY ACCEPTS FIRST TWO DIGITS
      BNE NOMTCH FAIL
      CMPU @VOLNAM+11                   GETHEI CLRB
      BNE CMPLP NOT END, KEEP ON               PSHS  B      TEMPORARY STORAGE
      LDY 6,1 GET SECTOR CNT            GHLOOP JSR   NITCH  GET CHARACTER
      LDA 11,1 SET MAI TRK                     BSR   GETDIG GET DIGIT
      STA MAITRK SET                           BCS   GHEIIT EXII IF NOT HEI
                                               INCB         BUMP COUNTER
* INITIALIZE SWITCHES                          CMPB  #2
                                               BHI   GHLOOP IGNORE DIGITS AFTER SECOND
INIT LDA @STDDAT RESET DAT TO NORMAL           ASL   0,S    ALIGN MS NIBBLE
     STA DAT                                   ASL   0,S
      LDD   DSKVEC+1 ARE WE ALREADY 'IN'?       ASL   0,S
      CMPD  @READ                               ASL   0,S
      BEQ   NOCLR  YES, DON'T CLEAR STARTING BLOCK TABLE   ORA   0,S    MERGE IN LS NIBBLE
      LDI   @STBLKS                             STA   0,S    SAVE IT
CLRSLP CLR  ,U+                                 BRA   GHLOOP
       CMPU @STBLKS+10
       BLO  CLRSLP                       GHEIIT PULS  A,PC   GET BYTE AND RETURN
NOCLR LDA   #$FF
      STA SELECT INIT SWITCH TO NOT SEL  GETDIG CMPA  #'0
      LDU   @STBLKS PUT STARTING BLOCK IN TABLE       BLO   NOTHEI
      LDB   DRVNUM                              CMPA  #'F
      LDA   STBLCK                              BHI   NOTHEI
      STA   B,U                                 CMPA  #'9
     LDD @$1001 SET INIT TRK/SEC               BLS   SKPADJ
     STD TRACK                                 CMPA  #'A
                                               BLO   NOTHEI
* TELL THEM WE ARE DONE                        SUBA  #7
                                        SKPADJ ANDA  #$F
     LDI @MSG                                  CLC
     JSR PSTRNG                                RTS
     PSHS Y SAVE TOTAL SECS             NOTHEI STA   TERMCH STORE TERMINATING CHAR
     TFR S,1 GET PTR TO SAVED                  SEC
     CLRB SET ZERO FLG                         RTS
     JSR OUTDEC OUT CNT
                                        PBLOOP JSR   PUTCHR
* MOVE OLD DISK I/O VECTORS AND REPLACE PDATA  LDA   ,I+
                                               CMPA  #EOL
     LDD DSKVEC+1 GET READ ADDR                BNE   PBLOOP
     CMPD @READ IT IS US                       RTS
     BEQ EXIT DONT MOVE VECTORS TWICE
     LDI @NEWVEC MOVE IN NEW VECTORS    DRVNUM RMB   1       DRIVE # CURRENTLY BEING FORMATTED
MVMLP LDA ,I+                           MAITRK RMB   1       MAI TRACKS SIMULATED
      LDD DSKVEC-NEWVEC-1,I SAVE OLD    STBLCK RMB   1       STARTING BLOCK OF CURRENT 'DRIVE'
      STA DSKVEC-NEWVEC-1,I SET NEW     ENDBLK RMB   1       ENDING   "    "    "    "
      STD DSKVEC-NEWVEC+SIZE-1,I SET MOVED OLD TERMCH RMB   1       GETHEI TERMINATING CHARACTER
      CMPI @NEWVEC+SIZE DONE?           STFLAG RMB   1       START BLOCK PROCESSED FLAG
      BLO MVMLP NO                      DONFLG RMB   1       COMMAND COMPLETELY PARSED FLAG
      BRA EXIT                          GOODTK RMB   1       LAST GOOD TRACK

NOMTCH LDI @NOTFM                       * MESSAGES
       BRA ERRMSG
NOMEM LDI @NOMEMM                       VOLNAM FCC 'HYPERDSK#L1'
ERRMSG LDA @STDDAT SET DAT BACK TO NORMAL FMTMSG FCC 'Formatting ',EOL
       STA DAT                          DRVMSG FCC ' as drive '
       JSR PSTRNG                       DMSG FCC '0',EOL
     JMP WARMS ALL DONE INITIALIZING    MSG FCC 'Total Sectors Available: ',EOL
EXIT   TST   DONFLG  ANYTHING ELSE ON COMMAND LINE? NOMEMM FCC 'NO MEMORY AVAILABLE',EOL
       LBEB  PARSE4  YES, CONTINUE PARSE BADARG FCC 'BAD OPTION',EOL
       JMP   WARMS   ELSE OUTT          NOTFM FCC 'MEMORY NOT FORMATTED',EOL
                                        SYNMSG FCC  'SYNTAI ERROR - PLEASE RETYPE COMMAND',EOL
* REMOVE I/O VECTOR CHANGES
                                        * NEW DISK DRIVER ROUTINE VECTORS
REMOVE LDD DSKVEC+1 GET ADDR OF READ JMP
       CMPD @READ IS IT US?             NEWVEC JMP READ
       BNE EXIT NO, NOTHING TO DO             JMP WRITE
       LDI @DSKVEC INIT PTR                   JMP VERIFY
RMLP LDA SIZE,I                               JMP RESTOR
     STA ,I+ MOVE                             JMP DRIVE
     CMPI @DSKVEC+SIZE DONE?
```

```
        JMP CHKRDY
        JMP CHKRDY (QUICK)
        LBRA **SIZE INIT, PASS THRU
        LBRA **SIZE WARM, PASS THRU
        JMP SEEK
SIZE EQU *-NEWVEC TABLE SIZE
        PAG
* DISK DRIVER SIMULATOR FOR HYPERDISK

        ORG DSKVEC+SIZE LEAVE SPACE FOR ORIGINAL VECTORS
RD RMB 3 SPACE FOR MOVED VECTORS
WR RMB 3
VFY RMB 3
RES RMB 3
DRV RMB 3
CHK RMB 3
BLK RMB 3
    RMB 6 PASSED THRU
SK RMB 3

STBLKS RMB    10      STARTING BLOCKS FOR DRIVES 0-9
SELECT RMB 1 DRIVE WHICH IS SELECTED, $FF IF NONE
TRACK RMB 1 SIMULATED TRACK REG, SET BY SEEK & RESTORE
SECTOR RMB 1 SIMULATED SECTOR REG
MAXSEC FCB $10 MAX SECTOR SIZE

CHKNUM PSHS   B,U
        LDB 3,1 GET DRIVE NUM
        LBU   #STBLKS
        LDA   8,U
        PULS  B,U,PC


CHKRDY PSHS   A
        BSR   CHKNUM
        PULS  A

    BEQ CHK
    CLRB SET AS RDY
    RTS


DRIVE PSHS   A
        BSR   CHKNUM
        PULS  A
        BNE SEL
        LDB   #$FF
        STB SELECT TURN US OFF
BRA DRV GO DO REAL
SEL LDB 3,1 TURN US ON
    STB SELECT
    CLRB SET NO ERROR
    RTS


RESTOR PSHS   A
        BSR   CHKNUM
        BNE   RES1
        PULS  A
        BRA   RES      PASS THROUGH
RES1   LDB #$01 SET AT FIRST SECTOR
    STB TRACK
        PULS  A
    CLRB SET NO ERROR
    RTS


SEEK  PSHS   A
        LDA   SELECT  ARE WE SELECTED?
        CMPA  #$FF
        PULS  A
    BEQ SK NO, PASS IT ON
        PSHS  U
        LDU   #STBLKS GET BASE FOR STARTING BLOCKS
CMPD #$1RSEC IS IT $1R?
BNE SK1 NO
        LDA   SELECT GET DRIVE #
        LDA   A,U    GET STARTING BLOCK
        LDB   #1     SET TO FIRST SEC
SK1 CMPD #DIRSEC IS IT DIRECTORY START?
BNE SK2 NO
        LDA   SELECT
        LDA   A,U
        LDB   #2     SET TO SECOND SECTOR
SK2   PSHS  B
        LDB   SELECT
```

```
        CMPA  B,U
        PULS  B,U
BLO NOTFND
        CMPB  MAXSEC
        BHI   NOTFND
STB TRACK SET FOR R/W
CLRB SET NO ERROR
RTS
NOTFND LDB #$10 SET RNF ERROR
RTS


VERIFY PSHS   A
        LDA   SELECT
        CMPA  #$FF
        PULS  A
LBEQ VFY NO, PASS ON
CLRB YES, WAS GOOD
RTS


WRITE PSHS   A
        LDA   SELECT
        CMPA  #$FF
        PULS  A
LBEQ WR NO
BSR SEEK GO TEST AND SET
BNE ERROUT
PSHS U SAVE
BSR RWSET
EXG X,U SET PROPER TO-FROM REGS
BRA IFER
READ  PSHS   A
        LDA   SELECT
        CMPA  #$FF
        PULS  A
LBEQ RD NO, PASS ON
BSR SEEK SEEK AND LIMIT TEST
BNE ERROUT
PSHS U SAVE
BSR RWSET GO SET UP FOR OP
IFER TFR I,0 GET TO ADDR
INCA BUMP ONE SECTOR
PSHS 0 SAVE FOR COMPARE
LOOP LDD ,U++ GET WORD
STD ,I++ SET WORD
CMPI ,S ARE WE DONE?
BNE LOOP NO
LEAS 2,S REMOVE COMPARE
LDA #STDDAT
STA DAT SET BACK NORMAL
PULS U RESTORE
CLRB SET GOOD
ERROUT RTS


RWSET LDA TRACK
STA DAT SET DAT AT TRACK
LDU #WINDOW SET SECTOR ADDR
LDA SECTOR
DECA BUMP BACK
CLRB
LEAU D,U CALC SEC START
RTS


END START
```

DOUBLE DATE ISSUE

As some of you might have noticed, this issue carries two dates AUGUST/SEPTEMBER 1984. The reason being that we are growing on the newsracks. Because of date/time considerations we needed a little more time than our present issue dating allowed on the bookrack shelves. Hence, the double dating.

This will in no way affect your subscription frequency. You will still receive the proper number of issues. It will just be that if your subscription expired in say October '84 before, it will now expire in November '84. Nothing lost and a lot more exposure for our advertisers, and we sell a few more copies.

Hope you understand, nothing really changes as far as your subscription is concerned, it is just one of those technical things that occur as we 'grow'.

DMW

- - -

VDATE

FLEX Utility Reports
File Creation Date

By Geoffrey A. Gass
5240 S. W. Dosch Rd.
Portland, Oregon 97201

You may not be aware of it, but the FLEX* operating system carefully notes down in the disk directory the creation

date of every file you save. In the standard set of utilities furnished with FLEX 1.Ø (for the DMAF-1 8" disk), there is no means of accessing this information, except by single-stepping the directory and snooping in the $A89Ø-A97F region of the file sector buffer.

There is a DATE transient command, however, which allows you to read or alter FLEX' MO-DA-YR registers (this, by the way, is not the routine used when the system is first booted up: that's an input-only routine in the resident part of FLEX). As your command string is parsed by the DATE program, it jumps to an input routine if it sees something beyond the DATE or DATE.CMD filename, but simply reports the current date if there is no operand in the line.

It's a relatively simple operation for the program to look a little closer at the operand, and if it looks like a filename (starts with a letter or with one digit and a period), to use that name to open a file and extract the date information from the directory, processing it as it would the MO-DA-YR register.

*TM, Technical Systems Consultants, Inc.

There are a couple of traps to watch for. The TSC-furnished .SYS, .LOW and .CMD files have Ø-Ø-Ø as creation dates. The month-lookup routine can't handle "Ø", so a "Ø" date must be trapped out.

And, if you have been playing around and using these directory bytes for something else, you'll also need to trap out any "month" value higher than $C, or the month routine will print out garbage — maybe lots of it!

In the FLEX directory, the byte just before the month digit is not (yet) used by TSC. It's a handy place to keep track of revision numbers — particularly on files which may be revised or updated several times in a day. If you train your assembler or text editor to extract this byte on every delete operation and plug in the incremented value when you open the file for writing, you will be able to check on this revision number (1 to 255) of any file, without having to download the file itself, just by calling VDATE,FILENAME.EXT.

If the revision byte is nonzero, VDATE will report:

Rev 35 April 22, 1981

— or whatever. The "Rev" title and number are omitted if the data byte is Ø.

The original DATE routine in loader format just barely slops over into a second sector — so there's plenty of room if you want to substitute this program for the original DATE.CMD, even on a full disk.

The VDATE routine here is coded and "ORG'd" for the SWTPC 68ØØ/DMAF-1. It is no doubt adaptable to the SWTPC minifloppy and 68Ø9 versions, and perhaps to SSB FLEX as well — but I haven't seen the code on these versions, and won't promise a thing.

But if you have the original target equipment, give it a try: you'll like it!

```
ØØØ1Ø              NAM   VDATE   Modified DATE Utility
ØØØ2Ø          *          Rev Ø.3 March 28, 198Ø
ØØØ3Ø              OPT   O,NOG

ØØØ5Ø          *Provides reporting of creation/revision date
ØØØ6Ø          *of disk files; and of revision numbers if
ØØØ7Ø          *implemented, as well as current date I/O.

ØØØ9Ø          *By Geoffrey A. Gass      Portland, Oregon 972Ø1

ØØ11Ø          *External References

ØØ13Ø    AC11  LTERM EQU   $AC11   Last terminator or delimiter
ØØ14Ø    ACØ2  EOLCH EQU   $ACØ2   EOL character
ØØ15Ø    ADØ3  WARMS EQU   $ADØ3   FLEX re-entry
ØØ16Ø    A84Ø  FCB   EQU   $A84Ø   System FCB
ØØ17Ø    AD3F  RPTERR EQU  $AD3F   Error reporting routine
ØØ18Ø    AØ48  INDEC EQU   $AØ48   Decimal input, binary conv.
ØØ19Ø    AD24  PCRLF EQU   $AD24   Output CRLF
ØØ2ØØ    AD18  PUTCHR EQU  $AD18   Output character
ØØ21Ø    AD39  OUTDEC EQU  $AD39   Binary to decimal & out.
ØØ22Ø    ACBE  FMO   EQU   $ACBE   FLEX Date register
ØØ23Ø    ACBF  FDA   EQU   $ACBF
ØØ24Ø    AC1D  FYR   EQU   $AC1D
ØØ25Ø    AC14  LBUFP EQU   $AC14   Line buffer pointer
ØØ26Ø    AD2D  GETFIL EQU  $AD2D   Pick up file spec
ØØ27Ø    AD33  SETEXT EQU  $AD33   Set default ext if none.
ØØ28Ø    B4Ø6  FMS   EQU   $B4Ø6   File management system
ØØ29Ø    AD36  ADDBX EQU   $AD36   XR = XR + ACC B

ØØ31Ø A1ØØ          ORG   $A1ØØ

ØØ33Ø A1ØØ 2Ø Ø7 VDATE BRA   DATE1   Skip registers

ØØ35Ø A1Ø2 Ø1 V     FCB   1       Version
ØØ36Ø A1Ø3 ØØ REV   FCB   Ø       Rev # for files so flagged
ØØ37Ø A1Ø4 ØØ MO    FCB   Ø       From FLEX or file
ØØ38Ø A1Ø5 ØØ DA    FCB   Ø
ØØ39Ø A1Ø6 ØØ YR    FCB   Ø
ØØ4ØØ A1Ø7 ØØ NUMH  FCB   Ø       Working register
ØØ41Ø A1Ø8 ØØ NUML  FCB   Ø       LSB

ØØ43Ø A1Ø9 B6 AC11 DATE1 LDA A LTERM   Get last delimiter
ØØ44Ø A1ØC 81 ØD    CMP A #$ØD    C/R?
ØØ45Ø A1ØE 27 5A    BEQ   DATO    If so, just report date.
ØØ46Ø A11Ø 81 ACØ2  CMP A EOLCH   EOL character?
ØØ47Ø A113 27 55    BEQ   DATO    No input: output only
ØØ48Ø A115 FE AC14  LDX   LBUFP   Buffer pointer
ØØ49Ø A118 A6 ØØ    LDA A Ø,X     Have a look
ØØ5ØØ A11A 81 4Ø    CMP A #$4Ø    Alpha?

ØØ51Ø A11C 22 Ø6    BHI   FILDP   Probably a filename
ØØ52Ø A11E A6 Ø1    LDA A 1,X     Look at next-following
ØØ53Ø A12Ø 81 2E    CMP A #$2E    Period?
ØØ54Ø A122 26 Ø3    BNE   DATE2   Probably date input
ØØ55Ø A124 7E A1CF FILDP JMP   FILDAT  Must be filename.
```

```
00570 A127 8D 2F    DATE2  BSR    NUMIN     Get number from buffer
00580 A129 25 20           BCS    SYNERR    C set; bad input
00590 A12B B1 0C           CMP A  #$0C      Over 12?
00600 A12D 22 1C           BHI    SYNERR    Does not compute
00610 A12F B7 AC0E          STA A  FMO       Into FLEX date register
00620 A132 8D 24           BSR    NUMIN     Get next digit(s)
00630 A134 25 15           BCS    SYNERR    Bummer?
00640 A136 B1 1F           CMP A  #$1F      Over 31?
00650 A138 22 11           BHI    SYNERR    Don't dig long months
00660 A13A B7 AC0F          STA A  FDA       February 31 is OK.
00670 A13D 8D 19           BSR    NUMIN     For year
00680 A13F 25 0A           BCS    SYNERR    C flags NG or no data
00690 A141 B1 63           CMP A  #$63      99 in hex
00700 A143 22 06           BHI    SYNERR    Actual date + 256 is OK.
00710 A145 B7 AC10          STA A  FYR       To FLEX
00720 A148 7E AD03          JMP    WARMS     All done.

00740 A14B CE AB40  SYNERR LDX    #FCB      System control block
00750 A14E C6 1A           LDA B  #$1A      Syntax error (#026)
00760 A150 E7 01    SYNER1 STA B  1,X       Into Error Status byte
00770 A152 BD AD3F          JSR    RPTERR    FLEX routine
00780 A155 7E AD03          JMP    WARMS     Back to FLEX.

00800 A158 BD AD40  NUMIN  JSR    INDEC     Input & binary conversion
00810 A15B 25 0C           BCS    NUMEX     Bad input
00820 A15D 5D            TST B            Check for no-input
00830 A15E 27 0B           BEQ    NREJ      Delimiter -- no digits
00840 A160 FF A107          STX    NUMH      Four hex digits
00850 A163 B6 A108          LDA A  NUML      Get LSB only
00860 A166 0C             CLC              All's well
00870 A167 39             RTS
00880 A168 0D     NREJ   SEC              Bounce flag
00890 A169 39     NUMEX  RTS

00910              *DATO will output REV (if any), MO, DA, YR.

00930 A16A CE AC0E  DATO   LDX    #FMO      Start of FLEX date registers
00940 A16D A6 00    DAT01  LDA A  0,X       Entry for creation date
00950 A16F B7 A104          STA A  MO        Local register
00960 A172 EE 01           LDX    1,X       Get DA, YR
00970 A174 FF A105          STX    DA
00980 A177 BD AD24          JSR    PCRLF     Do a CRLF
00990 A17A F6 A103          LDA B  REV       Look at REV register
01000 A17D 27 0E           BEQ    DAT02     Nothing? Omit mention.

01010 A17F CE A294          LDX    #REVT     'Rev '
01020 A182 BD A18D          JSR    STRNGO    Output text
01030 A185 17             TBA              Swap # into A
01040 A186 8D 3A           BSR    NUMO      Output it
01050 A188 86 20           LDA A  #$20      Space
01060 A18A BD AD18          JSR    PUTCHR    Output that

01080 A18D B6 A104  DAT02  LDA A  MO        Get month (binary)
01090 A190 27 22           BEQ    ENDPRT    00? Print one zero.
01100 A192 CE A29E          LDX    #MOTAB    Table of names
01110 A195 4A     NEXM   DEC A            Count 'em out
01120 A196 27 0B           BEQ    DPRINT    Found it? Print it.
01130 A198 08     LOOP   INX              Step to next
01140 A199 6D 00           TST    0,X       Looking for 00 delimiter
01150 A19B 26 FB           BNE    LOOP
01160 A19D 08             INX              Past delimiter
01170 A19E 20 F5           BRA    NEXM      Try this one

01190 A1A0 8D 1B   DPRINT BSR    STRNGO    Run month name
01200 A1A2 86 20           LDA A  #$20      Space
01210 A1A4 BD AD18          JSR    PUTCHR    Output it
01220 A1A7 B6 A105          LDA A  DA
01230 A1AA 8D 16           BSR    NUMO
01240 A1AC CE A209          LDX    #CENTUS   Text string ', 19'
01250 A1AF 8D 0C           BSR    STRNGO    Run it
01260 A1B1 B6 A106          LDA A  YR
01270 A1B4 8D 0C   ENDPRT BSR    NUMO
01280 A1B6 7E AD03          JMP    WARMS     All done.

01300 A1B9 8D AD18  STRNG1 JSR    PUTCHR
01310 A1BC 08             INX
01320 A1BD A6 00    STRNGO LDA A  0,X       Entry point
01330 A1BF 26 FB           BNE    STRNG1
01340 A1C1 39             RTS              00 is delimiter

01360 A1C2 5F     NUMO   CLR B            No leading zeros
01370 A1C3 F7 A107          STA B  NUMH      No garbage in MSB
01380 A1C6 B7 A108          STA A  NUML      Data
01390 A1C9 CE A107          LDX    #NUMH     Pointer for 4 digits
01400 A1CC 7E AD39          JMP    OUTDEC    Print the last 1 or 2

01420              *FILDAT looks up a file creation date

01440 A1CF CE AB40  FILDAT LDX    #FCB      Use system FCB
01450 A1D2 BD AD2D          JSR    GETFIL    Get filename from buffer
01460 A1D5 24 04           BCC    FILO1     OK? Set loop
01470 A1D7 C6 15           LDA B  #$15      Code for filename error
01480 A1D9 20 26           BRA    FERR
01490 A1DB 86 01    FILO1  LDA A  #1        Open for read
01500 A1DD A7 00           STA A  0,X       Into FCB
01510 A1DF 86 99           LDA A  #9        Default extension (.BIN)
01520 A1E1 BD AD33          JSR    SETEXT    Set default if no ext.
01530 A1E4 8D 8406          JSR    FMS       Open file
```

```
01540 A1E7 26 16           BNE    FERR1
01550 A1E9 86 04           LDA A  #4        Close-file code
01560 A1EB A7 00           STA A  0,X
01570 A1ED BD 8406          JSR    FMS       Do it
01580 A1F0 26 0D           BNE    FERR1     Problems?
01590 A1F2 A6 18           LDA A  $18,X     Byte 24, non-FLEX Rev #
01600 A1F4 B7 A103          STA A  REV       FLEX files will have 00
01610 A1F7 C6 19           LDA B  #$19
01620 A1F9 BD AD36          JSR    ADDBX     Point to creation date
01630 A1FC 7E A16D          JMP    DAT01     Load MO-DA-YR and output.

01650 A1FF E6 01    FERR1  LDA B  1,X       Get error code
01660 A201 7E A150  FERR   JMP    SYNER1    Report & exit

01680 A204 52     REVT   FCC    /Rev /
01690 A208 00             FCB    0
01700 A209 2C     CENTUS FCC    /, 19/
01710 A 0D 00             FCB    0

01730 A29E 4A     MOTAB  FCC    /January/
01740 A215 00             FCB    0
01750 A216 46             FCC    /February/
01760 A21E 00             FCB    0
01770 A21F 4D             FCC    /March/
01780 A224 00             FCB    0
01790 A225 41             FCC    /April/
01800 A22A 00             FCB    0
01810 A22B 4D             FCC    /May/
01820 A22E 00             FCB    0
01830 A22F 4A             FCC    /June/
01840 A233 00             FCB    0
01850 A234 4A             FCC    /July/
01860 A238 00             FCB    0
01870 A239 41             FCC    /August/
01880 A23F 00             FCB    0
01890 A240 53             FCC    /September/
01900 A249 00             FCB    0
01910 A24A 4F             FCC    /October/
01920 A251 00             FCB    0
01930 A252 4E             FCC    /November/
01940 A25A 00             FCB    0
01950 A25B 44             FCC    /December/
01960 A263 00             FCB    0,$FF

01980 A04B            ORG    $A04B
01990 A04B A100          FDB    $A100    Transfer address.
02000            END
```

TOTAL ERRORS 00000

Dear Editor,

At one time I was very interested in the 6809 CPU. I owned a computer from SWTPC which included dual disk drives and the FLEX operating system. Needing a better version of a 6809 based computer I bought a Radio Shack 64k Color Computer. At the time I had received a few free issues of the Color Micro Journal and read about the deficiencies in the Radio Shack disk system. I decided to buy their new disk controller and mate it to my dual floppy. The dealer seemed to think that was O.K., and that was when the trouble started. He did not realise that Radio Shack keeps things to themselves. After going to a lot of trouble to get all the parts he found that a manual was not available. He was a decent guy, but I still got so mad I set the entire computer aside and have not touched it since. After 25 years as an Electronic Engineer I have learned that some things are not worth bothering with. Radio Shack could have done a lot with that computer, but seems to be just too cheap and greedy.

This brings me to the substance of my letter. Why does "American Management" make such bad decisions? What happened to personal pride in a job well done? My experience has been that even though engineering is sometimes difficult, it is infinitely more difficult to talk to management. Witness the millions that have been lost in the computer field by c panies that "had it made". I have seen people who seem much smarter than I am (and whom I personally liked) make absolutely unworkable decisions. No wonder the Japanese can penetrate our mar et so easily.

Of course we all make mistakes. When I do, I make no bones about it. Hiding an error hurts everyone, and can end up costing more than most people are willing to admit.

In the publication you work for you come in constant contact with software and hardware that just does not work right. There is no excuse for this, but it happens all the time. I have seen equipment costing more than $10,000 which was not even a good boat anchor. At my last job I saw a computer driven test system built that was a joke from the start. When all the smoke cleared the grapevine had it that a quarter million went down the tubes. I knew most of the people involved. Not one of them was unintelligent or dishonest, but still the fiasco went ahead.

Perhaps I should not unload all this on you. You are probably quite busy, and have heard all this before. What I am really trying to find out is the description of the new Radio Shack Color Computer disk controller, and whether the computer is worth developing hardware and software for. After working with FLEX, CPM, OS8, RTS8 and proprietary operating systems and building working hardware, I feel I have the qualifications needed.

Eds Note: This letter was sent to us with a request that this letter not be published since the writer felt that by having his name appear at the bottom, it might not be too difficult for someone to figure out which company he worked for and possibly the people he mentioned. Since some of the thoughts expressed in this letter are shared by many in the SS50 industry, I have taken the responsibility of inserting it into the Bit Bucket.

Sincerely,
Larry E. Williams
Exec. Editor

- - -

ALL Computer Systems Consultants Software
runs on the Color FLEX System
ALL in stock
call 800-338-6800
for **OVERNITE DELIVERY**

Computer Systems Center

COMPUTE +

An "easy to use", powerful Disassembler for Disk Resident 6809
and 6800 Binary Files. Allows the development of a "Control
File" of various Program "Boundaries" during successive
disassemblies; can use a Label File which automatically replaces
a Hex location with a Label Name; includes an XREF Utility; etc.
Label Files provided for Mini-FLEX, FLEX2, FLEX9, Color Computer
(for use with Color FLEX Systems), etc. OS-9 Version includes
special OS-9 options.

CCF, Obj. Only			$100.00
ECO,	"	"	$59.95
F,	"	"	$100.00
O,	"	"	$150.00
U,	"	"	$300.00

COMPILERS & DECOMPILERS

6809 "Structured" Assembly Lang. Compilers

Windrush Micro Systems

PL/9

By Graham Trott. A combination Editor/Compiler/Debugger, all in
ONE PACKAGE; provides a totally INTERACTIVE Program Development
Cycle. The Single-Pass Compiler supports large Symbol Names;
Variable Types; Pointers; Control Structures (similar to 'C' or
'Pascal'); Stack, A-, B-, and D-Register manipulation; etc. The
Source-Oriented Trace/Debugger provides Single Stepping, Break-
pointing, etc. An excellent Software Development Tool which
provides for the maximum utilization of the power of the 6809.

F, CCF - **$198.00**

Whimsical Developments

WHIMSICAL

Need the Ease of Design and Maintainability of "Structured
Programming" AND the Speed and Control of Assembly Language?
Then WHIMSICAL was designed for you! This Single Pass,
Recursive Descent Compiler provides the tool for developing
simple Utilities to MAJOR Systems in Assembly Language.
Supports 3 "Lex" Levels which allow one level of Procedure
nesting, or more within "Modules". It is easy to develop
programs written for other machines since you are working at
the Assembly Language level. Features unified, user-defined
I/O; produces ROMable, relocatable, recursive, re-entrant Code;
Structured style and statements with Procedures and Modules;
supports Byte and Double-Byte primitives with 3 types of
Integers (up to 32 bit), Char and Boolean, and unlimited sized
Arrays (vectors only); Interrupt handling; unlimited length
Variable Names; Variable Initialization (defaults to $00);
Include "Source File" directive; Conditional compiling; direct
Code insertion; control of the Stack Pointer; etc. To quote
Ron Anderson in his review of WHIMSICAL in the Sept. '83 Issue
of '68' Micro Journal that, except for the lack of floats, "...,
I have to give this one VERY high rating, ...". It is a FAST
Compiler which produces FAST Code (his "Primes" Benchmark ran
at 9 secs. on a 2 MHz System).

F and CCF - **$195.00**

'C' Compilers

Windrush Micro Systems

C Compiler

By James McCosh. Full featured C Compiler for the FLEX
Operating System (lacking ONLY "bit-fields"), including an
Assembler. Requires the TSC Relocating Assembler IF the user
wishes to implement his own libraries.

F and CCF - **$295.00**

Introl

C Compiler

A full-featured C, streamlined for the 6809. Generates very
efficient object code. Output "benchmarks" close to 12MHz
68000 in 8 MHz Operations; 1.5 times faster than a 4 MHz 280
when using a 2MHz 6809 System (Re. p 43, '68' Micro Journal, May
'83). Floats, etc.

F, CCF, and O - **$375.00**
U - **$425.00**
One Year Maint. - **$100.00**

ASSEMBLERS

Southeast Media

ASTRUK09

A "Structured Assembler for the 6809" which requires the TSC
Macro Assembler. Allows direct use of structured statements
such as IF, ELSE, DO, REPEAT, etc., and provides indented level
formatting of the listing so that the structure is apparent.
Re. '68' Micro Journal, Sept. '83 (program was called "STASM09";
has been renamed due to conflicts).

A User reports

"... I'm very pleased and am now writing almost exclusively in
(ASTRUK09). I've selected it over --- for all future systems
development... As (one) of my early evaluations, I rewrote a
rather elaborate routine originally done in assembly. Out of
the 1000 bytes of code generated, the (ASTRUK09) version used
only 20 more bytes than the original. --- could not handle
this program since it uses triple-precision fixed point
arithmetic... I have a large body of code already written that
is incompatible with --- constructs. No problem with
(ASTRUK09) and the structure sure helps in understanding the
logic!"

F, CCF - **$99.95**

TSC

Macro Assembler
The FLEX STANDARD Assembler.   F,CCF $50.00
Relocating Assembler w/Linking Loader
Use with many of the C and Pascal Compilers.   F,CCF $150.00

Great Plains Comp. Co.

RRMAC
Relocating, Recursive-Macro Assembler and Linking Loader.
F,CCF $120.00; w/Source $240.00

OmegaSoft

FRALL1
Relocating Assembler and Linking Loader.
F,CCF $125.00; for One Year Maint., add $50.00

Windrush Micro Systems
MACE, by Graham Trott.   F,CCF - **$98.00**

Computer Systems Consultants

SUPER SLEUTH
Computer Systems Consultants Super Sleuth is a "Time Tested",
reliable, PROVEN Disassembler that has gained acceptance
through out the SS-50 Bus Community as an extremely POWERFUL,
INTERACTIVE, Software Tool. The Super Sleuth Software Package
consists of 3 Programs; SLEUTH (the Disassembler), CHGNAM (used
to globally Change Labels to a meaningful Name), and XREF (a
Cross Reference Generator for Source Code Files). SLEUTH will
Disassemble Memory Resident 6809 Code and 6800, 6801, 6802,
6803 (the "Baby CoCo"), 6805, 6808, 6809, and 6502 (Apple,
Atari, Commodore, etc.) Binary Disk Files. (See Aug. '83 '68'
Micro Journal "Color Users Notes" Column for a full Review.)

Color Computer	SS-50 Bus (all w/ Source)
CCO (32K Req'd)	
Obj. Only $49.00	F. $99.00
ECF, Obj. Only $50.00	U. $100.00
CCF, w/Source $99.00	O. $101.00
CCO, Obj. Only $50.00	

PASCAL Compilers

TSC
PASCAL Compiler
Native Code Compiler (UCSD Oriented).

F and CCP - $265.00

Lucidata
PASCAL Compiler
P-Code Compiler (ISO Standard). Designed especially for
Microcomputer Systems; Run-time System checks available
resources for each task, allowing operation on even minimal
computer systems. Allows linkage to Assembler Code for maximum
flexibility.

F and CCP 5" - $190.00
F 8" - $265.00

OmegaSoft
PASCAL Compiler
For the PROFESSIONAL; ISO Based, Native Code Compiler.
Primarily for Real-Time and Process Control applications. Use
custom I/O devices in place of the Pascal INPUT and OUTPUT;
Long Int. (32 Bit); Dynamic length strings; Interrupt
processing, ROM-able, PIC, Re-Entrant Code, etc. POWERFUL!
Includes Source for the Symbolic Debugger, Runtime, and several
Utilities. Requires a "Motorola Compatible" Relocating
Assembler and Linking Loader.

F and CCP - $425.00
One Year Maint. - $100.00

DECOMPILERS

Southeast Media
DUB (A UniFLEX "basic" De-Compiler)
Re-Create a Source Listing from UniFLEX Compiled basic
Programs. Easy to Use; works w/ ALL Versions of UniFLEX basic;
Output to Disk or Terminal. Time TESTED and PROVEN; SOLID!

U - $219.95

UTILITIES

Southeast Media
Basic09 XRef
This Basic09 Cross Reference Utility is a Basic09 Program which
will produce a "pretty printed" listing with each line numbered,
followed by a complete cross referenced listing of all variables,
external procedures, and line numbers called. Also included is
a Program List Utility which outputs the listing without the
overhead of building the cross reference table, which allows it
to run considerably faster when only a "pretty printed" listing
with line numbers is desired. Requires Basic09 or RunB for
operation.

```
72      EXIT10 CCP(internal) TECH counter=ALSE \ ENDLstT
73      GET BinPath.read
74      GET BinPath.Po.is \ GET BinPath.Pars
75      SEEK BinPath.IndexPoin
76      Pname=""
77      REPEAT
78        GET BinPath.char
79        Pname=Pname+CHR$(LNG)inner.07F11
80      UNTIL <nail127
81      UNTIL Done=Ondone
82      RETURN

Noise    3   26   66   70   7a
Name     3   19   39   81
OutPath  4   31   34   56
char     4   38   79   83   33   48   41   42   44   45   46
         78   79   80
round    4   22   88   73
id       9   11
30       11   13
```

O and CCO - Obj. Only -- $39.95
O and CCO - w/ Source - $79.95

Southeast Media
OS-9 VDisk
Give your OS-9 Level I System the speed of memory access that
can be several orders of magnitude over your present floppy disk
drive. Use that Extended Memory capability of your SWTPC or
Gimix CPU card (or any other that has the same format DAT).
The size of the Virtual Disk is completely variable in whole
increments of 4K up to 960K, which is all that these systems
can address beyond the base page that OS-9 Level I uses. By
putting all of your CMOS Directory on your Virtual Disk, you can
have the fastest execution speed possible (next to eating up
System Memory with all of them). You can also set up high
speed inter-process communications via random virtual disk files
and not eat up valuable system memory with pipe buffers. Some
Assembly Required - Level I ONLY.

O, obj. only - $79.95
w/ Source - $149.95

Southeast Media
O-F
---- OS/9 to FLEX - FLEX to OS/9 ----
Finally; the barrier has been removed between OS/9 and FLEX
formatted disks! Now you can READ from, and WRITE to, a Single
Sided 5" or 8" FLEX diskette from OS-9 with O-F. O-F is a new
and unique program, written in BASIC09 (with Source), that
performs the following functions;
REFORMAT: A BASIC09 Program that reformats a chosen amount of
an OS-9 disk to FLEX Format so it can be used normally by
FLEX.
FLEX: A BASIC09 Program that does the actual read or write
function to the special O-F Transfer Disk, all selected from a
user-friendly menu. Functions provided include reading the
FLEX Directory, Deleting FLEX Files, Copying both directions,
etc. All selections are interactive and complete, including
all necessary prompts to the operator.
FLEX users can read, write and use the special disk as any
other FLEX disk, provided the FLEX directory is not allowed to
continue beyond track zero (too many files).

F and CCF - $79.95

Southeast Media
COPYMULT
--- Copy LARGE Disks to several smaller disks ---
The following FLEX utilities allow the backup of ANY size disk
to any SMALLER size diskettes (Winchester to 8's or 5's, 8" to
5's, etc.). By simply inserting diskettes as requested by
COPYMULT, a large disk system may be downloaded to your present
floppy disk system, any size. No need to fiddle with directory
deletions or any of the other tedious operations that must be
done using the normal copy routines.
COPYMULT.CMD understands normal "copy" syntax and always keeps
up with files already copied by maintaining directories for
both host and receiving disk system, eliminating hours of
tedious keyboard entries and other time consuming cleanup
chores.
BACKUP.CMD is a special program that downloads "random" type
files, any size.
RESTORE.CMD a special program to restructure copied "random"
files for copying, or recopying back to the host system.
FREELINK.CMD a "bonus" utility that "relinks" the free chain of
floppy or hard disk thereby eliminating fragmentation.
Completely documented source files included.
ALL 4 Programs (8" or 5") $99.50

Southeast Media
CHESS 6809
Requires FLEX and DISPLAYS On Any Type Terminal
Features;
*Four levels of play.
*Swap side. *Point scoring system.
*Two display boards. *Change skill level.
*Solve Checkmate problems in 1-2-3-4 moves.
*Make move and swap sides. *Play white or black.
This is one of the strongest CHESS programs running on any
microcomputer, estimated USCF Rating 1600+ (better than most
'club' players at higher levels).

F and CCF - $79.95

Availability Legends —
F = FLEX, CCF = Color Computer FLEX
O = OS-9, CCO = Color Computer OS-9
U = UniFLEX
CCD = Color Computer Disk
CCT = Color Computer Tape

Southeast Media
DIET-TRAC Forecaster

DIET-TRAC Forecaster is an XBASIC program that plans a diet in terms of either calories and percentage of carbohydrates, proteins and fats (C P GS) or grams of Carbohydrate. Protein and Fat food exchanges of each of the six basic food groups (vegetable, bread, meat, skim milk, fruit and fat) for a specific individual.

Sex, Age, Height, Present Weight, Frame Size, Activity Level and Basal Metabolic Rate for normal individual are taken into account. Ideal weight and sustaining calories for any weight of the above individual are calculated. When a weight goal is given (either gain or loss), and a calorie plan is agreed upon between the computer and the individual, the number of days to reach the weight goal is projected. The starting and ending rate of weight loss is calculated, and a daily calendar with each day's weight for a 30-day period is printed.

                                                F - $59.95
                                                U - $89.95

Southeast Media
XDATA
A COMMUNICATION Package
for the UniFLEX Operating System

Allows UniFLEX Based Systems to Transmit and Receive files to and from other Computer Systems via Modem. Use with CP/M, Main Frames, other UniFLEX Systems, etc.
   -- Verifies Transmission integrity using checksum or CRC
   -- Automatically Re-Transmits bad blocks
   -- Transmits data in 128 byte blocks

                                                U - $299.99

Southeast Media
_JUST
Text Formatter

JUST, a Text Formatter developed by Ron Anderson, provides numerous features which make it a valuable addition to any FLEX Users Software Library. JUST is designed for formatting Text Output for Dot Matrix Printers and provides many unique features:
-Output the "Formatted" Text to the Display for format analysis and change.
-Output the "Formatted" Text to a Text File for use with the supplied FPRINT.CMD for producing multiple copies of the Text on the Printer INCLUDING IMBEDDED PRINTER COMMANDS (this Utility is very useful at other times also, and worth the price of the program by itself).
-"User Configurable" for adapting to other Printers (comes set up for Epson MX-80 with Graftrax); provides for up to ten (10) imbedded "Printer Control Commands", such as Italics on and off, boldface on and off, etc.
-Automatic compensation for a "Double Width" printed line.
-Includes the normal line width, margin, indent, paragraph, space, vertical skip lines, page length, page numbering, centering, fill, justification, etc.
-Use with ANY Editor.
-Supplied with "Structured Source" (Windrush PL/9); easy to see the flow of the program.

                                                F and CCF - $49.95

Lucidata
PASCAL UTILITIES
Requires LUCIDATA Pascal ver 3.

IREF -- produce a Cross Reference Listing of any text; oriented to Pascal Source.

                                                F and CCF - $25.00

INCLUDE -- allows the inclusion of other Files in a Source Text; has unlimited nesting capabilities. Also allows Binary File inclusions.

                                                F and CCF - $25.00

PROFILER -- produces an Indented, Numbered, "Structogram" of a Pascal Source Text File. Allows viewing the overall structure of large programs, and provides clues as to the integrity of the program. Supplied as Source Code; requires compilation.

                                                F and CCF - $25.00

Lucidata
COPYCAT
Pascal NOT required

Allows reading TSC Mini-FLEX, SSB OOS6B, and Digital Research CP/M Disks while operating under FLEX 1.0, FLEX 2.0, or FLEX 9.0 with 6800 or 6809 Systems. COPYCAT will not perform Miracles, but, between the program and the manual, you stand a good chance of accomplishing a transfer. Includes Utilities to List Directories, Copy Files, and convert Text Files when required. Also includes a Utility for investigating Physical Compatibility problems. Programs supplied in Modular Source Code (Assembly Language) to make it easier to solve unusual problems.

                                                F and CCF 5" - $50.00
                                                F 8" - $65.00

Computer Systems Consultants
FLEX DISK UTILITIES

Eight (8) different FLEX Utilities that should be a part of every FLEX Users Toolbox; Assembly Language (Source Code):
   Copy a File with CRC Errors, so it can possibly be salvaged; Test Disk for errors; Compare two Disks; a fast Disk Backup Program; Edit Disk Sectors; Linearize Free-Chain on the Disk; print Disk Identification; and Sort and Replace the Disk Directory (in sorted order).

                                                F and CCF - $50.00

WORD PROCESSORS

Alford and Associates
SCREDITOR III

EXTREMELY Powerful Screen-Oriented Editor/Word Processor. Almost 50 different commands; EXCELLENT Documentation (over 300 pages), including a full Tutorial Section to help you learn how to use the system. Features Cursor-based editing, dynamic Screen Formatting (what you see is what you get), Multi-Column display and editing, "decimal align" columns (AND add them up automatically, if wanted), define multiple keystroke macros, even and odd page number headers and footers, imbed printer control codes in text, full Justification series of commands, full "help" support, store common command series on disk for future use, etc. Easy "Set-Up" (for example, you just hit the key you want to use for a specific function, such as "cursor up", and the System reads an stores that key - no digging into tech manuals for codes, etc.); use supplied "set-ups", or remap the keyboard to what you are used too. Except for proportional printing, this package will DO IT ALL!

                                6800 or 6809 FLEX or SSB DOS, OS-9 - $175.00

Great Plains Computer Co.
STYLOGRAPH

A full-screen oriented WORD PROCESSOR -- (now runs on the Data-Comp and FHL Color FLEX Systems; uses the 51 x 24 Display Screens). Full screen display and editing (i.e., what-you see is what you get); supports the Daisy Wheel proportional printers.

                                SPECIAL CCF - $195.00
F and O - $295.00   U - $395.00

SPELL
Fast Computer Dictionary.
F. CCF, OS/9 - $125.00   U - $175.00

MAIL MERGE
Greatly extends the power and flexibility of STYLOGRAPH.
F. CCF, O - $145.00   U - $195.00

Computer Systems Center

DYNASHARE
— Multi-User, Multi-Tasking with FLEX —

Southeast Media is now shipping DYNASHARE FROM STOCK - the multi-user, multi-tasking capability of DYNASHARE allows FLEX users the advantages of more sophisticated and time saving computer usage without having to buy or learn a new language or Operating System syntax. DYNASHARE, as its name implies, allows true "time-sharing" operation under the popular FLEX operating system, and also allows each user to run two simultaneous jobs (multi-tasking); even on single-user systems. For example, while in EDIT, you can list another file or examine a directory. Or, you might look up an item in a Data Base while a Sort is in progress! DYNASHARE also provides some fringe benefits that will be greatly appreciated by FLEX users, including type-ahead, command line editing, and instant response to "escape".

DYNASHARE is the painless method! Use your existing Flex computer by simply adding 64K of RAM for each user and/or task. Fact is, you still use FLEX just like you always have! DYNASHARE is not intended as competition to UniFLEX. It does not improve on the speed of FLEX, and does not offer password protection or other niceties of a full-blown multi-user system. What DYNASHARE does do is give FLEX users a low-cost way to use existing software in a multi-user, multi-tasking environment, so your existing FLEX versions of BASIC, XBASIC, editors, assemblers, disassemblers, sort/merge packages, word processors, compilers, DYNACALC spread-sheet package, and so on are still good.

NOTE -- The initial release of DYNASHARE is for SWTPC S/09 Computers, but versions will also be available for other popular extended-memory (up to 1MEG) systems, such as HELIX and GIMIX. A minimum of 128K of RAM will be required with ALL versions. DYNASHARE requires 64K of RAM for each active task; thus a 256K system could allow foreground-background operation on two terminals, or foreground-only operation on four terminals.

AVAILABLE NOW from Southeast Media - $200.00

AUTHORS - PROGRAMMERS
QUALITY SOFTWARE NEEDED
FLEX - UniFLEX - OS/9 - Color Computer

For the past several months, we at the Southeast Media Division of Computer Publishing, Inc. (CPI), the parent company of '68' MICRO JOURNAL and COLOR MICRO JOURNAL, have debated expanding our software distribution business. Many other magazines have been doing so for years (in fact, MOST were in the Software Distribution Business BEFORE they began to publish a Magazine). Presently there are many fine examples of software that has been developed by YOU, our readers, that will never see the "light of day" due to the Cost of Advertising and TIME and Cost involved in the production, distribution, and Customer SUPPORT of that software unless SOMEONE, with enough exposure and the willingness to continually advertise, runs with the ball.

Software is the "backbone" for the REAL utilization of any Computer System, and ours are no exception! This has been no simple decision. While we realize that there could be some conflict with some of our advertisers, we ALSO hear a LOUD and CONTINUOUS cry for HELP from our Readers. From day one, the foremost concern of '68' MICRO JOURNAL has been it's READERS! Therefore, our Southeast Media Division will accept, for appraisal for possible Distribution, 6809 software; Games, Utilities, Software Development, Business Application Programs, etc.

In the past there has been too much software offered that was not quite ready. We will strive to eliminate that element. But, right up front, we tell you only that we will do our very best; nothing more. Also, we will strive to keep cost to a bare minimum, while securing for the author a fair return in royalty payments, promptly paid, and in customer support for his product.

Of course, we will expect, no -- DEMAND, that the author keep the product free of errors (bugs), and maintain it in a prompt and business like manner. Also we shall require that authors be willing to furnish 'source' for those programs that justify, by price and utility, inclusion of same. The lack of source code, properly commented, is a continual complaint we hear. Not all programs will be sold with source, but where necessary, we will insist that it be included.

In some instances the program may be small or short and not justify itself as a "single" sale product. In this event it will be combined with other like programs, and offered as a package. In that event, the royalties will be split between the various authors.

If you have software that you feel will qualify under this program, please contact one of the people below. Remember, if your software has any problems or "funnies" — GET IT STRAIGHT BEFORE YOU CONTACT US!! Also get your source code in proper shape and well commented; there is too much 99% code already drifting around.

If your software is READY contact:
Bob Nay, Don Williams, or Tom Williams

Southeast Media is a division
of Computer Publishing, Inc. (CPI),
a family of 100% 68XX support facilities.

This Index is provided as a reader service. The publisher does not assume any liability for omissions or errors.

ONCE AGAIN HAZELWOOD COMPUTER SYSTEMS demonstrates its leadership in computer technology by delivering the only computer system capable of switching between either the 6809 or the 68000 processor. Switching is easily accomplished by a simple front panel toggle switch. The reason we can offer this exclusive feature now, is that when our proven 6809 processor board was designed several years ago, we had the foresight to include the bus controls that allow processor switching.

Hazelwood Computer Systems is also proud to be the first S-50/S-64 bus manufacturer to license and deliver the OS9/68K Operating System from Microware Systems Corporation. OS9/68K is the 68000 version of the popular and powerful OS9 Operating System. Utilizing our proven MC-20 disk controller, OS9/68K can conveniently share a Winchester disk with OS9. Changing from 6809 to 68000 operation is as simple as switching processors and booting the new system from the Winchester disk.

The ease of switching processors and operating systems makes a HELIX™ dual processor system the natural choice for software development. In addition, the advanced design of HELIX™ equipment, emphasizing performance and reliability, makes HELIX™ boards and systems the best value in computing offered anywhere.

System prices vary with configuration. Call for exact pricing.

1 Megabyte dual processor HELIX™ system with 20 Megabyte Winchester and floppy disk drives.

THE SWITCH IS ON...

The CP-08 processor board utilizes a 68008 processor running at 10 Mhz clock rate. Using proprietary bus synchronization circuitry and single cycle DMA, the CP-08 achieves a marked performance increase over a 2 MHz 6809. Offering absolute compatibility with the 68000 instruction set, the 68008 addresses up to 1 Megabyte of memory. Also included on the CP-08 are up to 4K of ROM, an interrupt timer, and, with battery backup operation, a clock/calendar and 2K RAM. Implemented as a standard S-50 board, the CP-08 brings 68000 operation to S-50 bus computers.

ORDER: CP-08   PRICE: $595

The MC-20 Mass Storage Controller board interfaces up to 4 floppy and 8 Winchester disk drives to the S-50/S-64 bus. The MC-20 is an intelligent controller with its own 2 Mhz 6809 processor and 56K RAM. It provides DMA data transfers to a full 24 bit address. All disk operation requests are by logical block number, with the controller performing the necessary track/sector address calculations. Any combination of 5¼ or 8 inch floppy drives can be accommodated with all drive parameters, such as write precompensation, software controlled for each individual drive. Winchester drives are connected via a SASI bus interface. Block address mapping is provided which allows a single drive to be segmented into several logical units. The MC-20 is the controller of the MS-20 Mass Storage Subsystem which includes a 20 Megabyte Winchester drive.

ORDER: MC-20   PRICE: $695

OS9/68K offers increased performance and larger user memory space while retaining all of the features of OS9. Disk file compatibility and operational similarity assures that present OS9 users can easily transfer their operations to the 68000. Included are an editor, assembler, linker, and debugger. A C compiler is available now. BASIC09 and other languages will be avilable soon.

OS9/68K

ORDER: OS9/68K   PRICE: $250

All items available stock to 30 days. Prices subject to change without notice.

HAZELWOOD COMPUTER SYSTEMS

907 East Terra, O'Fallon, MO 63366,   314-281-1055   HELIX™

OS9 and OS9/68K are registered trademarks of microware Systems Corp. HELIX is a trademark of Hazelwood Computer Systems.